

MESSAGE TO PARENTS

Thank you for bringing home BOB THE BUILDER'S RC SCOOP. This is a toy full of imagination and fun. It's wonderful to pretend with Scoop!

Please read the instructions carefully and learn about the many different features of BOB THE BUILDER'S RC SCOOP. This will allow you to explain how the toy works in a way that is easy for your child to understand.

INSERTING THE BATTERIES

Important Note: Battery installation should be done by an adult.

To Insert Batteries in Vehicle:




(PICTURE 1)




(PICTURE 2)

1. Remove screws on battery compartment door located on bottom of vehicle. (PICTURE 1)
2. Insert 3 "AA" or LR6 (alkaline recommended). Be sure the (+) and (-) are properly matched. (PICTURE 2)
3. Replace battery door and tighten screw.

To Insert Batteries in Transmitter:



(PICTURE 3)



(PICTURE 4)

1. Uncrew and remove the battery cover. (PICTURE 3)
2. Insert 1 5V(6LR61) and replace battery door. (PICTURE 4)


CAUTION: TO AVOID BATTERY LEAKAGE

1. Be sure to insert the batteries correctly and always follow the toy and battery manufacturers' instructions;
2. Do not mix old and new batteries or alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries;
3. Always remove weak or dead batteries from the product.


TO ENSURE PROPER FUNCTION:

- Battery installation should be done by an adult.
- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the toy before being charged. (if removable)
- Rechargeable batteries are only to be changed under adult supervision.
- Only batteries of the same or equivalent type as recommended are to be used.
- The supply terminals are not to be short-circuited.
- Do not dispose of batteries in fire. Battery may explode or leak.


Operating the Vehicle:



1. Move the On/Off switch to the On position.



2. Press the right side of the button to make Scoop go forwards.



3. Press the left side of the button to make Scoop reverse and turn left at the same time.

4. Scoop's bucket will automatically move up and down when the vehicle is moving.
 5. When you have finished playing with Scoop, turn off the vehicle and transmitter.
- Note: The remote control must be within 30 feet of "Scoop" for the toy to respond.

Safety Precautions:

Adults, to ensure that the child's play is both safe and fun, please review operating instructions and the following safety rules before operating vehicle.

Caution:

1. Do not pick up vehicle while in motion.
2. Keep fingers, hair and loose clothing away from the tires and the wheel hubs while the vehicle is in operation mode.
3. To avoid accidental operation, remove battery pack when not in use.
4. Radio interference is caused by the presence of another radio-controlled vehicle operating on the same frequency as our vehicle.
5. Radio interference can be caused by the operation of your vehicle near high voltage electrical wires, large steel reinforced concrete buildings and passing trucks with CB radios.
6. Do NOT operate your vehicle over wet surfaces. Water can damage the internal electronics.
7. Do Not drive your remote control vehicle into public roadways.
8. For best results, hold antenna up, not pointed down toward the R/C vehicle. If the vehicle gets too far away from the transmitter, your signal strength will become weak and the vehicle will not function properly. The maximum range for the vehicle should be between 125 and 300 feet depending on environmental conditions.

