

Transmitter

- Pull the lid downward and install the battery
- Make sure + and - poles of the battery are positioned properly
- Remove the battery from the transmitter after playing

Vehicle

- Use screw driver to open the battery door
- Join the connectors of the NiCd pack and the vehicle
- Replace the battery door and use screw driver to close it
- Remove the battery from the vehicle after playing

HOW TO PLAY

- Turn ON the vehicle
- Operate the vehicle with transmitter

(diagram of the transmitter with steering control indication)

(diagram of the vehicle with steering indication)

TO ADJUST STEERING ALIGNMENT

(diagram of the straight line alignment tuner)

RECHARGING

- Join the connector of the 4.8V charger to the connector of the NiCd rechargeable battery
- Plug the charger into an electrical outlet
- When the recharging is over, plug out the charger from the electrical outlet and detach the connectors.

! CAUTIONS

- Battery installation should be done by an ADULT.
- Non-rechargeable batteries are not to be recharged.
- Re-chargeable battery are to be removed from the toy before being recharged.
- Re-chargeable battery are not to be recharged under ADULT supervision.
- Batteries are to be inserted with correct polarity
- Exhausted battery are to be removed from the toy.

- Only rechargeable NiCd battery in the charger provided
- NiCd rechargeable battery must be recycled or disposed of properly

DO NOT DISPOSE OF THIS PRODUCT IN FIRE, BATTERIES INSIDE THIS PRODUCT MAY EXPLODE OR LEAK

FCC STATEMENTS

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions :

- (1) This device may not cause harmful interference
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning : Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

CAUTION: Not recommended for children under aged of 6. Read all instruction before operating. Avoid hitting people, pets or furniture. Do not pick up moving vehicle. Keep hair, hands and clothing away from vehicle when power switch is turned ON. Remove batteries when vehicle is stored. **AVOID TIRE CONTACT ON PAINTED OR VARNISHED SURFACES.** Outdoor play recommended.

NOTE : This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio TV technician for help.