

Pairing your phone is simple, just follow these steps:

The system can pair up to 3 phones

1. Hold both buttons for 3 seconds  
This puts the system into pairing mode for 5 minutes
2. Go to settings or connections in your phone menu.
3. Find bluetooth menu
4. Turn Bluetooth on
5. Your phone will have a setting like:
"Search for new device", "new", "Handsfree Search" Depending on the phone the selection will vary, select the setting and the phone will search for the bluetooth kit.
6. Your phone will then display all the bluetooth devices in the area. Select **NSV_Blue**. Enter the code **1234** The system will let out a positive bleep to advise you are now paired.
7. **IMPORTANT NOKIA USERS:** If you want the kit to connect automatically you must now select edit device and select the NSV_Blue and change default to: Device Authorised "yes" or Conn Auth "yes"
This means connections when you enter the car will take place automatically.

To delete all paired phones: hold both buttons for 6 seconds.

Pairing Trouble Shooting

1. *Can not find the bluetooth menu ?* Go to your user manual of the phone for assistance.
2. *Phone will not pair ?* The system can only accept 3 phones to be paired, delete the other phones by holding both keys for 6 seconds then try again. Sometimes phones have software problems and need to be reset. Remove your battery and try again. Try deleting all other devices in your phone and try again, as you might have exceeded the maximum number of connections.
3. *My phone connects but when I enter the car it does not connect automatically ?* See instruction number 7.

1. **Connection:** After you enter the car and turn the ignition on the system will link with your phone. If it is the first time you have connected or your phone was not the last to connect it will take between 40-90 Seconds to connect. If your phone was the last to use the kit then connection will take place in less than 10 seconds. Some phones are faster than others so the kit leaves time for phone with highest priority to have a chance to connect before connecting another phone. You will hear a positive short Bleep when the kit is connected. If the system finds no connection it will give a short negative Bleep.
2. **Connection Priority:** The system decides on which phone to connect as follows.

Priority 1: Last phone to have connected

Priority 2: Phone connected most times to the kit

This means that if you have three phones linked to the system and you all enter the car at the same time, then the person who last was connected will be connected. If only the two phones who were not last to connect enter the car then who ever has used the system most in the past will get priority.

If you want to change who is using the kit then turn the bluetooth off on the phone you do not want to connect and turn off and on the ignition.

3. **Voice Dial:** By pressing the green button for two seconds you activate the voice dial function. Wait until you hear the system give a positive Bleep Bleeep and then say the name of the person you wish to call. These names must be pre-recorded and follow the instructions in your phone user manual on how to record the name. Record them in a quiet environment with engine running and windows closed for best results. To cancel a voice dial press the red button for 1 second. If the phone has no voice dials or does not support voice dial you will hear 4 negative beeps.
4. **Redial:** To redial a last called number, press the green button for 2 seconds. You will hear a short beep, followed by a "bbbbi, bbbbi ". Be careful not to press it for too long or you will disconnect the handset from the kit temporarily by activating the disconnect function after pressing for 4 seconds.

- 5. Private Call:** If you want to have a private call on your handset, after you answer the call, press the green key for 2 seconds and the kit will transfer the call to the handset. To get the call back on hands free press the green key again for 2 seconds.
- 6. Disconnect from kit:** If you enter the car and you do not want any phone calls in hands free mode, just press the red key for 4 seconds and the kit will disconnect. When calls come in they will only be in handset mode.
To manually connect again, press the green key for 2 seconds or turn the ignition off and on again.
- 7. Sound Quality:** The system uses the highest quality components and latest DSP (digital signal processing) to give you the best possible sound quality for the caller and receiver. A few things must be remembered though to give you the best results:
 - a. Road Noise:** The faster you drive the more background noise exists and the lower the sound quality for your caller. The system has excellent DSP to reduce the noise but closing your windows etc will help.
 - b. Echo Cancellation:** The system has excellent Echo cancellation to prevent the caller hearing themselves back through the kit. To give the best quality for your caller try and have the volume at the lowest level which you can still easily hear them. This helps reduce any effects of echo.
 - c. Talk at a normal level:** Some older phone systems you had to yell at the system for people to hear you. This system uses the latest in sensitive microphones to allow talking at a normal level. If you yell at the system actually the voice will be reduced in volume by the DSP and you might even sound quieter. Just talk at a normal level and your caller will easily be able to hear you.
- 8. Customer Service:** If you have any problems with operation of the system then please contact your supplier for help.

**Pairing Mode: Hold both   for 3 seconds
You will hear a long buzz noise and then pair your phone**

ID: NSV - blue Code: 1234

Making and Answering Calls

-  **Answer** short press
-  **Reject** short press
-  **Voice Dial** short press
-  **Redial** press 2 sec
-  **Cancel dial** press 1 sec

In a call

-  **Volume up** short press
-  **Volume down** short press
-  **Private Call** press 2 sec
-  **Reconnect Call** press 2 sec
-  **Hang Up** press 2 sec

Advanced

-  **Disconnect** 4 Seconds
(temporary disconnects phone until either you manually connect again or turn ignition off and on again.)

-   **Delete pairings** 6 Seconds
(Deletes all paired phones from the system, a long buzz is heard and then two blips and then a long buzz, you need to pair the phones again)

FCC statement in User's Manual (for class B)

"Federal Communications Commission (FCC) Statement

This Equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.**
- Increase the separation between the equipment and receiver.**
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.**
- Consult the dealer or an experienced radio/TV technician for help.**

FCC Caution:

1. The device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:
 - (1) This device may not cause harmful interference, and
 - (2) this device must accept any interference received, including interference that may cause undesired operation.

2. This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

3. Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user authority to operate the equipment.