

A grayscale photograph showing the interior floor of a vehicle. A single white dashed line runs diagonally from the bottom left towards the top right. The floor has a textured, speckled pattern.

TOYBTHF

Owner's Manual

Bluetooth Hands Free Vehicle Kit

IMPORTANT NOTE: The operation of the Bluetooth Hands Free Kit as described in this manual is applicable to most phones. However, due to the configuration of some phones, some functions may not apply. Please see your installing dealer for more information.

Using Your Bluetooth Hands Free Kit

Powering On/Off

The bluetooth kit will automatically turn on when the vehicle's key is turned to the accessory position and will remain on until the vehicle's accessory power is turned off. After turning on, the bluetooth kit will automatically search for phones that have been paired with it. Since it is possible to have multiple phones paired to the system the order of priority of connecting will be the latest phone paired, the phone most used with the system, the phone second most used phone with the system. If the bluetooth kit has not been paired to a phone pairing will automatically activate.

Making a Call

When connected to the bluetooth kit you may use your phone as normal to dial numbers or search your contacts list or by using Voice Dialing.

Voice Dialing

To activate voice dialing press the ANSWER key on the bluetooth keypad, the system will prompt you for a command. Clearly speak your command (example, Call Shaun). The system will then confirm the command and in this example will then call Shaun.

Ending a Call

To end a call press the ANSWER key.

Answer a Call

When there is an incoming call the vehicle's radio will be muted/turned off and the call will ring through the vehicle's speaker, to answer press the ANSWER key.

Ignore an Incoming Call

To ignore an incoming call press the ANSWER key 2 times quickly.

Redial the Last Number

To redial the last number press the UP key then the ANSWER key within 1 second.

Adjusting the Call Volume

While in a call, adjust the volume up/down with the UP key or DOWN key, each press raises or lowers the volume by 1 level. When the min/max volume is reached the system will beep 2 times through the speaker.

Transfer a Call

To transfer a call between bluetooth hands free or normal phone operation press and hold the UP key on the bluetooth keypad for 2 seconds.

Mute the Bluetooth Microphone

To mute/un-mute the bluetooth's mic press and hold the DOWN key on the bluetooth keypad for 2 seconds. The bluetooth kit will automatically un-mute.

Pairing

To activate phone pairing press both the UP and DOWN keys at the same time. At this time you will need to activate pairing on the phone, see your phones owners manual. The PIN code for pairing is 1234 and will need to be entered into your phone at the time of pairing.

*Throughout this manual, 'press' refers to pressing for less than 1 second, 'press and hold' refers to pressing for 2 seconds.

Using Your Bluetooth Hands Free Kit, continued

Manual Search for Paired Phone

If your phone is not connected to or has been disconnected by you from the bluetooth kit but has previously been paired to the system you can activate the manual search which will locate your phone and connect to it. To activate a manual search press the ANSWER key.


Reset / Clear All Paired Phones

To permanently remove all paired phones from the bluetooth kit press and hold both the UP and DOWN keys together for 5 seconds.

Quick Reference

Quick Reference Guide

FUNCTION	KEYPAD BUTTON	NOTES
Power Unit Up	-	Turn vehicle accessory ON
Make a Call	-	Use phone as normal
Voice Dialing	ANSWER	Press and release
End Call	ANSWER	Press and release
Answer Call	ANSWER	Press and release
Ignore Call	ANSWER	Press 2 times
Volume	UP or DOWN	Press and release
Transfer Call	UP	Press and hold for 2 seconds
Mute	DOWN	Press and hold for 2 seconds
Pairing	UP + DOWN	Press both buttons together
Manual Search	ANSWER	Press and release
Reset	UP + DOWN	Press together for 5 seconds



FCC COMPLIANCE

This device complies with Part 15 of the FCC rules and with RSS-210 of Industry Canada. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including any interference that may cause undesired operation.

Warning!

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC statement in User's Manual (for class B)

"Federal Communications Commission (FCC) Statement

This Equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.**
- Increase the separation between the equipment and receiver.**
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.**
- Consult the dealer or an experienced radio/TV technician for help.**

FCC Caution:

- 1.The device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:
 - (1) This device may not cause harmful interference, and
 - (2) this device must accept any interference received, including interference that may cause undesired operation.
- 2.This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.
3. Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user authority to operate the equipment.