
User Manual RX & TX

Rev 1.0




Product information is subject to change without prior notice.

Transmitter (TX or RX)


Easily mirror whatever shows on your laptop or mobile screen, ideal for video-watching, game-play, and idea sharing.

* The Type-C connector model is the TX, while the HDMI connector model is the RX.



Receiver (RX)

Display the contents passed from your transmitter on the big screen like HDTV or projector screen.



How to mirror

1 Install the receiver

Use the Type C connector to connect EH-WD9905 to the HDMI port on TV, and power on by an independent power 5V/1A adapter.

2 Plug and play


Plug EH-WD9905 Transmitter to Type C or HDMI port on laptop or mobile. Wait a few seconds until the flashing light on transmitter stops, and it will start mirroring automatically.

When using the Transmitter TX (HDMI connector), using the Type C connector connect to an independent power 5V/1A adapter.



3 Stop and restart mirroring

Press the mirror / pair button on the transmitter to stop mirroring or restart mirroring.



Note: EH-WD9905 Transmitter support mirroring for all laptops including Windows and MacOS, and Android mobiles with DP Alt output. To reset to default, press the reset button for 5s.

How to pair Transmitter with receiver


1 Turn on pairing mode for the receiver

- (1) Power up the receiver by an external adapter (5V/1A). (2) Plug the receiver to the HDMI port on the monitor. (3) Press the reset button on receiver for 2 seconds.



2 Press the Mirror / Pair button on Transmitter

Plug the transmitter on laptop or mobile, when using the Transmitter TX, please make sure using the Type C connector to provide power. Press the mirror / pair button on the transmitter for 5 seconds to complete pairing while the screen shows "Ready to pair" . After paired, it will start casting automatically.



Note: There are 2 mode for reset button on Receiver, depending on

- ressing duration.

 (1) Press for 2 seconds: Turn on pairing mode for the Transmitter.

 (2) Press for 10 seconds: Reset the Receiver to default.

Product informations

- Pitteristic Filoman inge - NCC 警路

NCC 警路
取得香盤服明之低功率封婚器材、非經結准、公司、商號或使用者均不得擅自變更排率、加大功率或變更層設計之 特性及功能、促功率封辦器材之使用不得影響執致全及不確於法國信、超级財务干燥期余時、國立即停用、並改 基本無干燥時方型離離使用。成分直域性、指核衛性管理法规定作業之無線電道信。低功率封頻器材准必受合法 透信或工業、科學及蓋衛用電及範對性系機設得之干燥。