

INSTRUCTIONS




Congratulations on your purchase of the DiscoveryTM 3-Way Walkie Talkie with Base Station. Keep this instruction manual, as it contains important information for future reference.


SAFETY WARNINGS

- Read all safety warnings before use.
- Use this product only for its intended purpose. Do not use attachments of any kind.
- This product has no user serviceable components. Do not disassemble.
- Inspect the product before every use. If the product appears damaged in any manner, discontinue use and discard immediately.

CONTENTS



BATTERY INSTALLATION



Using a Phillips head screwdriver, remove the bottom battery cover of the Base Station and Walkie Talkies. Insert 1 "9V" size battery (not included) in each in the polarity direction shown in the diagram. Replace the battery cover and tighten the screw.


BATTERY WARNING:

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.
 Insert batteries using the correct polarity. Do not short-circuit the supply terminal.
- Remove batteries when not in use. Recycle or dispose of exhausted batteries according to federal, state, and local laws. Do not dispose of batteries in a fire they may leak or explode.
- Only use manufacture specified battery(ies), charger(s) and/or adapter, if applicable, specified
- Always use, replace, and recharge (if applicable) batteries under adult supervision.


KEEP THIS PACKAGING FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION.

3-Way Walkie Talkie

HOW TO USE



Slide the Walkie Talkie Switch down to turn the Walkies ON. Rotate the Base Station Knob clockwise to turn Base Station ON. The knob is also used to control the volume of the Base Station.



Press and hold the Push To Talk Button to transmit sounds. Release the Push To Talk Button to receive signals. A squeaking noise will be heard if the base station and Walkie Talkies are too close.

STORAGE

· Put the product into its package when not in use and store neatly in a dry, cool location protected from direct sunlight.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation,

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ☐ Reorient or relocate the receiving antenna.
- ☐ Increase the separation between the equipment and receiver.
- ☐ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ☐ Consult the dealer or an experienced radio/TV technician for help.

FOR AGES 5 AND UP. ADULT SUPERVISION REQUIRED.



Caution: To maintain the compliance with the FCC's RF exposure guideline, place the base unit at least 20cm from nearby persons.

For body worn operation, this unit/handset have been tested and meets the FCC RF exposure guidelines, when used with included components. Use with other accessories may not ensure compliance with FCC RF exposure guidelines.

@2017 Discovery Communications, LLC. Discovery $^{\text{TM}}$ and the Discovery $^{\text{TM}}$ are trademarks of Discovery Communications, LLC, used under license. All rights reserved. discoverykids.com

For customer support, please visit ©2016, 2017 MerchSource, LLC. All rights reserved. www.merchsource.com or call 1-800-374-2744. Distributed by MerchSource, LLC, Irvine, CA 92618.