

Quick Start Guide



my tv • anywhere


www.sling.com

Copyright © 2014 Sling Media, Inc. Sling, Sling Media, Slingbox, and SlingPlayer are trademarks or registered trademarks of Sling Media, Inc. Other products and companies mentioned are the trademarks of their respective owners and not of Sling Media, Inc.

Warranty, safety, regulatory and legal information can be found at www.sling.com/warranty

Part Number: 203471

What's in the box





8

Power Cable



€

Component Video Cable



Stereo

Audio Cable

E

IR Emitter Cable (optional)



Before you get started...

Write down the manufacturer name and model of your cable/satellite box below. You'll be asked to enter this information during setup.

Manufacturer name: (Examples: TiVo®, DirecTV®, Motorola®, etc.)

Model: (Examples: ViP722, DCT-3146, etc.)

If you plan to connect your Slingbox to a wireless network, you may want to write down your network name and password.

Network name (SSID):

Network password:







Set up your Slingbox M1


www.sling.com/M1setup

the Slingbox, once the power cable is properly connected.

One or more lights should start blinking on the front of

Connect the power cable

To complete setup, visit the above link on your computer, iOS device or Android device and follow the instructions.



•••





Need more help?

Need more help?

Go to www.support.sling.com for helpful articles, forums, FAQs and support contact information.

Stay connected with Sling



www.facebook.com/ Facebook

@Slingbox Twitter

SlingboxUS




blog.sling.com



Connect the audio cables and component video cables

Connect your Slingbox M1 to your cable or satellite box using the diagram below.



If you're already using component and audio cables to connect your TV and cable/satellite box:

COMPONENT IN ports. Use the second set of cables to connect the Slingbox M1's AUDIO OUT and COMPONENT OUT ports to your TV's AUDIO IN and



Connect an Ethernet cable (optional)

This step is only needed if you wish to provide your own Ethernet cable for a wired network setup.

If you plan to connect to your Slingbox using WiFi, you can skip this step.





Connect the IR emitter cable (recommended)

Your Slingbox already has a built-in IR emitter, but installing the IR emitter cable will add range and flexibility to the signal.

To install, simply plug the cable into the back of your Slingbox and position the other end so that it sits in front of your cable/satellite box's IR sensor, either placed on top or from the bottom (usually a small, dark red "window").



