

WST-100 Keyfob Remote

Rev. A

Installation Instructions

Product Summary

This Keyfob remote provides users with convenient options for the following system operations:

- _ Arm the system (doors, windows, and motion sensors)
- _ Arm the system with no entry delay
- _ Disarm the system
- _ Activate panic alarms

The keyfob is lithium battery-powered and designed to fit on a keychain, in a pocket or purse.

Programming

For complete programming information, refer to the system installation instructions.

Testing keyfob Remote

Test the Keyfob Remote by pressing the buttons as described below:

- _ Unlock Button -disarms the system. Doors, windows, and motion sensors are disarmed.
- _ Lock Button - arms doors and windows.
- _ Lock and Unlock Buttons - when pressed simultaneously, activates a panic alarm.

- _ Light Button - operates auxillary function.
- _ Star Button - performs EXIT button function.

Specifications

Power source: 3 V, 220 mAh CR2032 lithium battery

Frequency: 433.92 MHz.

Dimensions: L = 2.50" x W = 1.25" x H =.5"

Typical battery life: 5 years

Operating temperature range: 0° to 49° C

Notices

These devices comply with part 15 of the FCC rules. Operation is subject to the following two conditions:

1. These devices may not cause harmful interference.
2. These devices must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by Interactive Technologies, Inc. can void the users' authority to operate the equipment