

W320T说明书25国语言 (英语(EN)、法语(FR)、西班牙语(ES)、德语(DE)、意大利语(IT)、葡萄牙语(PT)、日语(JP)、波兰语(PL)、捷克语(CZ)、斯洛伐克语(SK)、乌克兰语(UKR)、希腊语(GR)、俄语(RU)、土耳其语(TR)、保加利亚语(BG)、荷兰语(NL)、丹麦语(DK)、瑞典语(SV)、韩语(KR)、越南语(VN)、泰语(THAI)、印尼语(ID)、阿拉伯语(SA)、希伯来语(HEB)、繁体中文(CN)

材质: 65g哑光铜版纸
工艺: 单色正反面印刷

尺寸: 55x70mm

页面数:, 对折打钉

封底

封面

For more information, please visit our website:

www.edifier.com

@Edifierglobal

@Edifier_Global

@Edifier_Global

Model: EDF200117
Edifier International Limited
P.O. Box 6264
General Post Office
Hong Kong

www.edifier.com
© 2023 Edifier International Limited. All rights reserved.
Printed in China

NOTICE:

For the need of technical improvement and system upgrade, information contained herein may be subject to change from time to time without prior notice.

Products of EDIFIER will be customized for different applications. Pictures and illustrations shown on this manual may be slightly different from actual product.
If any difference is found, the actual product prevails.

V1.0

EDIFIER

W320TN

True Wireless Noise Cancellation Earbuds Headphones

Manual

BC

EN

Power ON/OFF

1.Power ON when the case is opened.

2.Power OFF when placed in the case and the case is closed.

Note:

If there is no Bluetooth connection for 10 minutes after power on, the earbuds will turn off automatically.

Pairing

1. Earbuds placed in the case and keep the case open.

2. Press and hold the button on the case for about 3s. White and orange LEDs will blink alternately.

3. Select "EDIFIER W320TN" in your device setting to connect. White LED will blink once and then turn off when successfully.

1st Pairing

1. Earbuds placed in the case and keep the case open. White and orange LEDs will blink alternately.

2. Select "EDIFIER W320TN" in your device setting to connect. White LED will blink once and then turn off when successfully.

Note:

For subsequent use, the earbuds will automatically connect to the device used last time.

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator

Button

Indicator