


SimpliciKey KeyCloud Quick Start Guide



Step 1: Install SimpliciKey Remote Control Electronic Deadbolt that is KeyCloud™ compatible.




Step 2: Write down your KeyCloud™(SKEY-KC1) MAC address here:




MAC Address / Adresse MAC

--	--	--	--	--	--	--	--	--	--	--	--

Step 3: Plug power adapter into KeyCloud™ and wall receptacle




Step 4: Connect ethernet cable (provided) from home router to KeyCloud™



Step 5: Plug in SimpliciKey Relay Module (SKEY-SRM1) within 20' of SimpliciKey Deadbolt (installed in step 1).



Step 6: Create your KeyCloud Account at keycloud.simplicikey.com



Instructions continued on the back

Step 7: Register the KeyCloud

Settings

Manage Locations

Add Location

Once your account has been created:

- 1) Select the Settings button in your account,**
- 2) Select the Manage Locations button,**
- 3) Select the Add location, and**
- 4) Follow the instructions as shown.**

Step 8: Register your lock

Settings

Manage Devices

Add Device

Within the KeyCloud application:

- 1) Select the Settings button in your account,**
- 2) Select the Manage Devices button,**
- 3) Select the Add Device button, and**
- 4) Follow the instructions as shown**

Step 9: Lock is now registered and ready to use.



Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by SimpliciKey could void the user's authority to operate the equipment.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

For additional tips and troubleshooting, please visit

www.SimpliciKey.com

1 (800) 785-6595

2-year electronic warranty

Garantía de 2 años para el sistema electrónico

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference (2) this device must accept any interference received, including interference that may cause undesired operations

© SimpliciKey 2013