



**Battery Installation Instructions:**

**VEHICLE**




**TRANSMITTER**



- Open battery door by a PHILLIPS SCREWDRIVER and insert 2 "AAA" batteries (FOR VEHICLE) and "9V" (FOR TRANSMITTER).
- Be sure to align the "+" and "-" with the marking in the plastic battery compartments.
- Replace the battery door and tighten the screw by a PHILLIPS SCREWDRIVER.

**CAUTION:**

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
- Do not use RECHARGEABLE batteries.
- Different types of batteries or new and used batteries are not to be mixed.
- Only batteries of the same or equivalent type as recommended are to be used
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.
- Please retain this information for future reference.



— **“Modifications not authorized by the manufacturer may void users authority to operate this device”**