



IMPORTANT NOTICE:



1. Do not mix old and new batteries.
2. Do not mix alkaline, standard (Carbon zinc) or rechargeable (nickel-cadmium) batteries.
3. Do not use rechargeable batteries.
4. Batteries should be replaced by adults because of small parts.
5. Batteries are to be inserted with correct polarity.
6. Non-rechargeable batteries are not to be recharged.
7. Only batteries of the same or equivalent type as recommended are to be used.
8. Exhausted batteries are to be removed from the toy.
9. Don't operate your car in dangerous places.
10. Don't put your car and transmitter near any source of HEAT.
11. Don't run through water, including pools or puddles.
12. Avoid all possible collisions. Check the road ahead and watch for obstacles.
13. Avoid your car and transmitter antennas touching each other.
14. Don't run your car in the same vicinity as another radio-controlled car.
15. Don't leave your car and transmitter outside overnight. Night dampness will cause harm.
16. Don't forget to remove batteries from your transmitter if you are not going to operate the car again that day.
17. If malfunction occurs, replace batteries.
18. The supply terminals are not to be short circuited.

NOTE:

This equipment has been tested and found to comply with limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Modifications not authorized by the manufacturer may void users authority to operate this device



INSTRUCTION MANUAL

USE UNDER SUPERVISION OF AN ADULT

RADIO CONTROL

• PLEASE READ CAREFULLY BEFORE STARTING TO OPERATE

MICRO SUPER CHARGER™



NO. 1623

Micro Super Charger

- TRANSMITTER ALSO WORKS AS THE CHARGER
- SUPER EXTREME SPEED
- CHARGE 2 MINS. CAN PLAY FOR ABOUT 6 MINS.

Batteries Requirements:

- 1.5v "AAA" batteries x 4 (not included)
- 2.4v Ni-MH Chargeable battery built-in (non-replaceable)

NO. 16239

Micro Super Charger "Ready to Run" (ALL BATTERIES ARE INCLUDED)



P.T. CRUISER

Chrysler is a registered trademark of DaimlerChrysler Corporation
Chrysler® PT CRUISER and its trade dress are used under license from DaimlerChrysler
©DaimlerChrysler Corporation 2001

(Keep the display box and the instruction manual for future reference.)