



World Headquarters / North America

Hypercom Corporation  
2851 W. Kathleen Road, Phoenix, Arizona 85053 USA • Tel: +1.602.504.5000 • Fax: +1.602.504.4655

**HYC Latin America:**

Hypercom Industria e Comercio LTDA  
Centro Empresarial Atibaia  
Rodovia Dom Pedro 1, KM 07, 5 Av.  
Tegula, 888-Ponte Alta  
Atibaia 12940-000, Brazil

Tel: +55.11.4417.7000  
Fax: +55.11.4417.7060

**HYC EMEA:**

Hypercom EMEA  
Unit 2, Woking Eight  
Forsyth Road  
Woking, GU21 5SB,  
United Kingdom

Tel: +44.1483.718600  
Fax: +44.1483.718601

**HYC Asia:**

Hypercom Asia  
21/F Metro Centre II  
21 Lam Hing Street  
Kowloon Bay, Kowloon  
Hong Kong

Tel: +85.2.2561.6800  
Fax: +85.2.2561.5890

**HYC Australia:**

Hypercom Australia  
Unit 1,  
11 Orion Road  
Lane Cove, NSW 2066  
Australia

Tel: +612.9420.6444  
Fax: +612.9420.6466

**Compliance**

- FCC ID: NVA00003, QIPMC56 (GSM)  
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. The user is cautioned that changes or modifications to the product(s) identified in this manual unless expressly approved by Hypercom could the user's authority to operate these product(s).
- IC: 1204B-00003, 267W-MC56 (GSM)
- CE
- A-tick

Bluetooth models use Ezurio BISMII Transceiver.

© 2006 Hypercom Corporation, all rights reserved. Hypercom and the Hypercom logo are registered trademarks of Hypercom Corporation. Optimum is a trademarks of Hypercom Corporation. All other products or services mentioned in this document are trademarks, service marks, registered trademarks or registered service marks of their respective owners. Celebrating 26 years of technology excellence, innovation and leadership, Hypercom Corporation is a leading global provider of electronic payment solutions that add value at the point-of-transaction for consumers, merchants and acquirers, and yield increased profitability for its customers. Widely recognized as the global payment technology innovator, Hypercom delivers comprehensive card payment terminal, network and server solutions that help merchants and financial institutions generate revenues and increase profits.

Headquartered in Phoenix, Arizona, Hypercom's card payment terminal, network and server solutions are leading the transformation of electronic payments in more than 100 countries.



# Terminal Installation Guide

## M4100



# Optimum M4100 Installation Guide

## Equipment Check List →

**WARNING:**

- The battery pack is a Li-ion polymer battery which can explode if not properly replaced, handled or disposed of. Dispose of the battery in accordance with local regulations. Use only batteries recommended by Hypercom as a replacement.
- Recharge only with Hypercom approved chargers designed for this product.
- Do not use if visibly damaged.
- Do not expose to temperatures above 140 °F or 60 °C.
- Do not disassemble.
- Do not short circuit battery pack terminals.
- Do not incinerate or crush.
- Keep out of reach of children and pets.
- Dispose of properly.



Optimum M4100

Photo  
Coming  
Soon

Cable



Stylus



Battery

The Optimum M4100 terminal comes with a Lithium Battery Pack (3.6V 1150mAh). A fully charged battery can complete more than 200 transactions (or 10 hours) before requiring another charge.  
NOTE: Charge the battery for 4-6 hours before initial use of the terminal.

To recharge the terminal, use the M4100 Docking Station (sold separately).

To use the terminal while on the docking station, ensure that the terminal is fully charged.

For additional information, visit our website at [www.hypercom.com](http://www.hypercom.com).

### Inserting the Battery

### Powering the Terminal

### Using the Stylus



Remove the battery from the packaging. Flip the terminal over (as shown).



Remove the battery cover from the terminal.



Insert the battery (as shown).




Reattach the battery cover. Turn the terminal on.



Push button to power terminal



Remove the stylus from the packaging.



Insert the stylus (as shown).



Insert the stylus into the stylus holder (as shown).



To use, remove the stylus from its holder and press gently on the terminal screen. When not in use, return the stylus to its holder.

### Accessories Available

