Mineral Uncludes, Steering Wheel Adjustment Pads) Wheel Mount Adjustment Tool Wristband Remote Mount Car Stereo Cassette Adaptor

- quizion)
  (avec cales d'ajustement)

  Outil de serrage pour montage sur volant

  Bracelet pour télécommande

  Cassette adaptatrice auto radio

Wireless le Remote Kit

NYKO



for/pour



**Wireless Remote Control Kit for** Car, Home or On the Go

Kit Télécommande sans fil pour la Voiture, à la Maison ou sur l'Aller





waterless involve remover in a various ment source.

Thank you for purchasing the Winakess Mobile Remote Kit, compatible for use with all full size iProds. Please review the instructions below to ensure proper installation and use of

## INSTALLATION

STEETANN VITCE IN COURT OF THE ACTION OF THE

- To attach the Steeding Wheel Mount:
- Begin by unscrewing the centrally located hex screw. Please use the included Wheel Mount Adjustment Tool (Diagram 1). 2. Once the screwis incremed you can place the mount at a preferred position on your
- 2. Once on server so consomou pour can passe an emonat et air greeninet position on your sessing whose with the circular Founds Controllular tearly facing the other. We recommend a location that does not conflict with your normal greep of the stearing whose IMPORTAIT: The Seering Wheel Mount should be attached so that the Wireless Remote Unit is positioned on the stearing wheel? INSUE CNAY (Obliganam 2).
- 3. Once you have selected the desired position on the steering wheel, tighten the mount screwusing the included Wheel Mount Adustment Tool
- screwing to induce the mean would repeat a compared to the sering wheel is too MOTE: If the serie has been fully sightsoed but the demoter of your steering wheel is too small to hold the mount property, you will need to use one or more of the included custion pads. Return to Step #1 and add one or two custion pads to the inside of the Steering Wheel Mount as required to securely attach the mount to the steering wheel (Disagram 3) A Press the Remote Control Unit in the devotor control unit securing whose upgrams 3.

  A Press the Remote Control Unit in the devotor control unit will rotate so that the butbons are aligned to disc into place. The Remote Control Unit will rotate so that the butbons are aligned to the mount in position on the attention wheel (Diagram 4.)

  5. To remove the Remote Control Unit, simultaneously press the two butbons on opposite
- NOTE: Store the Wheel Mount Adjustment Tool in a safe location for future use Attaching the Wireless Remote Receiver to your iPod:
- In order to control the iPodusing the Remote Control I but you will react to attach the included Winniess Remota Receiver to the top of your iPod. With the Nyto logo facing in the same direction as the front of the iPod gently press the Receiver unit down into the iPod's headphone and remote jacks (Diagram 5).

MEDITARY When attaching the Wireless R The receiver is designed attach easily to the Pod. No force is necessary.

WIRELESS REMOTE FUNCTION AND FEATURES:

- PLUS (+) BUTTON: Press this button to raise the volume of the iPod headshone lack
- NOTE: Volume buttons do not control the universed the Dock Concertor oversed
- NOTE: Volume trademarks on his contrain the volume of the block Chemised's sucho output, which is present and cannot be edigicated.

  MINUS / BUTTOM: Press this button to lower the volume of your Proof's headqhoine jeck output. Please note it hat volume buttons cannot adjust the volume of the Dock Chemised audio output. The Audio output of your Proof's Dock Chemised his set if a preset level and .
- GRITTOR DE SANGERED.

  TRACK FORWARD (>1): BUTTON: Press this buffon once to advance to the next track. HARLIN FURRANCE (F1) SUIT HOME PRESS this bottom none to advance to the need track.

  Holding this block of the will first forward through the current track.

  LAST TRACK (1's) BUTTOM: Press this buttom once to go to the beginning of the current track. Press the buttom twice quickly to go to the previous track in your play list. Holding this
- REMOTE WRISTRAND ADAPTOR
- The Wireless-Mobile Remote Kit can be used outside of the car as well. The included Wristband Remote Adaptor enables you to control your iPod while jogging, bicycling, or
- anymen econologic.

  Attaching the Winness Remote Unit to the Wristband Adaptor;

  The Wireless Remote Unit attaches to the Wristband Remote Adaptor by two lock tabs located on the surface of the wristband (Diagram 6).
- Align the two openings on the underside of the remote with the tabs on the wristlend.
   Gently twist the remote counter clockwise to lock the remote onto the Wristlead Adapta. To remove the remote from the Whistband Adaptor, gently twist the remote clockwise short distance until the tabs align with popularies so that the remote can be culled free
- NOTE: When attaching or removing the Wireless Remote Unit, no force is necess
  The unit is designed to attach and distach easily from the diagram. USING THE CASSETTE ADAPTOR
- If your car stareo features a compatible cassatte tape player, you can use the included Cassette Adaptor to play your Pod music through your car's stareo system. IMPORTANT: Use only if the car cassatte player supports this type of cassette edeplor.

- while playing are competible with this device. If the cassette player in your car draws the cassette in and has a mechanical gate that must close fully during play, we do not recommend using this adoption. If you have any question regarding the compatibility of the Cassette Adoption with your cars starting, consult the manifecture of the cir sistence system.
- 2. Measure the distance from the cassette obsver to the Prod mount, and fold and the up the excess cable using the attached Velor way
- outside of the cassette player.

  4. Once the Cassette Adaptor is properly inserted into the player, play the cassette to activate your Pod. The Pod playhack should be auditied through the cassette mode of
- your storeo.
  To stop playback, stop your Food and/or press the eject button on the cassette player. Careful use of the device insures a long life for your new accessory. Please be cautious
- while triving and focus on the mod INSTALLING THE UNIVERSAL CAR MOUNT (Diagram 7)
- WARNING: For your safety, we recommend that you only access the Pod controls when your automobile is not in motion. Please keep your eyes on the road. ISING THE AIR VENT MOUNT The vent citys allow for attachment to either vertical or horizontal blades of your dashboard
- Attach the vent mounting plate (A) to the back of the Universal Car Mount.
- Accurate various stip place by in the cactor of the countries such a making sure they
  are oriented to match the direction of the air vent blades. Then side them into the rails to the extreme left and right of the mounting plate
- 3. Gently insert the vent clins onto the blades of the vent. News use expressive force in
- attaching or removing the vent cips.

  4. Make sure that the vent cips are spread evenly to each side for optimal weight distribution IMPORTANT NOTE: You should restrict hot or cool air flow to the vent holding the Universal Cer Mount and iPod by disabling that air vent. Excessive temperatures can cause serious can about anomously usuanuty usuanuty on a consistency and a consistency of control of c
- The Sticker Mount is a permanent solution that convices the enhancement from plate (C) to he attached disortiving surface in your conwith on adhooise material

Top View

It is essential to remove any dirt, poish or conditioners - which can impair adhesion - from the area to receive the adhesive mounting plate. Consult with your car manufacturer as to which noncharts to use for this numeroe.

- which products at deal or inspirajose. Once you have defermined the location on your dashboard or console, double-check the orientation of the achievium muniting plate before removing the protective paper, making sure the Universal Car Mount will side DOWNWARDs into the plate. Once the adhesive mounting has been attached, leave it in place for approximately 12 hours prior to first use pose has been attacked, serve an picce are approximately 2 hours price on an use. IMPORTANT: Removing this achieve mounting plate may cause demage to your dash-board material. For this reason be very sure of the position before installing the adhesive mounting plate. Nyto does not assume any responsibility for damage that may be caused.
- MOUNTING A FULL SIZE IPOD
- Make sure that the Universal Car Mount arms (D) are in the open position by pressing the Make sure that the Universal Car Mountarns (D) are in the open position by pressing it release button (E) located on top.
   Place the iPod into the Universal Car Mountared gently push it back against the spring-
- leaded depth adjuster. Put the arms together to lock onto the Pod.

  To release the Pod, simply press the release button on the top of the Universal Car Mount. MOUNTING THE IPOD MINI
- Make our ather the I became I Car Mount arms are in the COCK assisted Mean state that has unwastastics and unmammater in the CP-chip coston.
   Align the iPod mini is the guides at the inside bottom center of the base. Cently push it back against the apring-loaded depth adjuster, Pull the arms together to lock onto the iPod.
- 3. To release the iPod mini, simply press the release button on the top of the Universal
- Cair Mount and iPod by disabling that air vent. Eccessive temperatures can cause serious damage to your Universal Car Mount and iPod. Refer to your extremblé owner's manual for instructions on controlling air flow to individual air vents.
- USING THE STICKER MOUNT The Sidder Mount is a permanent solution that requires the achesive mounting plate (C) to be affacted directly to a surface in your car with an adhesive material.
- It is assertial to remove any dirt, poish or conditioners—which can impair achesion—from the area to receive the achieve mounting piate. Consult with your car manufacturer as to which products to use for this purpose.
- crientation of the achesive mounting plate before removing the protective paper, making sure the Universal Car Mount will slide DOWNWARDS into the plate. Once the achesive

IMPORTANT: Removing this achievine mounting plate may cause damage to your desh-board material. For this ressum be very zure of the position before installing the achievine remorting plate. Nylor does not assume any responsibility for damage that may be caused by removing the achievine mounting plate after I has been attached.

- MOUNTING A FULL SIZE IPOD
- 2. Place the iPod into the Universal Car Mountand cently push it back against the spring inacted depth activister. Profithe across together to lock corts the Profi To release the iPod, simply press the release button on the top of the Universal Car Mount.
- MOUNTING THE IPOD MINE Make time that the I Industrial Car Mount summers in the COCM position
- . More set a user use conversary or moors arms are in the CPSN position.
  2. Align the Prod minit to the guides at the inside bottom center of the base. Gently push it back against the apring-loaded depth adjuster. Pull the arms together to lock onto the iPod
- 3. To release the Podmini, simply press the release button on the top of the Univer-

## USING THE STICKER MOUNT

- The Stictor Mount is a permanent solution that requires the achesive mounting plain (C) to be attached directly to a surface in your cay with an adjessive material.
- to assert the cocyton a suseout in four or with arbitrary integration in the sesential to ramowe any first, polish or constitioners—which can impair adhesion—from the area for receive the achievem mounting plate. Consult with your car manufacturer as to which products to use for this purpose.
- Once you have determined the location on your deshboard or console, doubte check the crientation of the achiesive mounting plate before removing the or or sense and the processor incoming period before terroring the processor paper, make sure the Universal Cor Mount will side DOWNWARDS into the plate. Once the adhes mounting plate has been attached, leave it in place for approximately 12 hours prior to first use.
- MPORTANT: Removing this adhesive mounting plate may cause damage to your dashboard material. For this reason be very sure of the position before installing the achiester mounting plate. Nyto does not assume any responsibility for damage the caused by removing the achiestive mounting plate after it has been attached.
- OUNTING A FULL SIZE IPOD Make sure that the Universal Car Mount arms (D) are in the open position by pressing the release button (E) located on top.
- Place the iPod into the Universal Car Mount and gently push it back against the spring-loaded depth adjuster. Pull the arms togather to lock onto the iPod.

- 3. To release the iPod simply press the release button on the transitive Holescol Co. Mount MOUNTING THE IDOO MINI
- Make sure that the Universal Car Mountains are in the CPEN position
- 2. Align the Pod mini to the cuides at the inside bottom contar of the base. Goodly runch
- back against the spring-loaded depth adjuster. Put the arms together to lock onto the iPox To release the iPod mini, simply press the release botton on the lop of the Universal

## FCC Advisory

- This expirement has been tested and found to comply with the first for a Class B digital device pursuant to Part 1 of the CCC Pates. Those limits are designed to provide reasonable protection against hermal himference to management produced in a patient formal himference to management to be promoring management to the control of the c
- to radio communications, However, there is no guarantee tradinistriences will not occur in a particular installation. If this equipment does cause farmful interference to make or blocksion reception, which can be determined by faming the equipment off and on, the user is encouraged to by to correct the interference by one or more of the
- altering measures.

  Recident or notice his recisking antierria.

  Institutes his separation between the equipment and the receives.

  Connect his equipment to an outlet on a different discuttion has be which

  Consult his dealer or an experienced add of 19 schmids his help.
- You are cautioned that any changes or modifications not compliance could void the user's subseries to open to the
- TECHIBCAL SUPPORT
  We appreciate your support of NYKO products, and endeavor to guarantee your selfstaction with this product. If you experience difficulties, please contact us.

## Email: customersupport@nyko.com Phone: 1-888-444-NYKO (6956)

NYKO

From: 1-90-44-41 TO (1900)
The DNN O modest is warranted to be original perchase for the normal scheduld case for a period of the service products of the service products. In a defect conversal used for the service products, MNO or service products of the service products or servic




Diagram 2




Diagram 4



Diagram 5





Diagram 6



# Wireless Mobile Remote Kit

for/pour/para iPod®

# INSTRUCTIONS

www.nyko.com





0 3 JUN 2005



for/pour **iPod** 

# Wireless Remote Control Kit for Car, Home, On the Go

- Everything needed to control your iPod wirelessly, including:
  - 5-button Wireless Remote Control Unit
  - Remote receiver with headphone pass-
  - Steering Wheel (or Handlebar) Remote Mount
  - Universal Car Mount for all iPods
  - Stylish Wristband Remote Mount
  - Car Stereo Cassette Adaptor
- Safely control the iPod from steering wheel or bicycle handlebars
- Cassette adaptor plays the iPod through your car stereo
- Wristband remote mount controls iPod while jogging, hiking, or bicycling
- Use with other iPod accessories such as FM transmitters, car chargers and stereo cables

# Kit Télécommande sans fil pour la Voiture, à la Maison ou sur l'Aller

- Tous qu'il vous faut pour contrôler votre iPod sans fil, comprenant :
  - Télécommande à 5 boutons
  - Récepteur avec prise casque
- Montage de télécommande sur volant (ou guidon)
- Fixation auto universelle pour tout iPod
- Bracelet élégant pour télécommande
- Cassette adaptatrice auto radio
- Contrôler iPod en sécurité du volant ou guidon
- Écouter iPod sur auto radio avec cassette adaptatrice
- Bracelet télécommande contrôle iPod en faisant du jogging, marche à pied ou du véloc
- Utilisez avec d'autres accessoires iPod tels que transmetteurs FM, chargeurs voitures, et câbles stéréo





NYKO

NYKO® and Wireless Mobile Remote Kit." are tradements of NYKQ (Behnologies, Inc. IPod is a bademark of Apple Computer, Inc., registered in the U.S. and adherountiers. This is a NYKQ product and is not endorsed, qualifactured or distributed by Apple Computer, Inc.

NYXOB and Witniess Mobile Remote Nt.\* sont das marques déposées par WYXO Technogies, lius. iPod est une marque d'Apple Computer, inc., aveni siné six U.S. et à d'abithes pays. Cec est un produit NYXO. Il est ni Tabrique, ni distribué, il approuve par Apple Computer, inc. @2005 (YYXO Technologies; I.G., Tour Doits Réservés. Register this product online Enregistrer sur Internet: www.nyko.com



Nyko Technologies, Inc. 1990 Westwood Blvd., 3rd Floor Los Angeles, CA 90025 MADE IN CHINA

MADE IN CHINA FABRIQUE EN CHINE ITEM# 88030-E09



THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:

- (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND
- (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.