


**Bluetooth speaker**  
**User manual**  
**5B253BT**



Bluetooth speaker allows you to enjoy the charm of music anywhere

This is modern fashion the appearance of a unique Bluetooth phone hand –free digital audio

New miniature aluminum diaphragm speaker clear treble bass pure unique design so sound quality performance plus excellent

Integration of new concepts Walkman digital audio connect you

MP3/MP4/CD/DVD/IPOD/IPHONE/PSP mobile phone computer and FM radio function

Circular design button curved design a variety of colors highlights the modern style so that you own way

Battery computer USB adapter DC5V power supply so that you can enjoy anytime any where music eliminate worry

**Speaker function parameters**

Frequency response 80-18000HZ

FM frequency range 87.5---108MHZ (±3DB)

SNR ≥65DB

Bluetooth connection distance ≥10M with the hands –free function

Power input USB power adapter wiring or 5V-1000MA of the AC power adapter

**Instructions for USE**

Operating instructions

Battery built –in battery

DC -5V DC -5V (0.4-1A )power adapter USB power available

△!REMINDER when the battery charging is completed please unplug the line charge

Tuned charge you can use an adapter to charge normal play music the power indicator is displayed as red use the original USB cable to connect the computer to charge automatically converted to storage capabilities (Recommended charging tuned o in order to prolong battery life ).In external audio connection the audio signal and the audio input port of the host audio cable connection (line in )the blue indicator light in the playback

### **Bluetooth Connection**

Extremely audio connection mode the audio input port of the host with the audio cable connection (line in) then to enter extremely audio mode. Bluetooth connection the power switch in the "ON "state the boot by default in the Bluetooth status mobile phone scorch new Bluetooth equipment "NAXA NAS-3082"; after mating connector when speaker with voice prompts pairing is successful enter Bluetooth playback mode connect the PC to play music with Bluetooth match; make sure the Bluetooth matching drive installation intact open the taskbar Bluetooth device pairing after opening the Bluetooth interface to search for Bluetooth device found king won new equipment then double -click paring device to connect when the speaker and the voice prompts pairing is successful right set the device to play music in Bluetooth and engage in quality audio playback when the player is connected to the phone/telephone intervention and music stops directly using a mobile phone to answer; can also be used hands-free directly by using the speaker key try to face the speaker speak MIC to hang up press end call key after ending the call music will automatically resume 25M distance from the Bluetooth connection is not lower than in the case without any obstacle

Music mode on a /VOL -: short -automatically jump back on ling press -the volume decreases

Next a /VOL +: short -automatically select the next song press and hold the-volume increases

Radio mode

Short press for pause /playback /Fm automatic station search the colored indicator light ashes long press for turn on /o the led light

Connected by 3.5 line, short press "M" to select FM mode, short press" " for automatic searching FM station. After -noshing searching, it will play automatically.

On a /VOL -short -automatically jump back to the previous station long press -the volume decreases

The next track /VOL +short press -automatically select the next station press and hold the -volume increases

OFF /ON switch to the OFF sound to stop playing-card music automatically cut o the power at this time is set to ON the audio through the amplifier output

" " Key speaker phone /playback /FM automatic station search /turn on /other led light

"M " Key mode select long press for back to dial the telephone

Note : when using the USB data cable to a icon facing down wary and laterally inserted

Thank you

Playing MP3 Files through the Speaker using the USB/Micro SD Card  
In USB/Micro SD mode, you can press the button M to change to other mode.

#### **FCC Statement**

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. User should avoid un-intended operation of usage when it is collocated with other transmitters or antenna.