

evenflo[®] Ultra-Sensitive Monitor[™] with Sound Lights



Owner's Handbook

Model 615 9/98
#25705522

Thank you for purchasing the Evenflo Ultra-Sensitive Monitor.

Understanding how your monitor works helps you obtain the highest performance levels. Before setting up and using your Evenflo Ultra-Sensitive Monitor, please read this Owner's Handbook completely. It provides helpful tips to ensure the best operating circumstances for monitoring your child.

IMPORTANT: The Evenflo Ultra-Sensitive Monitor should not be used as a replacement for adult supervision of children. Please note that any modification of the transmitter or receiver will violate FCC compliance and can void the user's authority to operate this monitor set.



FCC ID: EHK615R



Important Safety Instructions



This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.



This symbol is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electrical shock to persons.

⚠ WARNING! ⚡

- DO NOT OPEN. NO USER SERVICEABLE PARTS INSIDE. RISK OF ELECTRIC SHOCK. MAY CAUSE SERIOUS INJURY, FIRE, OR DEATH.
- DO NOT USE NEAR WATER OR OUTDOORS.
- DO NOT PLACE FURNITURE ON CORD.

⚠ WARNING!

- This product does not replace responsible adult supervision of a child.
- You should check on your child regularly as this product will not detect your child's quiet activities.
- This product is not intended to be used as a medical monitor, and its use should not replace adult supervision. A responsible adult must stay within range of the Eventlo Ultra-Sensitive Monitor at all times during use.
- Always be sure that both the Baby's and Parent's units are properly functioning, on the same channel and within reception range of each other.
- It is essential to check the sound reception regularly.

1. Read and follow all instructions carefully before using your Eventlo Ultra-Sensitive Monitor.



2. Read and observe all warnings on the product and in this Owner's Manual. Pay special attention to information marked "WARNING" and "IMPORTANT". This information can affect your child's safety. Keep this owner's manual nearby for quick and easy reference.

⚠ WARNING!



3. • Never place the baby's unit or its adapter cord in the crib or playpen, or within reach of the child. DO NOT hang this monitor near or on crib. The cord can present a strangulation hazard.
- Always keep the adapters, transmitter and receiver out of the reach of children.

⚠ WARNING!



4. AVOID PLACEMENT NEAR WATER AND MOISTURE. Do not use baby's unit outdoors. Do not use your monitor near a bathtub, shower, sink, laundry tub, swimming pool, wet basement or other locations where water or moisture are present.



5. Allow for proper ventilation of the adapters and the monitors. Do not place your monitor on or under a rug, bed, sofa, blanket or similar object that blocks its ventilation. Do not place it in a built-in installation such as a bookcase or stereo cabinet. These may impede the flow of air through the ventilation openings.



6. Remove the battery or unplug the AC adapter from the Parent's unit and unplug Baby's Unit if it will not be used for a long period of time.



7. Avoid placement near heat sources. Do not use your monitor near a radiator, stove, heat register, or other appliance (including amplifiers and TVs) that produce heat. Heat can damage the case or components.



8. Operate this monitor using only a 9-volt battery (not included) or the Eventlo AC adapters provided and plugging the adapters into standard wall outlet. Do not use extension cords.



9. Protect the AC adapter cords. Route cords so that they are not walked on or pinched by items placed upon them, and pay particular attention to cords at the AC adapter plugs, wall plugs, and where they plug into the transmitter or receiver.


⚠ WARNING!



10. DO NOT IMMERSE ANY COMPONENT IN WATER. Clean these monitors with a dry cloth.



11. Do not use near fluorescent lights, appliances with motors, televisions, fans or other machinery. These items may interfere with the quality of your units' transmission or reception.



12. Adapter must be removed from receiver for battery operation. In case of a power outage, batteries will not act as a backup if the adapter is engaged.

13. Do not use your monitor if:

- Either AC adapter or their cords have been damaged.
- Objects have fallen or liquid has been spilled into any of its components.
- It has been exposed to rain or water.
- It has been dropped or something inside is damaged.

14. Refer to the Troubleshooting Chart in this handbook before returning your monitor for servicing. You may be able to solve the problem on your own in very little time.

15. If service is required due to a possible defect, and the monitor is still under warranty, see Limited Warranty for instructions. This product should be serviced only by qualified service personnel at Eventlo Company, Inc. when:

- An AC adapter or its plug has been damaged.
- Objects have fallen or liquid has been spilled into the Transmitter or Receiver.
- The Transmitter or Receiver do not appear to operate normally or exhibit a marked change in performance.
- There are no user serviceable parts inside these monitors. Do not open the cases.

Helpful Operating Tips

- FOR BEST RESULTS, use your AC adapter with the Parent's unit. The power is more consistent than that of the battery, and using the adapter provides clearer reception.
- In some homes, battery operation will dramatically reduce the effective range of the system.
- Your monitor's typical transmission/reception range is about 300 feet depending on battery power and possible obstructions (i.e. walls) that radio waves encounter. The methods and materials used in your home's construction, terrain and other factors may also affect transmission.
- For best results, use your adapter when you are in the same place (such as your bedroom at night or the kitchen during the day) over a long period of time. The adapter provides maximum power.
- WARNING: Your adapters are equipped with polarized alternating current line plugs (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. **If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Most building codes currently require polarized electrical outlets. Do not defeat the safety purpose of the polarized plug.**
- WARNING: The AC adapters provided with this monitor should NOT be used with other equipment under any circumstances. Do not use any other product's adapter with this monitor. Different adapters use different amounts of current.
- IMPORTANT: This nursery monitor operates over public airwaves. Transmissions from your Baby's unit may be picked up by another product operating on the same frequency. Your Parent's unit may also pick up transmissions from another product on the same frequency. If interference occurs, change BOTH your Baby's and Parent's Units to the alternate frequency channel.
- ALWAYS make sure that both units are on the same frequency channel. It is possible for the Parent's Unit to pick up the Baby's Unit even if they are on different channels when both units are close together. However, you'll experience static and interference.



UL Listed Adapter.
FCC Approved.

Using Your Evenflo Ultra-Sensitive Monitor

Before you set up your monitor, read "Important Safety Instructions" carefully and completely.

Setting Up Your Evenflo Ultra-Sensitive Monitor

Components: a Baby's Unit (transmitter), Parent's Unit (receiver), and two AC adapters.

1. Place the Baby's Unit within 10 feet of your baby.
2. Position the front of the Baby's Unit toward your baby. Be sure there aren't any large objects blocking the path between the microphone and your baby.



3. Your monitor can broadcast over one of two factory preset frequency channel (A or B). The frequency setting is located on the right side of each unit. **Be sure both Baby's and Parent's Units are on the same channel.**
4. If interference is present, change the channel setting on BOTH units.

Using Your System Successfully

The Baby's Unit:

1. Attach the AC adapter to the Baby's Unit, fully extend the cord, and plug the adapter into a standard wall outlet. Use only the adapters included.
2. Turn the unit on using the ON/OFF switch, located on the right side. The red LED power light should glow.
3. Check to see if the channel is set to A or B.

The Parent's Unit:

1. Move into another room away from Baby's Unit. Attach the AC adapter to the Parent's Unit, fully extend the cord, and plug the adapter into a standard wall outlet. Use only the adapters included or insert a 9-volt battery (not included).

FCC ID: EHK615R

2. Be sure both the Baby's and Parent's Units are set on the same frequency channel.
3. Using the ON/OFF volume switch located on the right side of the unit, turn it on. The red LED power light should glow.
4. The ON/OFF switch also controls the volume. Adjust the volume to your liking.
5. You're now ready to monitor all sounds from the nursery.
6. Have an adult speak into the Baby's Unit to verify sound transmission.
7. Use headphone jack on Parent's Unit with any standard headphone. Use caution when adjusting the volume.

USEFUL TIPS: You may use either a standard wall outlet or one (1) 9-volt battery (not included) for the Parent's Unit. If you have inserted the battery into the unit, it will automatically disconnect when you're using the adapter. You do not need to remove it.

It is best to use your low-voltage AC plug-in adapter (that comes with the unit) when you are in the same place over a long period of time.

For example;

- From your bedroom at night.
- From a kitchen countertop during the day.

FCC ID: EHK615R

TROUBLESHOOTING GUIDE		
PROBLEM	POSSIBLE CAUSE	SOLUTION
ON/OFF light signal isn't working.	<ul style="list-style-type: none"> Units aren't getting power. 	<ul style="list-style-type: none"> Make sure each unit is properly plugged into the wall and the outlet is switched on. When using batteries with the Parent's Unit, be sure the adapter is not attached. If it is not and the light still does not work, replace the batteries and turn unit on again.
Reception is poor due to static buzzing or interference.	<ul style="list-style-type: none"> Baby's Unit and Parent's Unit are on different channels. Other household appliances, cordless phones, fluorescent lights or motors may be disrupting the signal. Parent's Unit is out of effective range. 	<ul style="list-style-type: none"> Make sure that both Units are on the same channel. Turn off, unplug or move the device that is causing the problem. Move the Parent's Unit closer to the Baby's Unit.
Parent's Unit continues to buzz when turned on.	<ul style="list-style-type: none"> Baby's Unit may not be plugged into a working outlet or may not be turned on. 	<ul style="list-style-type: none"> Check the AC outlet to be sure it is working. Check the Baby's Unit to be sure it is on and tuned into the same frequency channel as the Parent's Unit.
Parent's Unit is making a loud feedback noise.	<ul style="list-style-type: none"> Baby's Unit is picking up sounds from Parent's Unit because they are too close to each other. Volume may be set too high. 	<ul style="list-style-type: none"> Move the Parent's Unit at least 10 feet away from the Baby's Unit. Lower the volume.
Parent's Unit is picking up sounds or static from outside your home or apartment.	<ul style="list-style-type: none"> A neighbor has a similar baby monitor, cordless phone or walkie talkie that is transmitting sounds on the same FM channel. 	<ul style="list-style-type: none"> Change the frequency channel that is in use. Be sure to change it on BOTH units.
Weak reception of sound.	<ul style="list-style-type: none"> Parent's Unit may be outside of the transmission range of the Baby's Unit. Antenna is covered or unit is lying down. Batteries may be weak. 	<ul style="list-style-type: none"> Check both Units in an AC outlet or test with new batteries. Move Parent's Unit closer to Baby's Unit. Make sure both units and antennas are standing upright.

Limited Warranty

Evenflo Company, Inc. warrants this product to be free from defects in material and workmanship under normal use for a period of ONE (1) year from the date of purchase by the original consumer/buyer.

Evenflo Company, Inc. will, at its option, either repair or replace this product if Evenflo Company, Inc. deems it to be defective within such one (1) year period. A product claimed to be defective should be returned, postage prepaid, to the Evenflo Company, Inc. Consumer Relations listed below.

This warranty does not apply to any product damaged due to abuse, alterations, damage in transit, failure to use according to instructions, improper maintenance, connection to an improper voltage supply, misuse or accident.

REPAIR OR REPLACEMENT OF THE PRODUCT, AS PROVIDED UNDER THIS WARRANTY, IS EVENFLO COMPANY, INC.'S SOLE LIABILITY IN CONNECTION WITH THIS WARRANTY OF THE PRODUCT. EXCEPT AS EXPRESSLY STATED HEREIN, EVENFLO COMPANY, INC. MAKES NO WARRANTY, EXPRESS OR IMPLIED, WITH RESPECT TO THE PRODUCT, UNLESS REQUIRED BY LAW TO DO SO. IN NO EVENT SHALL EVENFLO COMPANY, INC. BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES WITH RESPECT TO ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY OF THE PRODUCT.

Some states do not allow the exclusion or limitation of incidental or consequential damages, or allow limitations on how long an implied warranty lasts, so the above limitations or exclusion may not apply to you.

Warranty replacement may be available from your retailer. Check with them first, especially if this is a recent purchase.

To obtain factory warranty service, the consumer shall carefully pack and pad the complete product and send it postage prepaid, to the Evenflo Company, Inc. Consumer Relations (address listed below). **Proof of purchase in the form of a bill of sale, receipted invoice or other positive proof that the unit is within its warranty period must be enclosed.**

This warranty gives you specific legal rights. You may also have other rights, which may vary from state to state. For further information, contact :

Evenflo Company, Inc. Consumer Relations, 1801 Commerce Drive, Piqua, OH 45356 U.S.A.
1-800-233-5921

evenflo

Evenflo Company, Inc.
www.evenflo.com
1801 Commerce Drive
Piqua, OH 45356 U.S.A.

Made in China

© 1998 Evenflo Company, Inc.
Trademarks owned by Evenflo Company, Inc., Lisco Furniture, Inc. or Lisco Feeding, Inc.
Patents owned by Evenflo Company, Inc.

For new batteries or other replacement parts call:
Evenflo Company, Inc. Consumer Relations, 1-800-233-5921
or write: 1801 Commerce Drive, Piqua, OH 45356 U.S.A.

4IS981871A00