

Smart Watch

User Guide

Please read this manual before using

V1.0

Attention before using :

1. Watchband tightness standards: cross the watchband, can be added into an index finger as the standard ;
2. Pairing connection for the first time, using Bluetooth pairing method.
3. Use watchband for the first time, will be tight, hard to buckle into, please follow as below methods:
Put right index finger inside of the watchband ,from the top push button in.




1. Safe instructions and main precautions

1.1 The company reserves the right to revised the manual without any prior notice.

1.2 Please charge more than 2 hours before first using.

2. Product Introduction

2.1 Introduction



Power button: Turn on/off, Wake up, Shut down, Back ;

USB : Charging and data function ;

Touch screen: capacitive touch screen, the function can be operationed in capacitive touch screen.

Heart rate monitor windows: check heart rate

2.2 Enter Quickly

After turn on, finger drag left enter the next menu, drag right to return back the menu; Finger drag from the top to down, enter into the notification bar, from the bottom to top, back to the main menu. Drag distance need drag over half of the screen, if drag too short, will be mistaken for a click. The function icon can be place the position freely according to your ideas, click ok to sure.

2.3 Using the Clock screen

While using the Watch, press the Power button to open the Clock screen.

Then click the central of screen to change clock type.



Setup ways :

method 1: turn on , on the Clock screen , click the central of screen to change clock type. , there are 6 types can be selected.

method 2: turn on , enter the menu, settings--Clock—Clock type menu --Unlock type selection.

2.4 Theme Settings

Setting Method :

Go into the smart watch menu: themes-theme Settings-select your theme

3. Operation Quickly

3.1 Download the synchronous software

Methods 1、 turn on the menu of watches - enter into QR Codes directory, using mobile phone QR code scanning software scan the QR code on the watch.。

Methods 2、 Using mobile phone scans below QR code to download



(Synchronous Bluetooth software)

Method 3, using mobile browser, enter the following URL to download

<http://www.fundo.cc/other/download/FunDoWear/>

After download, according the prompts to install the application.

This Program only support synchronization between watch and smart phone, will not charge mobile phone network traffic.

If you have downloaded relevant software from other website, please check the software version, please use the latest version of the synchronization software, to ensure the normal use of function. If software version has upgraded, please update synchronization software.


3.2 Installation and use synchronization software

Android application software installation : :

On smart phone, according to the normal android software installation, when installation complete, can be stored into the phone memory or synchronization assistant software installation can be used.

Android applications use method: (installed software already)

(Smartphone) Enter the Settings --auxiliary Settings--Bluetooth notice (services) click enter, enable the service.(when start using, there will be a warning, please select "ok") software can be automatically run in the background, synchronizing function can be used .as following :



Click on the bluetooth notice, choose "notification service", in the "notice", choose to push personal application or system application you need; Telephone service function, including text messages and telephone; Looking for watch.

Note: when you use the back-end to clean up or close the back-end application software, please do not close this bluetooth notification service, if closed, sync will influence the watch with a mobile phone.

3.3 Bluetooth connectivity and synchronization function

3.3.1 from the mobile phone to connect Watch

Enter Mobile phone settings - turn on bluetooth - search equipment, when find **ES001**, click choose matching, and select "yes" on the watch,

matching success, when there is a phone book request, please click "ok", it is better choose "next time no longer prompt" at the same time, convenient for next time connection, the phone book will sync directly, not prompt again.

Note: If has installed a synchronization software, pls also turn on this synchronization software on mobile phone in auxiliary function, after connection, within 2-5 seconds, the mobile phone terminal will show the bluetooth connected; on smart watch at the same time, will prompts you automatic synchronization cellphone time, it indicates that the synchronization function is enabled. When mobile phone have a new message coming , will synchronization to smart watches in timely.

3.3.2 From the smart watch to connect mobile phone

On the smart watch, select the Bluetooth dialer - click to search bluetooth device - find your Smartphone (such as Samsung 9500) - click connection; the continue process operation as 3.3.1

Note: At the same time, the mobile phone need turn on the bluetooth and

allow to be searched by around bluetooth products.

3.4 Function menu description

3.4.1 Message

mobile phones synchronous message or smart watch message.

3.4.2 Bluetooth

Set up the state of the Bluetooth, turn on or off.

3.4.3 Call Records

After connecting the bluetooth, you can view your call status of the near term.

3.4.4 Bluetooth Dialer

From the watches to connect the mobile phone for matching ;

3.4.5 Remote Notification

Synchronous Show the message from mobile phone terminal ,
such as: QQ, WeChat, messages, time, Twitter, Facebook etc. ;

3.4.6 Remote Take Photos

Controlling from the watch,using mobile phone camera take

pictures;Need turn on the android mobile phone's camera advance.

3.4.7 Anti-lost

Watch looking for mobile phone or mobile phone looking for watch. Two-way anti lost ;


3.4.8 Setup

Note: In the phone setting, you can set the clock type and theme;In the security Settings, the default security code: 1122

3.4.9 Pedometer

In pedometer Settings, drag to left, you can see steps and burn calories, speed, mileage etc. movement information ;

In the process of movement, if want to go back to the main menu, and don't want to stop step function, please press the power button.pedometer function will continue to run in the background. Motion synchronization data, please see the behind dynamic capabilities.



3.4.10 Sleep Monitoring

According to your sleep time to show the quality of your sleep.

3.4.11 Sedentary Remind

Can set up the time, remind you need to take exercise; It is recommended that one time at least per hour ;

3.4.12 QR code

Scan the QR code, can download the synchronization software, if have the new version software to upgrade, please contact with our company, we will provided the new download address; Please do not use WeChat or QQ ,or others browser scanning and download.

3.4.13 Intelligent search

Searching for the relevant information on the watch

3.4.14 Clock

3.4.15 Calendar

3.4.16 Calculator

3.4.17 Profiles

3.4.18 Music Player

Can play music on mobile phone music connected Bluetooth ;

3.4.19 Theme, as shown in the theme Settings

4. Precautions for use

4.1 Please charge fully before use, charging time need 1-2 hours.

4.2 Charge line can use android Smartphone charge line and

authentic charger; Or use the standard configuration accessories;

4.3 Bluetooth disconnect if exceeds the distance, after using two-way

anti-lost,if do not reconnect again,it cannot use the search

function;

4.4 Using bluetooth,it will be disconnect occasionally, please

reconnect(if over 5 minutes not connected, need

connect manually);When connection, please pay attention to choose agree with the phone book synchronous; Otherwise, it will not be able to show the calls from phone book;

4.5 Music function, because of there are different android mobile phone, some will show the name of the song ,some mobile phone is can not show the name of the song, this is normal. ;

5. movement data synchronization function

5.1 Sport data storage and sharing

5.1.1 Registered ID and login dynamic server, to accurate accounting sport data and give you the correct guidance,pls set your parameters, including height, weight, age.

5.1.2 Connect Smart Watch and mobile phone bluetooth, and connect the bluetooth synchronization software;Same as above

5.1.3 After do exercise, click the "reset" data on the watch, can store multiple data

5.1.4 In the mobile phone, use dynamic software synchronous

data,synchronization data to back-end to share and store.Back-end will record your movement process and data.

5.1.5 Please reference the function and use introduction on the website about the other function and new features for the dynamic movement software.

5.1.6 Dynamic service website : www.fundo.cc

6. Common Troubleshooting Guides

If have any problems when using the smart watch, please refer to the

Following terms and conditions. If the problem still exists, please contact

the dealer or the designated maintenance personnel.

6.1 Can not turn on

Press the power button too short, please press over 3 seconds.

Battery Power too low, please charge.

6.2 Shut down automatic

Battery Power too low, please charge.

6.3 Using time is very short

Not fully battery power, please make sure Charging
enough time(minimum 2 hours).

Use the SIM card, but the signal is very poor, lead to cell phone
use big current.

6.4 can't normal charge

Check whether the battery is available, the performance of the
battery will reduce after a few years.

Check the charger is working correctly, change the new charger
to try

Check the connect USB charging line interface , try again.

6.5 Dynamic data can't sync, because of not log in the

back-end,movement data can't save in the back-end,please
register and log in.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Warranty Card			
Customer Information			
Model		Selling company	(signature)
Customer Name		Phone NO.	
Sales Tel		Purchase Date	
Product code			
Customer Address			
Sale Address			
Summary			
Date	Symptoms	Servicing	Remark