








 <p><b>CANDY BOX</b> Universal Bluetooth® Speaker QAA14AV002 QAA14AV004 User Manual</p>	<p>Thank you for purchasing CANDY BOX Universal Bluetooth® Speaker for smart phones, tablets, notebook computers and other Bluetooth enabled devices. This product combines high-tech innovation with design to provide you with years of dependability and enjoyment.</p> <p><b>Safety Precautions and Maintenance</b> Please read these operating and maintenance (servicing) instructions before installing and operating your speaker.</p> <p><b>Warning:</b> To reduce the risk of fire or electric shock, do not expose this speaker system to rain or moisture (including swimming pools or objects filled with liquids, such as vases or drinks).</p>	<p><b>Important Safety Instructions</b></p> <ol style="list-style-type: none"> <li>Always read Safety and Operation instructions before use. Retain instructions for later reference.</li> <li>For indoor use only. Do not expose the speaker to liquid, moisture or humidity.</li> <li>Do not use abrasive cleaners to clean the speaker case as they may damage the finish. Always unplug the unit before cleaning.</li> <li>Do not expose the speaker to extremely high or low temperatures.</li> <li>Keep the unit away from direct sunlight.</li> <li>Use only accessories and attachments as supplied and designated in the instruction manual.</li> <li>Do not attempt to open or modify the speaker in any way, as it does not contain any serviceable parts. Please refer all servicing to qualified personnel.</li> <li>Please store the unit in a dry place that is free from extreme temperatures and dust.</li> <li>Always operate the speaker on a flat and level surface.</li> <li>Always operate the speaker away from children and small animals as they may play with the power cord and other small parts.</li> <li>Always dispose of the packaging and the unit in accordance with the local regulations and in a responsible manner.</li> </ol>	<p><b>The FCC Wants You To Know</b></p> <p>Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.</p>	<p>However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <p>Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.</p> <p>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p>	<p><b>Speaker Overview</b></p>  <ol style="list-style-type: none"> <li>Power Switch/Battery status indicator</li> <li>Volume down</li> <li>Play/Pause button</li> <li>Volume Up</li> <li>TWS pairing indicator</li> <li>Bluetooth indicator</li> <li>Speaker Mode Switch</li> <li>Charging Port</li> <li>Line-in Audio Jack</li> </ol>	<p><b>Package Contents</b></p> <p>Main unit x 1 USB Charging Cord x 1 User manual x 1</p> 
--	---	--	---	--	---	---

 <p>Fenda Hi-tech Park, Zhoushi Road, Shiyuan, Baoan, Shenzhen, China Email: jane.chen@fenda.com www.ravon-audio.com</p>	<p><b>Bluetooth connect</b></p>  <p>Move the speaker mode switch to Mono. Press and hold to switch on, press and hold to switch off.</p> <p>On the Bluetooth device, switch on Bluetooth and search for Candy Box. For the first time connection, select Candy Box to start connection. After your connection is successful, you will hear "paired".</p>	<p><b>Play</b></p>  <p>Now you can begin to play music on your speaker. Press "◀" "▶" to adjust volume, and press "⏸" to Pause or Play.</p>	<p><b>Charge</b></p>  <p>Can be charged by using the USB to Micro USB cord (included) through computer or AC adapter with USB jack (not included). Approximately 3 hours required for full charge. Note: Battery will last up to 5 hours when connected wirelessly.</p> <p>Solid red light means the battery is charging. Red light off means the charge is complete. Note: When your battery is low, the red light will blink slowly.</p>	<p><b>Aux in</b></p>  <p>Use a 3.5mm cable (not included) to connect the speaker to another audio source. Press Play on the device and adjust the volume on the unit to obtain the desired volume. Note: Play/Pause controls on the unit will not work when using the "Line-In" audio jack.</p>	<p><b>Extra:-- Pairing 2 Candy Box Speakers together(Stereo):</b></p>  <ol style="list-style-type: none"> <li>Turn the speaker over and move the speaker mode switch to L.</li> <li>Turn the 2nd speaker over and move the speaker mode switch to R.</li> <li>Press and hold the power button for 5 seconds on the 1st speaker.</li> <li>Press and hold the power button for 5 seconds on the 2nd speaker.</li> <li>Speakers will begin to pair together automatically.</li> <li>Pairing process can take up to 30 seconds. When you hear a "Steel Drum" tone and the Candy Box 2 indicator light begins to slowly blink, you are ready to pair to your device.</li> <li>Follow the instructions of your device to pair the speakers.</li> <li>Pair your device with speakers by selecting "Candy Box 2" from the Bluetooth listings on your device.</li> </ol>	<p><b>Features</b></p> <ul style="list-style-type: none"> <li>Wirelessly stream music and movies anywhere up to 30 feet.</li> <li>3.5mm line in jack for playing MP3 and other audio devices.</li> <li>Passive radiator for rich bass.</li> <li>Built in rechargeable lithium battery with up to 6 hours of battery life.</li> <li>Micro USB charging input.</li> <li>Allows pairing two products together and creating a stereo speaker pair (1 product per channel).</li> </ul> <p><b>Technical Specifications</b></p> <ul style="list-style-type: none"> <li>Transducers: 1 x 2-1/4" (57mm)</li> <li>Amplifier power: 3W</li> <li>Frequency response: 150Hz – 20kHz</li> <li>Signal-to-noise ratio: &gt; 80dB</li> <li>Battery type: Li-ion rechargeable</li> <li>Bluetooth transmitter frequency range: 2.402 – 2.480GHz</li> <li>Bluetooth transmitter power: 0 – 4dBm</li> <li>Listening time on battery power: Up to 5 hours (Varies by volume level and audio content)</li> <li>Battery charge time: 2 hours</li> <li>Dimensions (W x D x H): 83mm x 83mm x 95mm</li> </ul>
---	---	--	--	--	--	---

	时 间	20140113	订 单 号	GM13716	
品 牌	Q-experience	公司型号	W15BT-Grey/Blue	客户型号	QAA14AV002/004
版 本	A0	设计内容	说明书(所有颜色共用)		
电 子 软 件		结 构 电 声		PLM文档编号	
设计者	张劲松	标 准 化		项 目 经 理 产 品 经 理	
复 核		业 务		核 准	

展 开 尺 寸	560X80mm
成 型 尺 寸	80X80mm
材 质 要 求	120G书纸
印 刷 要 求	单色印刷
工 艺 要 求	风琴折
页 码 数 ( 页 )	7页 ( 按成型尺寸计算页数 )