



105MM

<p>ENGLISH</p> <p>3GO</p> <p>SUPER BASS BLUETOOTH SPEAKER</p>   <p>INSTRUCTIONS</p> <ol style="list-style-type: none">1. Press ⏪ momentarily, it turns to next song2. Press ⏪ and hold it to volume up3. Press ⏩ momentarily, it turns to previous song4. Press ⏩ and hold it to volume down5. Press ⏸ momentarily to pause or play6. Press ⏻ to switch Bluetooth / TF / Line in / FM / BT Telephone <p>BASIC FEATURES</p> <ul style="list-style-type: none">• Bluetooth play• Playing songs in MP3 format which saved in TF card• Support PC / iPod / iPhone / iPad / MP3 / MP4 and another smartphones and tablet by connecting with 3.5 mm jack• Bluetooth telephone function• FM radio: under FM radio mode, press and hold button Ⓜ autosearch the radio station and auto save them <p>TROUBLE SHOOTING</p> <ul style="list-style-type: none">• Failed to read TF card: formatting TF card or change the format of song to MP3• No audio input when connecting with other devices: Press "M"(Mode) button to switch it or shut down to reboot it• Cannot turn on the speaker: check if the speaker does not have power, if no power, charge it first• Cannot connect with Bluetooth devices: check if speaker connected with the third Bluetooth device, if yes, disconnect it first, if still can not connect, reboot it and try again	<p>DATA TRANSFERRING/CHARGING VIA USB CABLE</p> <ul style="list-style-type: none">• Switch ON, and connect it with the PC via USB cable. It will play songs during charging• Switch OFF, and connect it with PC for charging only• USB cable is not for the use of data transferring <p>SPECIFICATIONS</p> <ul style="list-style-type: none">• Built-in Li-Ion Battery, 3.7V/500 mAh• USB charging Voltage: 5V DC• Speaker: 40 mm 4 ohm 3W• Audio frequency range: 60 Hz-18KHz• S/N: ≥96DB• Distortion ≤ 0.5%• Size: 60*60*53 mm <p>INTERFACES</p> <ul style="list-style-type: none">• Volume control knob: Turn the knob in a clockwise direction to volume up, Turn it in an anticlockwise direction to volume down• USB Port: charge• Microphone: Hands-free speaker available only for the Bluetooth mode• TF card slot• LED indicator:<ul style="list-style-type: none">◦ Blue flash: wait for Bluetooth connection◦ Blue slow flash: Bluetooth connected or playing music◦ Red: charging status (red indicator off when Fully charged) <p>FEATURE</p> <ul style="list-style-type: none">• Vibration resonance technology• 360 degree omni-directional sound <p>CAUTIONS</p> <ul style="list-style-type: none">• Keep out of reach of children• Never knock the speaker• Keep it away from fire, water, high and low temperature• Never block speakers nets• Never open it by yourself• Do not charge it for too long time in case of damage to the battery, 3 hours is the best charging time	<p>FCC Warning Statement</p> <p>Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.</p> <p>This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.</p> <p>If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: --Reorient or relocate the receiving antenna. --Increase the separation between the equipment and receiver. --Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. --Consult the dealer or an experienced radio/TV technician for help.</p>
--	--	--