

User Manual

Since this device is always used with vehicle, it is not sold to general end users separately.
Therefore there is no user manual of this device by alone.

Registration Information

FCC

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines. This equipment should be installed and operated keeping the radiator at least 20cm or more away from person's body.


Operational Buttons



Audio Select



Touch Audio button.



Touch SOURCE button.



Touch the button you want to play.

For example,

Bluetooth A2DP play

USB play

Ex.: USB Audio play screen



Bluetooth (Wi-Fi) Settings



Touch Setting button.




Touch Bluetooth/Wi-Fi button.



Touch Bluetooth Device List button.

When you want to connect Wi-Fi, touch Wi-Fi Network List button.

Park your car, you want the following operations.



When Status is Off, touch and set to On.





Touch Add Bluetooth Device button.



Touch Continue button.



Touch your device.



You can find pairing is success.