

Fisher-Price®

Instructions

2-in-1 R/C Truck

TM

Product Number 72824



Please keep these instructions for future reference.

Adult assembly is required to install batteries.

Requires four size "AA" (LR6) alkaline batteries (not included) in the truck.

Requires one 9-volt (6LR61) alkaline battery (not included) in the transmitter.

Tool needed for battery installation- Phillips Screwdriver.