


HOT WHEELS MID-AIR MADNESS™ WALL TRACKS INSTRUCTIONS

4+ Hangs with Command™

- YOU WILL NEED:**
- Low-adhesive tape such as painter's tape or masking tape
 - Approximately 3 feet of open wall space
 - 20 minutes



START HERE:

Please read all instructions before beginning assembly and set-up.

1 HANG POSTER

Lie poster flat and level against wall and tape as shown. Top of poster should align with the height of the child.

NOTE TO PARENTS: Before applying Command™ Strips make sure the wall surface is clean and dry. If cleaning is necessary 3M recommends using isopropyl rubbing alcohol. Do not use household cleaners.

2 PREPARE BRACKETS

You will find: 4 lettered brackets (marked A- D), 1 flat bracket, and 10 Command™ Strips (five extra strip). Separate strips. Remove red-printed liner from Command™ Strips and apply to back of brackets as shown. Make sure the strip tab is accessible for future removal.

NOTE: Apply strips to surfaces above 50°F (10°C). Adhesive could lose adhesion above 105°F (40°C).

CAUTION: DO NOT use with wallpaper. May not adhere well to vinyl surfaces. DO NOT hang items over beds.

Black Printing = On Wall
Red Printing = On Bracket

3 HANG BRACKETS

Remove black-printed liner from Command™ Strips and attach each bracket into the designated notch of the poster as shown.

Bracket should not overlap the poster.

Press bracket firmly onto wall and hold, pressing for 30 seconds.

Red arrow should line up with arrow on bracket.

Note: For optimal adhesion performance 3M recommends waiting 1 hour before adding weight to Command™ Strips.

FLAT BRACKET GOES HERE

CORRECT
INCORRECT

PRESS FIRMLY FOR 30 SECONDS

4 BATTERY INSTALLATION

- Unscrew the battery cover with a Phillips head screwdriver (not included).
- Install 2 "D" size (LR20) alkaline batteries (not included) in the orientation (+/-) shown.
- Replace battery cover and tighten screw.
- For longer life use alkaline batteries.
- Replace batteries when booster can no longer propel car through the track set.
- When exposed to an electrostatic source, the product may malfunction. To resume normal operation, remove and re-install the batteries.

5 ASSEMBLE TRACK PIECES

Pre-assemble pieces as shown.

SEE REVERSE FOR STEPS 6 - 9

INSTRUCTION SHEET SPECIFICATIONS

Title	HW IS CUSTOM COLOR ZINE
Part No.	W3423
Part Name	W3423
Print Size	3.5" W x 11" H
Print Area	11" W x 11" H
Type of File	Single
Color	Color
Pages	42 of 42
Page Weight	White Office
Print Weight	70 lb
Print No.	

3 PANEL Folding Dummy

SEE OTHER SIDE FOR STEPS 1-5

6 HANG TRACK ON WALL

Once poster and brackets are mounted on wall, attach track pieces as shown.

7 READY TO PLAY?

Switch on
I=ON
O=OFF

Load car and launch!

Send your cars in different directions!

8 REATTACHING & REMOVAL

Mounting brackets are designed to break away from the set without causing surface damage. If mounting plate separates from bracket, snap bracket back into place.

To remove brackets from the wall entirely:

- NEVER pull strip towards you.
- Hold bracket gently to prevent it from snapping fingers. DO NOT press against wall.
- Grab tab on Command™ Strip and SLOWLY STRETCH STRAIGHT DOWN ALONG WALL AT LEAST 12 INCHES until bracket and strip release.

Purchase medium Command™ Refill Strips to reapply to your wall.

12" / 30cm

9 CONNECT

Create your own set-ups with other Wall Tracks™ sets.

BATTERY SAFETY INFORMATION

In occasional circumstances batteries may leak fluids that can cause a chemical burn injury or ruin your product. To avoid battery leakage:

- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the product before being charged.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Do not mix old and new batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the product.
- The supply terminals are not to be short-circuited.
- Dispose of batteries safely.
- Do not dispose of this product in a fire. The batteries inside may explode or leak.

Protect the environment by not disposing of this product with household waste [2002/96/EC]. Check your local authority for recycling advice and facilities.

NOTE: Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

Command™ Strips are a product of 3M. For further information visit Command.com

©2017 Mattel, Inc. All Rights Reserved. Mattel, Inc., 5351 Great America, East Aurora, NY 14052, U.S.A. Consumer Relations: 1-800-524-8897 • Mattel (UK) Ltd., Sunningdale Parkway, Maidenhead SL6 6SE, Maidenhead (UK) SL6 6SE • Mattel Australia Pty. Ltd., Richmond, Victoria, 3113, Consumer Advisory Service: 1-800-553-372 • Mattel East Asia Ltd., Room 1116, South Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China • Olmeca & Dieckman GmbH, Mattel SEB P.O. Box 090303, P.O. Box 13, 1300 Pook, Mexico City, Mexico • Hot Wheels is a registered trademark of Mattel. ©2017 Mattel. All Rights Reserved.

W3423-0920 Asst. W3431

