



Downloadable adventures!
(see back)

Includes 2 "AAA" (R03) batteries.
Dispose of batteries safely.

Jake's Talking Spyglass

3+
Fisher-Price


02/06/2011 Remark for 0911
-Updated graphic on front panel
-Added QR code on back panel

LANGUAGE : US English

ASST. NO. (-DASH): PART CODE: SOFTWARE: COLOR PROFILE: GRACOL_EPC_High Speed / 150 lpi CS DATE:	NA (D/E): WS271-0911 Illustrator CSS GRACOL_EPC_High Speed / 150 lpi	GRAPHIC DESIGNER: Tracy Mai PI ENGINEER: Mandy Cheung PROJECT ENGINEER: Jim Ho CS VENDOR: Ocean
---	---	--

NOTES TO PRINTER:
1) Proofs accurate for process color only. All spot colors must follow PMS Color Formula Guide or color swatch specified.
2) For any dieline or structure change, signed sample approval by MAPS engineer is required before mass printing.


PROOF APPROVAL
SIGN OFF (GRAPHIC): _____ DATE: _____



Please keep these instructions for future reference as they contain important information.

BATTERY INSTALLATION:
Unscrew and lift away cover from back of a spyglass.
Replace batteries as indicated inside the battery compartment.
Batteries included are for demonstration purposes only.
For longer life use only alkaline batteries.
If this toy begins to operate erratically, you may need to reset the electronics.
Remove the batteries from the toy and replace them.
Requires 2 "AAA" (R03) batteries.

REQUIRED TOOL: PHILLIPS SCREWDRIVER (NOT INCLUDED)



BATTERY SAFETY INFORMATION
In exceptional circumstances batteries may leak fluids that can cause a chemical burn injury or ruin your product. To avoid battery leakage:
• Non-rechargeable batteries are not to be recharged.
• Rechargeable batteries are to be removed from the product before being charged.
• Rechargeable batteries are only to be charged under adult supervision.
• Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
• Do not mix old and new batteries.
• Only batteries of the same or equivalent type as recommended are to be used.
• Batteries are to be inserted with the correct polarity.
• Exhausted batteries are to be removed from the product.
• The supply terminals are not to be short-circuited.
• Dispose of batteries safely.
• Do not dispose of this product in a fire. The batteries inside may explode or leak.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.
NOTE: Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

• THIS CLASS B DIGITAL APPARATUS COMPLIES WITH CANADIAN ICES-003
• CET APPAREIL NUMERIQUE DE LA CLASSE B EST CONFORME A LA NORME NMB-003 DU CANADA.
• Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.
• L'utilisation de ce produit est soumise aux conditions suivantes: (1) il ne doit pas produire de brouillage et (2) il doit pouvoir tolérer tout brouillage reçu, même si ce brouillage est susceptible de compromettre son fonctionnement.

© Disney
Visit DisneyJunior.com
©2011 Mattel. All Rights Reserved.
*and ™ designate U.S. trademarks of Mattel, except as noted.
MADE IN CHINA.
Consumer Relations: Mattel, Inc., 636 Grand Avenue, East Aurora, NY 14023 U.S.A. 1-800-432-5437
Mattel East Asia Ltd., Room 1106, South Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China.
Disneyport & Distribution (Shanghai) Ltd. (993532) Lot 13.5, Menara Lien Hoe, Persiaran Topikiana Golf Country Resort, 47410 P1, Tel: 63-78803817, Fax: 03-78803867.

Colors and decorations may vary.
Conforms to the Safety Requirements of ASTM F963.

CONSUMER ASSISTANCE
1-800-432-5437 (U.S. & Canada)
service.fisher-price.com




Jake's Talking Spyglass

Keep an eye on Captain Hook!

Includes spyglass, map & headband!

If you spy Captain Hook, shout "Ahoy!"

Also available!

Jake's Magical Sword

Light-Up Tick Tock Croc

Download this code to your smart phone for more fun adventures with Jake and the Never Land Crew!

fisher-price.com



Jake's Talking Spyglass

Fisher-Price

- Jake & Hook phrases!
- Includes spyglass, map & headband!
- Hook appears in the spyglass!



Disney Junior

Fisher-Price

Keep an eye on Captain Hook!

Jake & Hook phrases!



Disney

Map of Never Land

Glue

Callout support behind the two circular graphics