
HTC Wireless Charger Quick Start Guide Model: HTC UW01



What's in the box

- Wireless charger
- Quick Start Guide
- USB Type-C cable
- Warranty card

Specifications

• Model: HTC UW01

· Color: Silver

• Material: Aluminium alloy + PVC


• Input: 5V==2A, 9V==2A, 12V==1.67A

• Output: 5V==5W, 7.5V==7.5W, 9V==10W, 12V==15W


• Input port: USB Type-C

• Operating temperature: 0°C to +40°C


Components



Charging your phone with the HTC Wireless Charger



Use the supplied USB Type-C cable to connect a power adapter (not included) to the HTC Wireless Charger. Plug in your power adapter to an outlet.



Place your Qi-compatible phone on top of the HTC Wireless Charger. Your phone will vibrate and charging will start automatically.



Make sure the back side of your phone (where the wireless charging coil is located) is placed on top of the HTC Wireless Charger. If your phone is not charging, adjust its position properly.

Note: The wireless charger stops charging when it overheats. After cooling down to a certain temperature, it will automatically resume charging.

Checking product authenticity





- **1.** Scan the QR code on the package with your phone.
- X HTC Digital product anti-counterfeit...




3. On your phone, enter the last four digits of the code.

- **2.** Scratch off the coating. You'll then see a code.
 - X HTC Digital product anti-counterfeit...



4. If the code is authentic, the Search results screen will show that you have a genuine product code.

X HTC Digital product anti-counterfeit..



Warning: If you see the above screen, beware of counterfeiting.



Legal Notice

HTC and the HTC logo are trademarks of HTC Corporation and used under license by Water World International Industrial Limited.

Copyright © 2022 Water World International Industrial Limited.

All rights reserved.

THIS DOCUMENT IS FOR INFORMATION PURPOSE ONLY, AND DOES NOT CONSTITUTE ANY KIND OF WARRANTIES.

RF exposure statement

This equipment complies with the FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and any part of your body.

FCC Warning

This device complies with Part 18 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.