

Assembly Instructions


Flexi 4 Shelf Large w/Casters

- Before you begin to assemble your new piece of furniture, please check to ensure that all parts have been supplied.
- Follow instructions closely as deviation from them may void your warranty and present a possible safety risk.
- It is recommended that assembly is done on a soft surface like carpet to avoid any damage.
- If you experience any problems with your new purchase please phone our Customer Service Hotline 1800 807 416 (Customers outside Australia should contact their closest Freedom store.)

Care Information

Periodically check and re-tighten any fasteners. Wipe down all surfaces weekly with a clean cloth. Do not clean any surfaces with harsh abrasives or chemicals.

Hardware



1xPart A



4xPart B



2xPart C




2xPart D




32xPart E


Parts



4xPart F



4xPart G




4xPart H


Assembly Instructions

Flexi 4 Shelf Large w/Casters


Step: 1



Step: 2




Step: 3




Assembly Instructions

Flexi 4 Shelf Large w/Casters

Step: 4



Step: 5



Finished :

