

Futaba TP-FSM 72 Synthesized RF Module Instructions

- To install the TP-FSM 72 into your T9C, make sure the power switch is in the "off" position. Next, Plug the TP-FSM 72 in place of the crystal type module. Push it all the way in until you hear it "Click" to ensure all contacts are in place.
- On the top of the TP-FSM 72, you will find two rotary dials marked X10 and X1. With the supplied plastic screwdriver, carefully turn the slots in each dial corresponding to the channel number you wish to transmit on.
- Next, change or select the channel of the receiver to match the channel you have selected.
- Turn on the transmitter first and then turn on the receiver. (approx. 1 second later) To make sure everything is working properly it is advised that you perform a range test with the transmitter antenna shortest position.
- If you confirmed everything working properly, you could play your r/c model with the transmitter antenna extended.
- Note: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- Always use only genuine Futaba receivers.
Futaba will not be responsible for problems caused by the use of other than Futaba genuine parts. Use the parts specified in the instruction manual and catalog.
- This RF module has been exclusively designed for use in transmitter model T9C. Operation in any other transmitter is not authorized and could void the user's authority to operate the equipment.
Only OEM integrators are authorized to install this RF module.