


# BLUE TOOTH SPEAKER MANUAL

## Parts:




- 1,Previous song
- 2,Volum+
- 3,Volum -
- 4,Next song
- 5,Audio line in jack
- 6,USB charge port


## Charge:



Fully charge the speaker before use.

Connect the speaker to the PC via provided USB cable. It is powered by internal rechargeable battery and it can using the converting cable for charging function by USB port. When the bottom RED LED flash approximately 15 times, it means the battery is low, please recharge the speaker. The solid RED LED will appear when speaker is on charged. The RED LED goes out when charge is finished



## Initial set up via Bluetooth



1. Turn on the Bluetooth™ Speaker by pressing up top control panel.
2. Wait for approximately 20 seconds,the speaker will go into pairing mode and will produce a "beep"tone.The bottom red led light will flash.
3. Turn on a device such as an ipod,iphone or mp3 device and go to:Setting>General>Bluetooth.Click on the bluetooth GP-508 will then appear on the device.Click on the GP-508. The device is now connected and paired with the speaker.If the device prompts for a pair code,enter:"0000"
4. If pairing is not successful within 150seconds,the system will search for the last paired device.To restart the pairing process,turn off the speaker and repeat step 1.If the initial set up connection is succesful,the next time the speaker is turned on,the speaker will automatically pair to the last device it was connected with.
5. Touch V+ for 1 second to increase the volume.When maximum volume has been reached, a tone indicator will sound.
6. Touch V- for 1 second to decrease the volume.When minimal volume has been reached ,a tone indicator will sound.
7. Touch  for 1 second to listen to the next song.
8. Touch  for 1 second to listen to the previous song.

## NOTE:

1. The bluetooth speaker only connects to one device at a time.Turn off the bluetooth speaker in order to pair the device with another bluetooth device.
2. The maximum transmission between the bluetooth speaker and a device is 10 meters or 32 feet.
3. Interference may occur during playback when using the bluetooth function near other wireless devices. If playback through bluetooth is problematic,move the bluetooth speaker and the playback device to a different location,or use the 3.5mm audio cable jack instead of the bluetooth function.

## WARNING:


The built-in rechargeable battery is not replaceable.Do not remove or replace battery.Dispose of unit properly.Do not dispose unit in trash or fire.

## Connecting with an audio cable

The bluetooth connection can be switched to a wired connection by plugging in the 3.5mm audio jack.

The volume key function will be disabled in the wired connection mode. Simply unplug the 3.5mm audio jack to


revert back to the bluetooth connection.



## Specification

Output:	3Wx1pcs
Signal To Noise Ratio:	>80dB
Frequency Response:	20Hz-20kHz
Distortion:	<10%
Battery Li-ion:	3.7v
Battery Capacity:	500mAh
Battery Charging Voltage:	5V
Charger Time:	3 hours max
Last Time:	5hours (via bluetooth to play)
Last Time:	7hours (via audio cable to play)
Driver Unit:	40mm, 4 Ohm ,3W
Dimension:	90x63mm
Power Indicator Light:	Blue lights
Transmission Distance:	10m
Work Frequency:	2.40-2.480GHz
Bluetooth Model:	V2.1+EDR
Transmission distance:	10m
Transmission Power:	bluetooth class 2

## GP-508 bluetooth operation Chart



**FCC Statement**

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

The antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.