

Operating instructions

- 1. Working voltage: 12V+/-3V**
- 2. Working current: maximum 15MA**
- 3. Working frequency: 433.96MHz**
- 4. Mediate Mode: ASK/ HCS301**
- 5. Working instructions:**

Press the first button of the remote control, the fist relay will have positive electricity output until you loose the first button. Repeat the above operation to the second button.

- 6. Learning coed:**

Press the learning button of the PCB 2seconds then loose, the LED of the PCB will light, which show to enter into learning state. Press any button of the remote control twice, the LED will be off then can work with the receiver. (please note the LED will be off automatically without learning code in 5seconds.) If failed in learning code can be repeated until success. The receiver can learn 20 remote controls at most.

- 7. Remove the code:**

Press the learning button of the PCB in 8seconds then loose, the LED flash show the original codes are successfully removed.

FCC WARNING

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for and radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.