

HMDX is pretty much short for awesome. Because you're rocking out to one tonight and every night from now on, prepare for an awesome night too, you awesome you.

The HMDX Neutron has friends—like lots of them. Invite them along next time for an even more epic night. You can check out all their online profiles at www.hmdxaudio.com.

Setup is pretty easy, but we put a manual together just in case you need it. It's full of information and sarcasm—just like that English teacher you had that crazy semester.







Charging the speakers is so easy you've probably figured it out by now, but just in case, you've got two options: your computer or a wall outlet.

- The cord that came with the speaker—the one with the USB on one end and the Micro USB on the other—will work with your computer.
- If you want to use the wall outlet, you'll need to pick up a power cord with a Micro USB the next time you're at the store, or use any USB AC adapter, including the one for your cell.



Now go get ready for an epic night while your speaker does too. It needs about 3 hours of me time for 4 hours of party time. For a longer party, plug it in using the aux cord for 12 hours of play.

- 1. That's the power button.
- Push it to play, push it again to pause.
- Turn the music up or down. (Wait, why do you need to turn it down?) 3.
- That light lets you know when Bluetooth has the hook-up.
- 5. That's the mic.
- 6. The power cord goes her
- 7. Hook it up old-school.
- 8. Easy pull tab

Like any amazing couple, this one starts with a connection—one between your device and the speaker's *Bluetooth*.

Here's how it works:

- We know you're probably going to think, "derp" with this one, but we have to say it: Make sure the smartphone, tablet or computer you war hook up to the speaker has Bluetooth. (There. We got that out of the w
- 2. Turn on the speaker and look for the little blinking light.
- Do whatever your device needs you to do on its end. (We don't know what you're using. We're not spies.)
- Look for HMDX NEUTRON in your device's *Bluetooth* list or click YES—whatever pops up on your device—and BAM! you're connected.
- Now hit PLAY on your speaker and crank it up—or down if you're lame.

You're probably only going to have to do this once, unless your device goes through a major l-just-dropped-it-in-the-pool kind of reboot. The device and Bluetooth will find each other every time just as long as the speaker is set to Bluetooth and your device's Bluetooth is, you know—on.

If you're connecting to a computer, you may have some extra steps o end. You'll have to get that information from the computer company.

Depending on your device you may be prompted to enter a pairing code. If prompted enter "0000" as the code.

To clear the pairing history hold the PLAY/PAUSE button for 5 seconds.

	What It Looks Like	What it Means
CHARGE	Flashing RED	Low Battery
	RED (when plugged in)	Charging
	Light turns off (when plugged in)	Fully Charged
*	Quick Flash BLUE	Pairing Mode
	Slow Flash BLUE	Connected
	RED	Line-in Mode



When friends call to interrupt your party of one—and you know they will—answer the phone without disconnecting from your HMDX Neutron.
Yes, that's right. Your speaker is a speakerphone too. How amazing is that? Here's how it works:

- Make sure your phone and the speaker are connected through *Bluetooth* and not on a "break."
- Answering and ending a call works the same way: simply click th PLAY/PAUSE button on your Neutron.

Neutron for three seconds to ignore the call.

THE COOLEST PART: The Neutron knows when a call is coming in and pause the music before ringing. When you hang up, the music starts where it left off—and so does the party. If it's you making the call, just start dialing from your phone, and the Neutron automatically does its hands-free thing. Isn't it refreshing to know your speaker totally gets you?

The smart folks who made this speaker designed it to keep the party going through just about anything (they call it IPX4). But those designers aren't miracle workers. Doing something like sending your speaker for a swim in the deep end will, at some point, fill those holes you need for incredible sound with water—and that's just not going to bode well for anyone or anything. Also, remember to keep the back flap flush with the speaker for the best protection.

A soft, dry towel is all you need to clean off your speaker. Using water, harsh cleaners or anything else only starts messing with the mechanics inside. So, yeah, don't do it.

FCC Disclaimer:
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energif not installed and used in accordance with the instructions, may caus harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receive
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Note: Changes or modifications not expressly approved by Jam could void the user's authority to operate this equipment.

For detailed Warranty Instructions and Information visit:

http://www.hmdxaudio.com/customer-support/warranty-1yr

To obtain warranty service on your HMDX product, contact a Consumer Relations Representative by telephone at 1-800-753-3000 or email cservice@hmdxaudio.com for assistance. Please make sure to have the model number of the product available. Representatives are available 8:30am - 7:00pm EST Monday-Friday.

IMPORTANT SAFEGUARDS:

When using an electrical product, basic particles followed, including the following:

- READ ALL INSTRUCTIONS BEFORE USING

 WARNING: Do not place speakers too close to ears. May cause damage to ear drums, especially in young children.

 Use this product only for its intended use as described in this manual. Do not use attachments not recommended by HMDX.

 HMDX is not liable for any damage caused to Smartphones, iPod/MP3

- player or any other device.

 Do not place or store this product where it can fall or be dropped into a
- tub or sink.
- tub or sink.

 Do not place or drop into water or any other liquid.

 Not for use by children. THIS IS NOT A TOY.

 Never operate this product if it has a damaged cord, plug, cab or housing.

 Keep away from heated surfaces.
- Only set on dry surfaces. Do not place on surface wet from water or cleaning solvents.

WARNING:

s product has an internal, non-replaceable lithium battery. Please dispose coordance with your local state, province and country guidelines.

r manual de instrucciones e Información de garantía en español visítenos www.hmdxaudio.com

©2014 HMDX, All Rights Reserved.