Cyber-Rain XCI WiFi

Installation and Quick Start Guide

Revision 1.0 - October 2015



Revision History

Revision	Date	Description
1.0	October 2015	Initial Draft.

Contact Us

Galcon LTD

Kfar Blum 12150, Israel

Tel: 972-4-6900222

Fax: 972-4-6902727

Email: info@galconc.com

Visit us at: www.galconc.com

Copyright © 2015 Galcon LTD. All rights reserved.

Information in this documentation is subject to change without notice and does not represent a commitment on part of Galcon LTD. The software described in this document is subject to the license agreement that is included with the product, which specifies the permitted and prohibited uses of the product.

Any unauthorized duplication or use of this documentation, in whole or in part, in print, or in any other storage or retrieval system is prohibited. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form by any means for any purpose other than the purchaser's personal use without the permission of Galcon LTD.

Contents

Before you Begin	4
What's inside the Box	4
Step 1: Connect to your Home WiFi Network	
Step 2: Install the Cyber-Rain Controller	8
Step 3: Wiring	0
Manual Operations	10
Opening Taps:	10
Stopping and Pausing Irrigation	10
Create your Account	11

Before you Begin

The Cyber-Rain XCI WiFi uses WiFi and must be installed at close proximity to a WiFi signal.

The Cyber-Rain XCI WiFi is designed to be installed indoors. If you install it outdoors, make sure to protect the unit using a water tight cover.


What's inside the Box




Step 1: Connect to your Home WiFi Network

Remove the controller and parts out of the box.

1. Remove the cover and the cables bridge by unscrewing the two screws.



2. Connect the power cable. Make sure to insert the cable in the direction shown on the unit. Connect the other side to a 110 - 220 V power socket.



The controller is powered on.

3. Press and hold the most lower button marked **Enter** for 5 seconds.



The WiFi symbol is flashing.

4. In your home pc or laptop locate the WiFi network named: Cyber_Rain WIFI and connect to it.



5. In your browser, type in: http://cyber-rain.net and in the window that appears select your home

WiFi network and password (if exist) and click Save.



The window closes and the controller is now connected to your home WiFi.

Note the WiFi icon on the controller screen indicating that the controller is connected to a WiFi network.

Step 2: Install the Cyber-Rain Controller


The Cyber-Rain XCI WiFi controller is designed for indoor installation. If you decide to install it outside, make sure to protect the unit from water, direct sunlight, and dust.

- 1. Position the unit against a wall and mark the top mounting hole for drilling.
- 2. Drill the hole and mount the unit using an appropriate screw (not provided).
- 3. Once the unit is mounted using the top hole, use the two bottom holes to affix the unit firmly to the wall.

Step 3: Wiring

For your convenience, take out the green connections block, connect the wires as described and then return the connection block back into its place.

- 1. Connect one wire from each valve to the matching connection number (1 to 8).
- Connect the second wire from each valve to the C connection.
 It is possible to connect all the C wires to a transmission cable outside the controller and to connect that cable to the C connection.
- 3. Connect the rain sensor wires to the connections marked **SEN**.



4. Close the controller cover.

Manual Operations

When your WiFi network is down, you can operate your Cyber-Rain XCI WiFi controller directly from the unit.

Opening Taps:

- 1. Press Enter \rightarrow the tap number flashes.
- 2. Use the arrow keys to select the tap number you want to open.
- 3. Press Enter again \rightarrow the time digits flash.
- 4. Use the arrow keys to set the irrigation time.
- 5. Press enter to confirm \rightarrow the Leds turn blue.


Stopping and Pausing Irrigation

- 1. Press Pause (top button) \rightarrow the controller returns to clock mode and the Leds turn purple.
- 2. Press and hold Pause for five seconds to put the controller on hold \rightarrow the leds turn red.
- 3. Press Pause again to release hold.


Create your Account

Visit http://cyber-rain.net to create your account and manage your controller online.


 In the Cyber Rain sign in page, click Create an account or sign in with your Google+ or Facebook account.



If you chose to create an account, in the Sign Up page, enter your account details and click **Submit**.




- 2. In the Welcome page, click **Add New Device**.
- 3. Type in your device serial number and give it a name, then click




The site authenticates your device and a PIN code will appear on the controller screen.

4. Type in this number in the **Verification** field and click to continue.



After a successful authentication, the following message appears:




5. Click select a network, select your home WiFi network and password, and click Save.




6. Click

The system locates your device and displays it on the map.



7. Click

Your controller is now ready to define irrigation zones.





FCC Compliance Statement

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installations. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio and television reception.

However, there is no guarantee that interference will not occur in a particular installation. If this device does cause such interference, which can be verified by turning the device off and on, the user is encouraged to eliminate the interference by one or more of the following measures:

- -Re-orient or re-locate the receiving antenna.
- -Increase the distance between the device and the receiver.
- Connect the device to an outlet on a circuit different from the one that supplies power to the receiver.
- -Consult the dealer or an experienced radio/TV technician.

WARNING! Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

To comply with FCC Section 1.310 for human exposure to radio frequency electromagnetic fields, implement the following instruction:

A distance of at least 20 cm between the equipment and all persons should be maintained during the operation of the equipment.