



Infotainment System



Owner's Manual
Guide de l'utilisateur
Manual del usuario





© 2012 Garmin Ltd. or its subsidiaries

All rights reserved. Under the copyright laws, this manual may not be copied, in whole or in part, without the written consent of Garmin. Garmin reserves the right to change or improve its products and to make changes in the content of this manual without obligation to notify any person or organization of such changes or improvements. Go to www.garmin.com for current updates and supplemental information concerning the use of this product.

Information in this document is subject to change without notice. Garmin reserves the right to change or improve its products and to make changes in the content without obligation to notify any person or organization of such changes or improvements. Go to the Garmin Web site (www.garmin.com) for current updates and supplemental information concerning the use and operation of this and other Garmin products.

Garmin® and the Garmin logo, are trademarks of Garmin Ltd. or its subsidiaries, registered in the USA and other countries. myTrends™ is a trademark of Garmin Ltd. or its subsidiaries. These trademarks may not be used without the express permission of Garmin.

The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc., and any use of such name by Garmin is under license. Apple® is a trademark of Apple Inc., registered in the U.S. and other countries. Pandora® is a registered trademark of Pandora Media, Inc.

This product has been certified under FCC ID: IPH-02023 and IC: 1792A-02023.

IMPORTANT

Please read this manual and follow its instructions carefully. To emphasize special information, the symbol **⚠** and words **WARNING** and **NOTICE** have a special meaning. Pay particular attention to messages highlighted by these signal words.

⚠ WARNING

Indicates a potential hazard that could result in death or serious injury.

NOTICE

Indicates a potential hazard that could result in property damage or negatively impact device functionality.





Table of Contents

Important Safety and Product Information	6	Traffic	24
Software License Agreement	7	Receiving Traffic Data	24
NAVTEQ® End-User License Agreement	7	Traffic on Your Route	24
NAVTEQ Traffic™ End User License Agreement	10	Traffic in Your Area	24
COFETEL (Mexico Compliance)	11	Understanding Traffic Data	25
Getting Started	12	Traffic Subscriptions	25
Using Device Applications	12	Enabling Traffic	25
Steering Wheel Controls	12	Media	26
Operating the Infotainment System	12	Using the Media Menu	26
Additional Steering Wheel Controls	13	Adjusting Media Sound	26
Multi-function Knob	13	Media Browser	26
Satellite Signals	13	Using the Radio	26
Using the On-screen Buttons	13	SD Card	27
Using the On-screen Keyboard	13	USB Audio	27
Setting Your Locale	13	Pandora®	28
Finding Locations	14	CD Player	28
Finding a Location by Category	14	Auxiliary Audio	29
Finding Fuel Stations	14	Bluetooth Audio	29
Finding an Address	14	Customizing the System	30
Finding a City	14	System Setting	30
Finding an Intersection	14	Adjusting the Volume Levels	30
Finding a Location Using the Map	14	Map Settings	30
Changing the Search Area	14	Navigation Settings	30
Saving a Home Location	15	Display Settings	30
Finding Recently Found Places	15	Bluetooth Settings	30
Finding Parking	15	Traffic Settings	31
		Language Settings	31
		Restoring Settings	31
		Navigation	18
		Starting a Route	18
		Following a Route	18
		Using myTrends	18
		About Exit Services	19
		Avoiding Road Features	19
		Map Pages	20
		Using the Map	20
		Customizing the Map	20
		Viewing Turns	20
		Viewing Current Location Information	21
		Hands-Free Phone Calls	22
		Using the Hands-Free Phone Menu	22
		Pairing Your Phone	22
		Placing a Call	22
		Receiving a Call	23
		Using the Call History	23
		Using In-Call Options	23
		Saving a Home Phone Number	23



Table of Contents

Appendix	32
Updating Maps	32
Cleaning the Touchscreen	32
Using the Backup Camera	32
Using USB Connections	32
Declaration of Conformity	33
Index	34



Important Safety and Product Information

Important Safety and Product Information



Failure to avoid the following potentially hazardous situations could result in an accident or collision resulting in death or serious injury.

Looking at the map on the navigation screen frequently or for too long while driving can potentially cause a crash, and you or others can potentially be seriously injured or killed. Keep your eyes and mind on the road and avoid looking at the navigation screen too often or for too long. Use voice guidance directions whenever possible.

If you are not familiar with the operation of the navigation system before you begin driving, you can become distracted while driving, which can lead to a crash.

Before you begin to operate your navigation system, read and become familiar with this manual. The navigation system has built-in features to minimize driver distraction, but the advanced technology of this system can never replace your judgement while driving.

Do not use pointed or hard items such as ball-point pens or pencils for touch screen operation.

Operation Warnings

- Always use your best judgement, and operate the vehicle in a safe manner. **Do not become distracted by the Infotainment System while**

driving, and always be fully aware of all driving conditions. Minimize the amount of time spent viewing the Infotainment System screen while driving and use voice prompts when possible.

- Do not input destinations, change settings, or access any functions requiring prolonged use of the system controls while driving. Pull over in a safe and legal manner before attempting such operations.
- When navigating, carefully compare information displayed on the device to all available navigation sources, including road signs, road closures, road conditions, traffic congestion, weather conditions, and other factors that may affect safety while driving. For safety, always resolve any discrepancies before continuing navigation, and defer to posted road signs and road conditions.

- The navigation system is designed to provide route suggestions. It is not a replacement for driver attentiveness and good judgement. **Do not follow route suggestions if they suggest an unsafe or illegal maneuver or would place the vehicle in an unsafe situation.**

Map Data Information

Garmin uses a combination of governmental and private data sources. Virtually all data sources contain some inaccurate or incomplete data. In some countries, complete and accurate map information is either not available or is prohibitively expensive.

Declaration of Conformity

Hereby, Garmin, declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. To view the full Declaration of Conformity, go to www.garmin.com/compliance.

CE Mark

If the CE Alert mark is present on your device, this device uses frequency bands that are not harmonised throughout the EU, and/or the intended use of the device is subject to restrictions made by one or more Member States.

FCC Compliance

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and may cause harmful interference to radio communications if not installed and used in accordance with the instructions. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the





Important Safety and Product Information

user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet that is on a different circuit from the GPS unit.
- Consult the dealer or an experienced radio/TV technician for help.

This product does not contain any user-serviceable parts. Repairs should only be made by an authorized Garmin service center. Unauthorized repairs or modifications could result in permanent damage to the equipment, and void your warranty and your authority to operate this device under Part 15 regulations

Industry Canada Compliance

Category I radiocommunication devices comply with Industry Canada Standard RSS-210. Category II radiocommunication devices comply with Industry Canada Standard RSS-310.

This device complies with part 15 of the FCC and Industry Canada Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

End-User License Agreements

Software License Agreement

BY USING THE INFOTAINMENT SYSTEM YOU AGREE TO BE BOUND BY THE TERMS AND CONDITIONS OF

THE FOLLOWING SOFTWARE LICENSE AGREEMENT. PLEASE READ THIS AGREEMENT CAREFULLY.

Garmin Ltd. and its subsidiaries ("Garmin") grant you a limited license to use the software embedded in this device (the "Software") in binary executable form in the normal operation of the product. Title, ownership rights, and intellectual property rights in and to the Software remain in Garmin and/or its third-party providers.

You acknowledge that the Software is the property of Garmin and/or its third-party providers and is protected under the United States of America copyright laws and international copyright treaties. You further acknowledge that the structure, organization, and code of the Software, for which source code is not provided, are valuable trade secrets of Garmin and/or its third-party providers and that the Software in source code form remains a valuable trade secret of Garmin and/or its third-party providers. You agree not to decompile, disassemble, modify, reverse assemble, reverse engineer, or reduce to human readable form the Software or any part thereof or create any derivative works based on the Software. You agree not to export or re-export the Software to any country in violation of the export control laws of the United States of America or the export control laws of any other applicable country.

NAVTEQ® End-User License Agreement

The software embedded in your Garmin product (the "Software") is owned by Garmin Ltd. or its subsidiaries ("Garmin"). The third-party map data embedded in or accompanying your Garmin product (the "Map Data") is owned by NAVTEQ North America LLC and/or its affiliates ("NAVTEQ") and is licensed to Garmin. Garmin also licenses

information, text, images, graphics, photographs, audio, video, images and other applications and data from third party data providers ("Third Party Content Data"). The Map Data and Third Party Content Data are collectively the "Data". Both the Software and Data are protected under copyright laws and international copyright treaties. The Software and Data are licensed, not sold. The Software and Data are provided under the following license and are subject to the following terms and conditions which are agreed to by End User ("you" or "your"), on the one hand, and Garmin and its licensors (including their licensors and suppliers) and affiliated companies on the other hand.

IMPORTANT: CAREFULLY READ THIS LICENSE BEFORE USING THIS PRODUCT. INSTALLING, COPYING, OR OTHERWISE USING THIS PRODUCT INDICATES YOUR ACKNOWLEDGMENT THAT YOU HAVE READ THIS LICENSE AND AGREE TO ITS TERMS.

License Terms and Conditions

Garmin ("we" or "us") provides you with storage media containing the computer Software (the "Software") and the embedded or accompanying Data, including any "online" or electronic documentation and printed materials (together called the "Product" for purposes of this License Agreement), and grants you a limited, non-exclusive license to use the Product in accordance with the terms of this Agreement. You agree to use this Data together with the Garmin product for solely personal, or if applicable, for use in your business' internal operations, and not for service bureau, time-sharing, resale or other similar purposes. Accordingly, but subject to the restrictions set forth in the following paragraphs, you may copy this Data only as necessary for



Important Safety and Product Information

your use to (i) view it; and (ii) save it, provided that you do not remove any copyright notices that appear and do not modify the Software or Data in any way. You agree not to otherwise reproduce, copy, modify, decompile, disassemble, reverse engineer or create derivative works of any portion of the Product, and may not transfer or distribute it in any form, for any purpose, except to the extent permitted by mandatory laws. Garmin also reserves the right to discontinue offering any Data supplied by any third party supplier if such supplier ceases to supply such content or Garmin's contract with such supplier terminates for any reason.

Restrictions. Except where you have been specifically licensed to do so by Garmin, and without limiting the preceding paragraph, you may not use this Data with any products, systems, or applications installed or otherwise connected to or in communication with vehicles, and which are capable of dispatch, fleet management or similar applications where the Data is used by a central control center in dispatching a fleet of vehicles. In addition, you are prohibited from renting or leasing the Data or the Garmin products containing the Data to any other person or third party. Only those rental car companies that are specifically authorized by Garmin in writing to rent Garmin products containing the Data to their rental customers are permitted to rent out such products.

No Warranty. This Product (including the Data) is provided to you "as is," and you agree to use it at your own risk. Garmin and its licensors (and their licensors and suppliers) make no guarantees, representations or warranties of any kind, express or implied, arising by law or otherwise, including but not limited to, content, quality, accuracy, completeness, effectiveness, reliability,

merchantability, fitness for a particular purpose, usefulness, use or results to be obtained from the Product, or that the Data or server will be uninterrupted or error-free.

Disclaimer of Warranty. GARMIN AND ITS LICENSORS (INCLUDING THEIR LICENSORS AND SUPPLIERS) DISCLAIM ANY WARRANTIES, EXPRESS OR IMPLIED, OF QUALITY, PERFORMANCE, MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NONINFRINGEMENT. NO ORAL OR WRITTEN ADVICE OR INFORMATION PROVIDED BY GARMIN OR ITS SUPPLIERS AND LICENSORS SHALL CREATE A WARRANTY, AND YOU ARE NOT ENTITLED TO RELY ON ANY SUCH ADVICE OR INFORMATION. THIS DISCLAIMER OF WARRANTIES IS AN ESSENTIAL CONDITION OF THIS AGREEMENT. Some States, Territories and Countries do not allow certain warranty exclusions, so to that extent the above exclusion may not apply to you.

Disclaimer of Liability. GARMIN AND ITS LICENSORS (INCLUDING THEIR LICENSORS AND SUPPLIERS) SHALL NOT BE LIABLE TO YOU: IN RESPECT OF ANY CLAIM, DEMAND OR ACTION, IRRESPECTIVE OF THE NATURE OF THE CAUSE OF THE CLAIM, DEMAND OR ACTION ALLEGING ANY LOSS, INJURY OR DAMAGES, DIRECT OR INDIRECT, WHICH MAY RESULT FROM THE USE OR POSSESSION OF THE INFORMATION; OR FOR ANY LOSS OF PROFIT, REVENUE, CONTRACTS OR SAVINGS, OR ANY OTHER DIRECT, INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF YOUR USE OF OR INABILITY TO USE THIS INFORMATION, ANY DEFECT IN THE DATA OR INFORMATION, OR THE BREACH OF THESE TERMS OR CONDITIONS, WHETHER IN AN ACTION IN CONTRACT OR TORT OR BASED ON A WARRANTY, EVEN IF GARMIN OR ITS LICENSORS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. GARMIN'S AND ITS LICENSORS'

TOTAL AGGREGATE LIABILITY WITH RESPECT TO ITS OBLIGATIONS UNDER THIS AGREEMENT OR OTHERWISE WITH RESPECT TO THE GARMIN PRODUCT OR THE DATA SHALL NOT EXCEED \$1.00.

Some States, Territories and Countries do not allow certain liability exclusions or damages limitations, so to that extent the above may not apply to you. **Disclaimer of Endorsement.** Reference to any products, services, processes, hypertext links to third parties or other Data by trade name, trademark, manufacturer, supplier or otherwise does not necessarily constitute or imply its endorsement, sponsorship or recommendation by Garmin or its licensors. Product and service information are the sole responsibility of each individual vendor. The NAVTEQ name and logo, the NAVTEQ and NAVTEQ ON BOARD trademarks and logos, and other trademarks and trade names owned by NAVTEQ North America LLC may not be used in any commercial manner without the prior written consent of NAVTEQ.

Export Control. You agree not to export from anywhere any part of the Data provided to you or any direct product thereof except in compliance with, and with all licenses and approvals required under, applicable export laws, rules and regulations.

Indemnity. You agree to indemnify, defend and hold Garmin and its licensors (including their respective licensors, suppliers, assignees, subsidiaries, affiliated companies, and the respective officers, directors, employees, shareholders, agents and representatives of each of them) free and harmless from and against any liability, loss, injury (including injuries resulting in death), demand, action, cost, expense, or claim of any kind or character, including but not limited to attorney's fees, arising out of or in connection with any use or possession by you of the Product



Important Safety and Product Information

(including the Data).

Canadian Map Data. The Map Data for Canada may include or reflect data of licensors, including Her Majesty and Canada Post. Such data is licensed on an "as is" basis. The licensors, including Her Majesty and Canada Post, make no guarantees, representations or warranties respecting such data, either express or implied, arising by law or otherwise, including but not limited to, effectiveness, completeness, accuracy or fitness for a particular purpose. The licensors, including Her Majesty and Canada Post, shall not be liable in respect of any claim, demand or action, irrespective of the nature of the cause of the claim, demand or action alleging any loss, injury or damages, direct or indirect, which may result from the use or possession of the data or the Map Data. The licensors, including Her Majesty and Canada Post, shall not be liable in any way for loss of revenues or contracts, or any other consequential loss of any kind resulting from any defect in the data or the Map Data. You shall indemnify and save harmless the licensors, including Her Majesty the Queen, the Minister of Natural Resources of Canada and Canada Post, and their officers, employees and agents from and against any claim, demand or action, irrespective of the nature of the cause of the claim, demand or action, alleging loss, costs, expenses, damages or injuries (including injuries resulting in death) arising out of the use or possession of the data or the Map Data. The terms contained in this Section are in addition to all of the rights and obligations of the parties under the Agreement. To the extent that any of the provisions of this Section are inconsistent with, or conflict with, any other provisions of the Agreement, the provisions of this Section shall prevail.

United States Map Data. NAVTEQ holds a non-

exclusive license from the United States Postal Service® to publish and sell ZIP+4® information. ©United States Postal Service® 2010. Prices are not established, controlled or approved by the United States Postal Service®. The following trademarks and registrations are owned by the USPS: United States Postal Service, USPS, and ZIP+4.

Canadian Map Data. Map Data for Canada includes information taken with permission from Canadian authorities, including © Her Majesty, © Queen's Printer for Ontario, © Canada Post, GeoBase®, © Department of Natural Resources Canada. All rights reserved.

Australian Map Data. Map Data for Australia is based on data NAVTEQ has licensed from PSMA Australia Limited (www.pasma.com.au). In addition, the Product incorporates data which is © 2010 Telstra Corporation Limited, GM Holden Limited, Intelmatics Australia Pty Ltd, Sentinel Content Pty Limited and Continental Pty Ltd. If your Product uses RDS-TMC Codes contained in the Map Data, the traffic location codes are © 2010 Telstra Corporation Limited and its licensors.

Term. This Agreement is effective until such time as (i) if applicable, your subscription term is either terminated (by you or by Garmin) or expires, or (ii) Garmin terminates this Agreement for any reason, including, but not limited to, if Garmin finds that you have violated any of the terms of this Agreement. In addition, this Agreement shall terminate immediately upon the termination of an agreement between Garmin and any third party from whom Garmin licenses the Data.

Entire Agreement. These terms and conditions constitute the entire agreement between Garmin (and its licensors, including their licensors and suppliers) and you pertaining to the subject matter hereof, and supersedes in their entirety any and all written or oral agreements previously existing

between us with respect to such subject matter.

Governing Law.

(a) For European Union NAVTEQ Data
The above terms and conditions shall be governed by the laws of the Netherlands, without giving effect to (i) its conflict of laws provisions, or (ii) the United Nations Convention for Contracts for the International Sale of Goods, which is explicitly excluded. You agree to submit to the jurisdiction of the Netherlands for any and all disputes, claims and actions arising from or in connection with the NAVTEQ Data provided to you hereunder.

(b) For North American NAVTEQ Data and other non-European Union NAVTEQ Data
The above terms and conditions shall be governed by the laws of Illinois, without giving effect to (i) its conflict of laws provisions, or (ii) the United Nations Convention for Contracts for the International Sale of Goods, which is explicitly excluded. You agree to submit to the jurisdiction of Illinois for any and all disputes, claims and actions arising from or in connection with the NAVTEQ Data provided to you hereunder.

(c) For disputes, claims and actions not related to the NAVTEQ Data
The above terms and conditions shall be governed by the laws of Kansas, without giving effect to (i) its conflict of laws provisions, or (ii) the United Nations Convention for Contracts for the International Sale of Goods, which is explicitly excluded. You agree to submit to the jurisdiction of Kansas for any and all disputes, claims and actions arising from or in connection with the NAVTEQ Data provided to you hereunder.

Government End Users. If End User is an agency, department, or other entity of the United States Government, or funded in whole or in part by the U.S. Government, then use, duplication,



Important Safety and Product Information

reproduction, release, modification, disclosure or transfer of the Product and accompanying documentation is subject to restrictions as set forth in DFARS 252.227-7014(a)(1) (JUN 1995) (DOD commercial computer software definition), DFARS 27.7202-1 (DOD policy on commercial computer software), FAR 52.227-19 (JUN 1987) (commercial computer software clause for civilian agencies), DFARS 252.227-7015 (NOV 1995) (DOD technical data – commercial items clause); FAR 52.227-14 Alternates I, II, and III (JUN 1987) (civilian agency technical data and noncommercial computer software clause); and/or FAR 1.2.2.11 and FAR 1.2.2.12 (commercial item acquisitions), as applicable. In case of conflict between any of the FAR and DFARS provisions listed herein and this License, the construction that provides greater limitations on the Government's rights shall control. The contractor/manufacturer is Garmin International, Inc., 1200 East 151st Street, Olathe, KS 66062, USA and NAVTEQ North America LLC, 425 West Randolph Street, Chicago, Illinois 60606 USA. Garmin® is a trademark of Garmin Ltd. or its subsidiaries, registered in the USA and other countries. These trademarks may not be used without the express permission of Garmin. NAVTEQ is a trademark in the U.S. and other countries. All other company names and trademarks mentioned or referenced in this documentation are the properties of their respective owners. All rights reserved.

NAVTEQ Traffic™ End User License Agreement

Your Garmin product may be equipped to receive traffic data. If it is so equipped, the following terms and conditions apply to your use of your Garmin product.

NAVTEQ North America LLC and/or its affiliates including Traffic.com ("NAVTEQ") holds the rights to the traffic event data ("Traffic Data") and, if you receive RDS/TMC or HD Radio™ Traffic Data, the RDS/TMC or HD Radio networks through which it is delivered to your Garmin product. By subscribing to, receiving or otherwise accessing the Traffic Data, you acknowledge that you have read this Agreement, that you understand it, that you agree to be bound by the terms and conditions of this Agreement, and that you are at least 18 years of age. If you do not agree to the terms and conditions of this Agreement, decline the subscription or, if the subscription is bundled as part of your Garmin product, return the product within 7 days for a full refund to the dealer from which you purchased the product.

You agree to use the Traffic Data together with your Garmin product solely for personal, non-commercial purposes, and not for service bureau, time-sharing or other similar purposes. You may not modify, copy, scan, decompile, disassemble or reverse engineer any portion of the Traffic Data, or use any other method to reproduce, duplicate, republish, transmit, or distribute in any way any portion of the Traffic Data. You agree to indemnify, defend, and hold harmless NAVTEQ (and its affiliates) and Garmin Ltd. (and its subsidiaries) against any and all claims, damages, costs, or other expenses that arise directly or indirectly out of (a) your unauthorized use of the Traffic Data or the RDS/TMC or HD Radio networks, (b) your violation of this Agreement, and/or (c) any unauthorized or unlawful activities by you in connection herewith. The Traffic Data is informational only. You assume all risk of use. NAVTEQ (and its affiliates), Garmin Ltd. (and its subsidiaries), and their suppliers make no representations about content, traffic and road conditions, route usability, or speed.

The Traffic Data is provided to you "as is," and you agree to use it at your own risk. NAVTEQ (and its affiliates) and Garmin Ltd. (and its subsidiaries) make no warranty of fitness or compatibility of the Traffic Data with the Garmin product and no warranty that the Traffic Data will operate properly as integrated and interfaced with the Garmin product. In addition, NAVTEQ (and its affiliates) and Garmin Ltd. (and its subsidiaries) make no warranty with regard to the reliability, accuracy, exhaustiveness, and completeness of the Traffic Data, which may contain inaccuracies and/or errors from time to time. To the maximum extent permitted by applicable law, any and all warranties of any kind whatsoever with regard to the Traffic Data are hereby expressly waived and excluded, including, but not limited to, those of merchantability, fitness for a particular purpose, accuracy or completeness of the Traffic Data, and/or a lack of viruses.

NAVTEQ (and its affiliates), Garmin Ltd. (and its subsidiaries), and their suppliers disclaim all liability for any loss, injury, or damage resulting from use of or inability to use the Garmin product and the Traffic Data as a result of weather difficulties, the destruction of transmitters and/or broadcasting infrastructures, a natural disaster, and/or a lack of reliability, completeness, or accuracy of the Traffic Data. In no event shall NAVTEQ (and its affiliates), Garmin Ltd. (and its subsidiaries), and their suppliers be liable to you or any other party for any compensatory, direct, indirect, incidental, special, or consequential damages (including, without limitation, indirect, direct, special, punitive, or exemplary damages for loss of business, loss of profits, business interruption, or loss of business information) arising out of the use of or inability to use the Garmin product or the Traffic Data, even if NAVTEQ or Garmin have been advised of the



Important Safety and Product Information

possibility of such damages.

Traffic. If you purchase or your Garmin product is pre-loaded with "lifetime" or "one-time" traffic, you will receive Traffic Data for the useful life of your Garmin traffic receiver (as long as you own a compatible Garmin GPS) or as long as Garmin receives Traffic Data from its third party content supplier, whichever is shorter. Garmin may terminate your traffic subscription immediately if you violate any of the terms of this Agreement. Your traffic subscription may not be transferred to another person or another Garmin product.

Governing Law. The above terms and conditions shall be governed by the laws of the State of Illinois, without giving effect to (i) its conflict of laws provisions, or (ii) the United Nations Convention for Contracts for the International Sale of Goods, which is explicitly excluded. You agree to submit to the jurisdiction of the State of Illinois for any and all disputes, claims and actions arising from or in connection with the Traffic Data provided to you hereunder.

Government End Users. If the Traffic Data is being acquired by or on behalf of the United States government or any other entity seeking or applying rights similar to those customarily claimed by the United States government, this Data is a "commercial item" as that term is defined at 48 C.F.R. ("FAR") 2.101, is licensed in accordance with this Agreement, and the Traffic Data delivered or otherwise furnished shall be marked and embedded as appropriate with the following "Notice of Use" and shall be treated in accordance with such Notice:

Notice of Use

Contractor (Manufacturer/ Supplier) Name:
NAVTEQ

Contractor (Manufacturer/supplier) Address: 425

West Randolph Street, Chicago, Illinois 60606

This Data is a commercial item as defined in FAR 2.101 and is subject to the NAVTEQ Traffic™ End User License Agreement under which this Data was provided.

© 2008 NAVTEQ; © 2008 Traffic.com – All rights reserved.

If the Contracting Officer, federal government agency, or any federal official refuses to use the legend provided herein, the Contracting Officer, federal government agency, or any federal official must notify NAVTEQ prior to seeking additional or alternative rights in the Traffic Data.

NAVTEQ and Traffic.com are trademarks in the U.S. and other countries. © 2008 NAVTEQ; © 2008 Traffic.com. All rights reserved.

HD Radio Technology manufactured under license from iBiquity Digital Corporation, U.S. and Foreign Patents. HD Radio™ and the HD, HD Radio, and "Arc" logos are proprietary trademarks of iBiquity Digital Corp.

Garmin® is a trademark of Garmin Ltd. or its subsidiaries, registered in the USA and other countries. This trademark may not be used without the express permission of Garmin. All other company names and trademarks mentioned or referenced in this documentation are the properties of their respective owners. All rights reserved.

COFETEL (Mexico Compliance)

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.



Getting Started

Getting Started

⚠ WARNING

Failure to familiarize yourself with the product safety information can lead to an accident.


See the *Important Safety and Product Information* section (page 6) for product warnings and other important information.

Failure to read and follow all safety warnings in this manual can result in serious injury or death.

Be sure to read and follow all safety warnings in this manual.

NOTE: The screenshots shown in this manual may not exactly match the screens on your navigation system. The images used in this manual are intended for reference only.

Operating the Infotainment System



- Select ① to activate Voice Command.
- Insert a CD in ②.
- Select ③ to eject a CD.
- Select icons on ④ to change system applications.
- Turn ⑤ to adjust the volume or press to turn off system.
- Use ⑥ to connect compatible external devices to system.
- Insert SD card in ⑦.

12



Using Device Applications

Application icons are always located at the top of the screen. The icons display information about features on the device. Select the icons to change settings or view additional information.

	Select to set or change media type.
	Select for navigation options.
	Select for phone or Bluetooth®.
	Select to change settings.

Steering Wheel Controls

NOTE: Steering wheel controls may not be available in all vehicles or models.



- Select ① to mute the volume.
- Select ② to change the media type.
- Select ③ to adjust the volume.
- Select ④ find radio stations or skip tracks.

Garmin Infotainment System



Additional Steering Wheel Controls

NOTE: You must have a Bluetooth connection to your phone (page 22). Additional steering wheel controls are not available in all vehicles or models.



- Select **1** to activate Voice Command (page 17).
- Select **2** to talk on Bluetooth-connected phone.
- Select **3** to end phone call.

Multi-function Knob



You can permanently damage your ears and lose hearing if you listen to the device at a high volume. The volume is typically too loud if you cannot hear people speaking around you. Limit the amount of time you listen at high volume. If you experience ringing in your ears or muffled speech, stop listening and have your hearing checked.



- Turn **1** to adjust the volume.
- Press **2** to turn off system.

Satellite Signals


After the Infotainment System is turned on, it begins acquiring satellite signals. The system may need a clear view of the sky to acquire satellite signals. When at least one of the  bars is green, your system has acquired satellite signals.

Using the On-screen Buttons

- Select  to return to the previous page.
- Hold  to quickly return to the main application page.
- Select  or  to see more choices.
- Hold  or  to scroll faster.

Using the On-screen Keyboard


See "Language and Keyboard Settings" to change the keyboard layout (page 31). Select a character on the keyboard to enter a letter or number.

- Select  to add a space.
- Hold  to delete a character.

Setting Your Locale

You must set a locale the first time you use the Infotainment System.


- 1 Select a country, and select **OK**.



- 2 Select **Agree**.

Resetting Your Locale

To reset your local, you must restore the Infotainment System to the factory default settings.

- 1 Select .
- 2 If necessary, select a settings category.
- 3 Select **Restore > Yes**.
- 4 Select a country, and select **OK**.





Finding Locations

Finding Locations

The detailed maps loaded in your Infotainment System contain locations, such as restaurants, hotels, and auto services. You can use categories to browse for nearby businesses and attractions.

Finding a Location by Category

- 1 Select **▲** > **Where To?**.
- 2 Select a category.
- 3 If necessary, select a subcategory.
- 4 Select a location.

Searching Within a Category

To narrow your search results, you can search within some categories.

- 1 Select **▲** > **Where To?**.
- 2 Select a category.
- 3 If necessary, select a subcategory.
- 4 If necessary, select **Spell**.

Finding Fuel Stations

You can find nearby fuel stations.

- 1 Select **▲** > **Where To?** > **Points of Interest** > **Fuel**.
- 2 Select a fuel station.

Finding an Address

NOTE: The order of the steps may change depending on the map data loaded on your device.

- 1 Select **▲** > **Where To?** > **Address**.
- 2 Select a city.
- 3 Enter the address number, and select **Done**.
- 4 Enter the street name, and select **Done**.
- 5 If necessary, select **Searching In** to change the city, state, or province.
- 6 If necessary, select the city, the state, or the province.
- 7 If necessary, select the address.

Finding a City

- 1 Select **▲** > **Where To?** > **Cities**.
 - 2 Select **Spell City**.
 - 3 Enter a city name.
- NOTE:** If necessary, select **State or Country** to change the country, state, or province.
- 4 Select a city.

Finding an Intersection

- 1 Select **▲** > **Where To?** > **Intersection**.
 - 2 Select a state or province.
- NOTE:** If necessary, select **State or Country** to change the country, state, or province.
- 3 Select a city.
 - 4 Enter the first street name, and select **Done**.
 - 5 If necessary, select the street.

- 6 Enter the second street name, and select **Next**.

- 7 If necessary, select the street.
- 8 If necessary, select the intersection.

Finding a Location Using the Map

You can find places included in the map data, such as restaurants, hospitals, and fuel stations.

- 1 Select **▲** > **Browse Map**.
- 2 Drag and zoom the map to display the area to search.
- 3 If necessary, select a category icon to view only a specific category of places.
Location markers **(U)** appear on the map.
- 4 Select a point, such as a street, intersection, or address location.
- 5 If necessary, select the map information box to view additional information.

Changing the Search Area

By default, your device finds locations closest to your current location. You can find a location near another city or location.

- 1 Select **▲** > **Where To?** > **Near**.
- 2 Select an option.
- 3 If necessary, select a location.



Saving a Home Location

You can set your home location for the location you return to most often.

- 1 Select **▲** > **Where To?** > **Go Home**.
- 2 Select **Enter My Address, Use My Current Location, or Recently Found**.

The location is saved as "Home" in the Saved menu (page 15).

Going Home

Select **▲** > **Where To?** > **Go Home**.

Editing Your Home Location Information

- 1 Select **▲** > **Where To?** > **Favorites** > **Home**.
- 2 Select the information box on the map.
- 3 Select **Edit**.
- 4 Enter your changes.
- 5 Select **Done**.

Finding Recently Found Places

Your device stores the last 50 locations you have found.

- 1 Select **▲** > **Where To?** > **Recently Found**.
- 2 Select a location.

Clearing the List of Recently Found Places

Select **Where To?** > **Recent** > **Clear** > **Yes**.

Finding Parking

- 1 Select **▲** > **Where To?** > **Points of Interest** > **Parking**.

- 2 Select a parking location.

Setting a Simulated Location

If you are not receiving satellite signals, you can use the Infotainment System to set a simulated location.

- 1 Select **✈** > **System**.
- 2 Select **GPS Simulator** > **On** > **OK**.
- 3 Select **▲** > **View Map**.
- 4 Select an area on the map.
- 5 Select **Set Location**.

Saving Locations

You can save locations so you can quickly find them and create routes to them.

Saving a Location

- 1 Search for a location (page 14).
- 2 From the search results, select a location.
- 3 Select **Save**.
- 4 If necessary, enter a name, and select **Done**.

Saving Your Current Location

- 1 From the map, select the vehicle icon.
- 2 Select **Save**.
- 3 Enter a name, and select **Done**.
- 4 Select **OK**.

Finding Locations

Starting a Route to a Saved Location

- 1 Select **▲** > **Where To?** > **Favorites**.
- 2 If necessary, select a category, or select **All Saved Places**.
- 3 Select a location.
- 4 Select **Go!**.

Editing a Saved Location

- 1 Select **▲** > **Where To?** > **Favorites**.
- 2 If necessary, select a category.
- 3 Select a location.
- 4 Select **More Information** > **Edit**.

- 5 Select an option:
 - Select **Name**.
 - Select **Phone Number**.
 - To assign categories to the Favorite, select **Categories**.
 - To change the symbol used to mark the Favorite on a map, select **Change Map Symbol**.

- 6 Edit the information.

- 7 Select **Done**.



Finding Locations

Assigning Categories to a Saved Location

You can add custom categories to organize your saved locations.

NOTE: Categories appear in Favorites after you have saved more than 12 locations.

- 1 Select > **Where To?** > **Favorites**.
- 2 Select a location.
- 3 Select **More Information**.
- 4 Select **Edit** > **Categories**.
- 5 Enter one or more category names, or choose an existing category.
- 6 Select **Done**.

Deleting a Saved Location

NOTE: Deleted locations cannot be recovered.

- 1 Select > **Where To?** > **Favorites**.
- 2 If necessary, select a category.
- 3 Select a location.
- 4 Select **More Information** > **Delete**.
- 5 Select **Yes**.

Planning a Trip

You can use the trip planner to create and save a trip with multiple destinations.

- 1 Select **Trip Planner**.
- 2 Select .
- 3 Select **Select Start Location**.
- 4 Search for a location (page 14).
- 5 Select **Select**.
- 6 To add additional locations, select .
- 7 Select **Next**.
- 8 Enter a name, and select **Done**.

Editing a Trip Itinerary

- 1 Select **Trip Planner**.
- 2 Select a saved trip.
- 3 Select an option:
 - Select a location in the trip to change the arrival or departure time.
 - Select a location in the trip, and then select **Duration** to record how long you stay at a location.
 - Select a travel time to change the route preference for that portion of the trip.
 - Select **Map** to view the trip on the map.

Navigating to a Saved Trip

- 1 Select **Trip Planner**.
- 2 Select a saved trip.
- 3 Select **Go!**.
- 4 If prompted, select **Next Destination**.
- 5 Select **Start**.

Editing a Saved Trip

- 1 Select **Trip Planner**.
- 2 Select a saved trip.
- 3 Select **Edit**.
- 4 Select an option:
 - Select **Edit Destinations** to add and delete locations, or to change the order of locations.
 - Select **Delete Trip**.
 - Select **Rename Trip**.

Optimizing a Saved Trip

You can arrange the stops on your trip in the most-efficient order.

- 1 Select **Trip Planner**.
- 2 Select a saved trip.
- 3 Select **Optimize**.



Voice Command

About Voice Command

NOTE: Voice Command is not available for all languages and regions, and may not be available on all models.

Voice Command allows you to use your device by saying words and commands. The Voice Command menu provides voice prompts and a list of available commands.

Activating Voice Command

Select  on the upper-left corner of the device (page 12).

 appears in the upper-right corner of the screen.

Voice Command Tips

- Speak in a normal voice directed at the Infotainment System.
- Reduce background noise, such as voices or the radio, to increase the accuracy of the voice recognition.
- Speak commands as they appear on the screen.
- Respond to voice prompts as needed.
- Listen for two tones to confirm when the system enters and exits Voice Command mode.

Voice Command

Starting a Route Using Voice Command

You can say the names of popular, well-known locations.

- 1 Say **Find Place**.
- 2 Say the **Category** or **Place Name**.
- 3 Say the line number.
- 4 Say **Navigate**.

Finding an Address

- 1 Say **Find Address**.
- 2 Say the entire address.
- 3 Say **Navigate**.

Disabling Voice Command

Say **Stop Listening**.





Navigation

Navigation


Starting a Route

- 1 Search for a location (page 14).
- 2 Select a location.
- 3 Select **Go!**.
- 4 If necessary, select an option.
- 5 If necessary, select a route.

Following a Route


The route is marked with a magenta line. A checkered flag marks your destination.

As you travel, the navigation system guides you to the destination with voice prompts, arrows on the map, and directions at the top of the map. If you depart from the original route, the device recalculates the route and provides new directions.



Adding a Point to a Route

Before you can add a stop to a route, you must be navigating a route.

- 1 While navigating a route, select  to return to the main menu.
- 2 Select **Where To?**.
- 3 Search for the location (page 14).
- 4 Select **Go!**.
- 5 Select **Add to Active Route**.

Taking a Detour

While navigating a route, you can use detours to avoid obstacles ahead of you, such as construction zones.

NOTE: If the route you are currently navigating is the only reasonable option, your device might not calculate a detour.

Select  > **Detour**.

Stopping a Route

Select  > **Stop**.

Using myTrends

Before you can use this feature, you must save at least one location and enable the travel history feature (page 31).

Using the myTrends™ feature, your navigation system predicts your destination based on your travel history, the day of the week, and the time of day. After you have driven to a saved location several times, the location may appear in the navigation bar on the map, along with the estimated time of travel, and traffic information.

Select the navigation bar to view a suggested route to the location.





About Exit Services

NOTE: You must be on a major interstate highway or road to use Exit Services.

While you navigate a route, you can find gas, food, lodging, and restrooms near upcoming exits.

Services are listed under tabs by category.

	Gas
	Food
	Lodging
	Restrooms

Finding Exit Services

- 1 Select **Where To?** > **Exit Services**.
- 2 Use the arrows to select an upcoming exit.
- 3 Select an exit service tab.
- 4 Select a point of interest.

Navigating to an Exit

- 1 From the map, select **Where To?** > **Exit Services**.
- 2 Select an exit service.
- 3 Select **Go!**.

Avoiding Road Features

- 1 Select > **Navigation** > **Avoidances**.
- 2 Select the road features to avoid on your routes, and select **OK**.





Map Pages

Map Pages

Using the Map

- 1 From the main menu, select **View Map**.
- 2 If the zoom controls are hidden, select the map to display the zoom controls.
- 3 Select the map to switch to browsing mode. Map buttons appear.
- 4 Select an option:
 - To zoom in or out, select **+** or **-**.
 - To rotate the map view, select **↻**.
 - To switch between North Up and 3-D views, select **!**.
 - To center the map on your current location, select **📍**.



Customizing the Map

Viewing the Trip Log

Your device keeps a trip log, which is a record of the path you have traveled.

- 1 Select **📍** > **Map**.
- 2 Select **Show** below Trip Log.
- 3 Select **Show** > **OK**.

Changing the Map Data Fields

- 1 From the map, select a data field in the lower left-hand corner.
- 2 Select a type of data to display.
- 3 Select **Save**.

Changing the Map Perspective


- 1 Select **📍** > **Map** > **Map View**.
- 2 Select an option:
 - Select **Track Up** to display the map in two dimensions (2-D), with your direction of travel at the top.
 - Select **North Up** to display the map in 2-D with North at the top.
 - Select **3-D** to display the map in three dimensions.

Viewing Turns

Viewing a List of Turns

When you are navigating a route, you can view all of the turns and maneuvers for your entire route and the distance between turns.

- 1 Select the text bar on the top of the map.
- 2 Select a turn.



The details for the turn appear. If available, an image of the junction appears for junction on major roadways.



Viewing the Entire Route on the Map


- 1 While navigating a route, select the navigation bar at the top of the map.
- 2 Select **Map**.

Viewing the Next Turn

While navigating a route, a preview of the next turn, lane change, or other maneuver appears in the upper-left corner of the map.

The preview includes the distance to the turn or maneuver and the lane in which you should be traveling, if available.

From the map, select **📍** to view the next turn on the map.






Viewing Junctions

While navigating a route, you can view the junctions on many major roadways. When you approach a junction in a route, the image of that junction appears briefly, if available.

From the map, select  to view the junction, if available.



Viewing Traffic Alerts


While you navigate a route with an active traffic subscription, traffic alerts may appear.

Select the alert to view more information.

Viewing Trip Information

The trip information page displays your present speed and provides statistics about your trip.

From the map, select **Speed**.



Resetting Trip Information

- 1 From the map, select **Speed**.
- 2 Select **Reset**.
- 3 Select an option:
 - Select **Reset Trip Mileage** to reset the odometer.
 - Select **Reset Max. Speed** to reset the maximum speed.
- 4 Select **OK**.

Viewing Current Location Information

You can use the **Where Am I?** page to view information about your current location. This feature is helpful if you need to tell emergency personnel your location.

Select  > **Where Am I?**.

Finding Nearby Services

You can use the **Where Am I?** page to find nearby services, such as hospitals, police stations, and fuel.

- 1 From the map, select **Where Am I?**.
- 2 Select a category.
- 3 Select a location.





Hands-Free Phone Calls

Hands-Free Phone Calls

Using Bluetooth® wireless technology, your Infotainment System can connect to your mobile phone to become a hands-free device. Your phone may not support all of the hands-free phone features Infotainment System provides.

Using the Hands-Free Phone Menu

Select 



- Select **1** to make a call.
- Select **2** to change phone or disable Bluetooth connection.
- Select **3** to view call history.
- Select **4** to call Home.
- Select **5** to call a POI.
- Select **6** to view and call contacts.
- Select **7** to view phone messages.


Pairing Your Phone

Before you can use hands-free calling, you must pair your device with a compatible mobile phone. Pairing your phone with your device allows your phone and device to recognize each other and connect quickly.

- 1 Place your phone and your device within 33 ft. (10 m) of each other.
- 2 Select  > **Bluetooth** > **Enabled** > **OK** to enable Bluetooth technology.
- 3 Select **Add**.
- 4 On your phone, enable Bluetooth wireless technology.
- 5 Select **OK**.

- 6 A list of nearby Bluetooth devices appears.
- 7 Select your phone from the list, and select **OK**. If necessary, on your phone, confirm that the device is allowed to connect.
- 8 If necessary, enter the device Bluetooth PIN (1234) into your phone.

Disconnecting Your Phone

- 1 Select  > **Bluetooth** > **Enabled**.
 - 2 Select **Disabled** > **OK**.
- Your phone is disconnected from your device but remains paired with your device.

Tips After Pairing the Devices

- After the initial pairing, the system and your phone can connect automatically each time you turn them on.
- When your phone is connected to the system, you are ready to make phone calls.
- When you turn on the Infotainment System, it tries to connect to the last phone to which it was connected.

- You might need to set your mobile phone to connect to the system automatically when the system is turned on.

Placing a Call

Your Infotainment System and phone must be paired before you can place a call using the hands-free feature.

Dialing a Number

- 1 Select  > **Dial**.
- 2 Enter the number.
- 3 Select **Call**.

Calling a Contact in Your Phone Book

Your phone book is loaded from your phone to the device each time your phone and the device connect. It may take a few minutes for the phone book to be available. Some phones do not support this feature.

- 1 Select  > **Contacts**.
- 2 Select a contact.
- 3 Select **Call**.

Calling a Location

- 1 Select  > **POI**.
- 2 Select a point of interest if a phone number is available (page 14).
- 3 Select **Call**.





Connected on a Call



- Select **1** to end a call.
- Select **2** to place a call on hold.
- Select **3** to mute a call.
- Select **4** to view the keypad.
- Select **5** to add a call for a conference.
- Select **6** to view contacts.
- Select **7** to switch to the phone.

Receiving a Call

When you receive a call, select **Answer** or **Ignore**.

Using the Call History

Your call history is loaded from your phone to the device each time your phone and the device connect. It may take a few minutes for the call history to be available. Some phones do not support this feature.

- 1 Select **Call History**.
- 2 Select a category.
A list of calls appears, with the most recent calls at the top.
- 3 Select a call.

Using In-Call Options

While on a call, select an option.

- To transfer audio to your phone, select **To Mobile**.
- TIP:** You can use this feature if you want to turn off your device and remain on the call, or if you need privacy.
- To display a keypad, select **Keypad**.
- TIP:** You can use this feature to use automated systems, such as voice mail.
- To mute the microphone, select **Mute Mic**.
- To hang up, select **End Call**.

Saving a Home Phone Number

TIP: After you save a home number, you can edit the home number by editing "Home" in your list of saved locations (page 15).

- 1 Select **Call Home** > **Set Home Number**.
- 2 Enter your home phone number.
- 3 Select **Done**.

Calling Home

Before you can call home using the Call Home button, you must enter a phone number for your home location.

Select **Call Home**.



Traffic

Traffic

NOTICE

Garmin is not responsible for the accuracy or timeliness of the traffic information.


NOTE: Traffic information may not be available in all areas or countries.

Your Intonation System can receive traffic information using a traffic subscription from Garmin Live Services. For information about traffic and coverage areas, go to www.garmin.com/suzuki.

Receiving Traffic Data

When you have a traffic subscription and your vehicle is within a traffic coverage area, the Intonation System displays traffic information.

About the Traffic Icon

When you are receiving traffic information, a traffic icon appears on the map. The traffic icon  changes color to indicate the severity of traffic conditions on your route or on the road you are currently traveling.


Color	Severity	Meaning
Green	Low	Traffic is flowing freely.
Yellow	Medium	Traffic is moving but there is a delay. There is moderate traffic congestion.
Red	High	Traffic is not moving or moving slowly. There is a severe delay.
Gray	No signal	Traffic information is not available.

Traffic on Your Route


When calculating your route, the system examines the current traffic and automatically optimizes the route for the shortest time. If a severe traffic delay occurs on your route while you are navigating, the system automatically recalculates the route.

Your system may route you through a traffic delay if a better alternative route does not exist. The delay time is added into your estimated time of arrival automatically.

Viewing Traffic on Your Route

- 1 While navigating a route, select .
- 2 Select **Traffic Search**.
A list of traffic events appears, organized by their location on the route.
- 3 Select an event.

Manually Avoiding Traffic on Your Route

- 1 From the map, select .
- 2 Select **Traffic Search**.
- 3 If necessary, use the arrows to view other traffic delays on your route.
- 4 Select **Avoid**.

Taking an Alternate Route

- 1 While navigating a route, select .
- 2 Select **Alternate Route**.
- 3 Select a route.


Viewing Traffic on the Map

The traffic map shows color-coded traffic flow and delays on nearby roads.

- 1 From the map, select .
- 2 Select **Traffic Conditions**.

Traffic in Your Area


Searching for Traffic Delays

- 1 From the map, select .
- 2 Select **Traffic Conditions**.
- 3 Select an item in the list.
- 4 If there is more than one delay, use the arrows to view additional delays.





Viewing a Traffic Incident on the Map

- 1 From the map, select .
- 2 Select **Traffic Conditions**.
- 3 Select a traffic icon.

Understanding Traffic Data


The traffic legend explains the icons and colors used on the traffic map.

- 1 From the map, select .
- 2 Select **Traffic Legend**.

Traffic Subscriptions

Adding a Subscription

You can purchase traffic subscriptions for specific regions or countries.

- 1 From the main menu, select  > **Traffic**.
- 2 Select **Subscriptions**.
- 3 Select an option:
 - For non-North American units, select **Subscriptions > +**.
 - For North American units, select **+**.
- 4 Write down the Infotainment System unit ID.
- 5 Go to www.garmin.com/suzuki to purchase a subscription and get a 25-character code.

The traffic subscription code cannot be reused. You must obtain a new code each time you renew your service. If you own multiple FM traffic receivers, you must obtain a new code for each receiver.
- 6 Select **Next** on the device.

Garmin Infotainment System






Media

Media

The Infotainment System supports several types of media. You can listen to AM/FM radio, Pandora® (North America only) on your Apple® mobile digital device, audio files on an SD card, CDs, Bluetooth wireless technology supported devices, and other types of mobile digital devices.

Using the Media Menu

Select > **Media**.



	Radio
	SD Card
	USB
	Pandora (North America only)
	Auxiliary
	Bluetooth
	CD Player

Adjusting Media Sound

You can adjust the volume, bass, treble, middle tones, and fade and balance for all of the media types.

Adjusting the Volume

Turn the multifunction knob (page 13).

Adjusting Tones

- From the media menu, select **Radio > Sound**.
- Select an option.
 - Adjust the bass with and .
 - Adjust the middle tones with and .
 - Adjust the treble with and .
 - Select **Balance and Fade** to adjust the sound location and balance in your vehicle.

Media Browser

You can browse and select different audio files.

- Select > **Media**.
- Select a media type.
- Select **Browse**.
- Select an option.
 - Select **Playlists** to display playlists.
 - Select **Artists** to display the different artists.
 - Select **Albums** to display available albums.
 - Select **Songs** to display songs.
 - Select **Genres** to display different music genres.

Using the Radio

You can listen to AM and FM radio on your Infotainment System.

Playing the Radio

Select > **Media > Radio**.



- Select **1** to search for stations.
- Select **2** to select AM, FM1, or FM2.
- Select **3** to manually select stations.
- Select **4** to change media.
- Select **5** to adjust the sound.
- Select **6** to automatically set the preset programs with local stations.
- Select **7** and hold buttons for five seconds to save the current station.



SD Card

NOTICE

Do not paste stickers on SD cards. The SD cards can get jammed in the slot.

Dirt or liquids on the SD card can cause faults and damage the card and card reader.

You can listen to audio files on an SD card on your Infotainment System.

Supported Audio Formats

The SD card player supports these audio file formats.

- WMA
- MP3 files

Playing an SD Card

- 1 Push an SD card **1** into the SD card slot **2** until it clicks in place.



- 2 Select **Media** > **SD**.



- Select **1** to view current track information.
- Select **2** to find similar music.
- Select **3** to restart track or go to previous track, and hold to scan backward in current track.
- Select **4** to start or pause playback.
- Select **5** to go to next track, and hold to scan forward in current track.
- Select **6** to change media.
- Select **7** to adjust the sound.
- Select **8** to browse the media.
- Select **9** to view the current playlist.
- Select **10** to repeat.

USB Audio

You can listen to audio files from an Apple mobile digital device, flash drive, and other USB mass storage devices through the USB port in your vehicle.

Listening to Music Through USB

- 1 Connect your audio player to the USB port in your vehicle.

NOTE: See your vehicle owner's manual for USB port location information.

Media

- 2 Select **Media** > **USB**.



- Select **1** to view current track information.
- Select **2** to find similar music.
- Select **3** to restart track or go to previous track, and hold to scan backward in current track.
- Select **4** to start or pause playback.
- Select **5** to go to next track, and hold to scan forward in current track.
- Select **6** to change media.
- Select **7** to adjust the sound.
- Select **8** to browse the media.
- Select **9** to view the current playlist.
- Select **10** to repeat.

Using Your Apple Mobile Digital Device with Other Media Apps

NOTE: iOS 5.1 or newer is required on your Apple mobile digital device.

You can control and view media information from media apps on your Apple mobile digital device.

- 1 Launch the media app on your Apple mobile digital device.
- 2 Select **Media** > **USB**.





Media

Viewing and controlling USB media is available on your Apple mobile digital device.

Switching Back to the Apple Music Player App

- 1 Select **Media** > **USB**.
- 2 Select **iPod**.

Pandora®

NOTICE


Pandora® capability is available for Apple mobile digital devices only.

Available in North America only.

Using an Apple mobile digital device, you can listen to Pandora on your Infotainment System.

Using Pandora

Select **Media** > **Pandora**.



- Select **1** for information on the track and artist.
- Select **2** to change media.
- Select **3** to adjust the sound.
- Select **4** to change stations.
- Select **5** to bookmark the track or artist.
- Select **6** to start or pause playback.

- Select **7** to change to the next track.
- Select **8** to rate track with a thumbs up or thumbs down.

Listening to Pandora

- 1 You must have the Pandora app loaded on your Apple device.
- 2 Launch the Pandora app on your Apple mobile digital device.
- 3 Connect your Apple device to your vehicle USB port.
- 4 Select **Media** > **Pandora**.
Pandora plays on the Infotainment System.

Creating a Station on Pandora

You can create custom stations on Pandora.

- 1 From the Pandora screen, select **Stations** > **Edit**.
- 2 Select **Create a station**.
- 3 Search for a station.
- 4 From the search results, select a station.
- 5 Select **Yes**.

Deleting a Station on Pandora

- 1 From the Pandora screen, select **Stations** > **Edit**.
- 2 Select **Delete Station(s)**.
- 3 Select a station from the list.
- 4 Select **Yes**.

CD Player

NOTICE

You do not forcibly insert a CD into the CD player. Do not paste stickers on CDs. These disks can get jammed in the CD drive and ruin it.

Dirt or liquids on CDs can smear the lens of the audio player inside the device and cause faults. You can play audio CDs and data CDs that contain music files on the Infotainment System.

Supported Audio Formats

The CD player supports these audio file formats on write-only disks.

- WMA
- MP3 files

Playing a CD

Insert an audio CD **1** with the readable side down into the CD slot **2**.



CD playback starts automatically and the CD or CD MP3 menu is displayed.



Media

NOTE: If the CD has been previously played and is still in the CD player, playback starts with the most recently played track.



- Select **1** to restart track or go to previous track, and hold to scan backward in current track.
- Select **2** to start or pause playback.
- Select **3** to go to next track, and hold to scan forward in current track.
- Select **4** to change media.
- Select **5** to adjust the sound.
- Select **6** to shuffle tracks.
- Select **7** to repeat the selection.




Auxiliary Audio

You can listen to music and other audio files from an MP3 player, iPod, or other mobile digital devices on your Infotainment System.

Using the Auxiliary Port

- 1 Connect your player to the Auxiliary port.
- 2 Select **Media** > **AUX**.
Track selection is made from your mobile digital device.



- Select **1** to change media.
- Select **2** to adjust the sound.

Bluetooth Audio

NOTE: You must have a Bluetooth technology compatible device to play music using a Bluetooth wireless connection on your Infotainment System.

Using a Bluetooth Connection

- 1 Connect your device to the Infotainment System using a Bluetooth technology connection (page 22).
- 2 Select **Media** > **Bluetooth**.
The music starts playing.



- Select **1** to restart track or go to previous track, and hold to scan backward in current track.
- Select **2** to start or pause playback.
- Select **3** to go to next track, and hold to scan forward in current track.





Customizing the System

Customizing the System

- 1 Select .
- 2 Select a setting category.
- 3 Select the setting to change it.

System Setting

Select > **System**.

GPS Simulator: Stops the device from receiving a GPS signal.

Units: Sets the unit of measure used for distances.

Keyboard Layout: Sets the keyboard layout.

Time Format: Allows you to select a 12-hour, 24-hour, or UTC display time.

About: Displays the software version number, the unit ID number, and information on several other software features.

Adjusting the Volume Levels

- 1 Select > **Volume**.
- 2 Select **Volume Mixer**.
- 3 Select an option.
 - Use and to adjust the radio, SD card, USB, AUX, CD, or Bluetooth volume levels.
 - Use and to adjust the Navigation, Voice, and Voice Command volume levels.
 - Use and to adjust the phone ringer and speaker phone volume levels.

Voice Prompts Activation

- 1 Select > **Volume** > **Voice Prompts**.
- 2 Select **On** > **OK**.

Recognition Prompt Activation

- 1 Select > **Volume** > **Recognition Prompt**.
- 2 Select **On** > **OK**.

Map Settings

Select > **Map**.

Vehicle: Changes the icon to represent your position on the map.

Map View: Sets the perspective on the map.

Map Detail: Sets the level of detail on the map. More detail may cause the map to draw slower.

Trip Log: Hide or display trip log information.

Navigation Settings

Select > **Navigation**.

Route Preference: Sets route preference.

Avoidances: Sets road features to avoid on a route (page 19).

Route Preferences

Select > **Navigation** > **Route Preference**.

The route calculation is based on road speeds and vehicle acceleration data for a given route.

Faster Time: Calculates routes that are faster to drive but can be longer in distance.

Shorter Distance: Calculates routes that are shorter in distance but can take more time to drive.

Prompted: The system calculates different routes to your location.

Display Settings

Select > **Display**.

Color Mode: Sets a light background (**Day**), a dark background (**Night**), or automatically, based on the vehicle head lamp input (**Auto**).

Brightness: Changes the brightness of the screen.

Bluetooth Settings

Select > **Bluetooth**.

Bluetooth: Enables the Bluetooth component.

Device: Manages connections between your device and mobile phones with Bluetooth wireless technology.

Friendly Name: Allows you to enter or edit a friendly name that identifies your devices with Bluetooth technology.

Managing the Bluetooth Device List

You can add, disconnect, or delete phones that your system detects while Bluetooth is enabled.

- 1 Select > **Bluetooth** > **Device**.
- 2 Select an option:
 - Select a phone for your device to connect with.
 - Select **Add Device** to add a device to the menu.



- Select **Remove** to delete a device from the menu.

Disabling Bluetooth

- 1 Select > **Bluetooth** > **Enabled**.
- 2 Select **Disabled**.
- 3 Select **OK**.

Traffic Settings

You must have an active traffic subscription to use the traffic settings.

Select > **Traffic**.

Traffic: Enables traffic

Subscriptions: Lists current traffic subscriptions.

Enabling Traffic

You must have an active traffic subscription.

Select > **Traffic** > **Traffic**.

About Traffic Subscriptions

You can purchase additional subscriptions or a renewal if your subscription expires. Go to buy.garmin.com.

Viewing Traffic Subscriptions

Select > **Traffic** > **Subscriptions**.

Language Settings

NOTE: Changing the text language also changes the voice language.

Select > **Language**.

Voice Language: Sets the language for voice prompts.

Text Language: Sets all on-screen text to the selected language.

NOTE: Changing the text language does not change the language of user-entered data or map data, such as street names.

Keyboard: Sets the language for your keyboard.

Restoring Settings

You can restore a category of settings or all settings to the factory default values.

- 1 Select .
- 2 If necessary, select a settings category.
- 3 Select **Restore**.



Appendix

Appendix

Updating Maps

You can update the maps on your device. For more information, go to www.garmin.com/suzuki.

Cleaning the Touchscreen

- 1 Use a soft, clean, lint-free cloth.
- 2 If necessary, use water, isopropyl alcohol, or eyeglass lens cleaner.
- 3 Apply the liquid to the cloth.
- 4 Gently wipe the screen with the cloth.

Using the Backup Camera



Keep your eyes and mind on driving while using the backup camera. Using a backup camera is an enhancement for safety practices. The backup camera is not a replacement for driver attentiveness and good judgement.

NOTE: The backup camera only displays when your vehicle is in reverse.

If your vehicle is equipped with a backup camera, you can view the area behind your vehicle as you back up.

- 1 Place your vehicle in **Reverse**.

The backup camera displays the area behind your vehicle on the Infotainment System screen.

- 2 Back up your vehicle.

Using USB Connections



Do not connect multiple USB devices to the USB connector using a USB hub or other multi-device connectors. Supplying power to multiple USB devices from the connector could cause overheating and smoking.

NOTE: Refer to the vehicle documentation to find the location of the USB port.

You can listen to audio files on USB devices (page 27). Your Infotainment System supports two types of USB devices.

- USB memory stick
- USB audio player



Declaration of Conformity

English

Hereby, Garmin, declares that this Infotainment System is in compliance with the essential requirements and other relevant provisions of Directive 1999 / 5 / EC.

Prohlášení o shodě Italian

Czech

Společnost Garmin tímto prohlašuje, že tento systém Infotainment odpovídá základním požadavkům a dalším relevantním ustanovením směrnice 1999 / 5 / EC.

Overensstemmelseserklæring

Danish

Garmin erklærer at dette infotainment System overholder de essentielle krav og andre relevante dele af direktivet 1999/5/EC.

Conformiteitsverklaring

Dutch

Hierbij verklaart Garmin dat dit Infotainment System voldoet aan de essentiële vereisten en overige relevante bepalingen in Richtlijn 1999 / 5 / EC.

VASTAVUSDEKLARATSIOON

Estonian

Käesolevaga kinnitab Garmin, et see meelelahutuslik IT-süsteem vastab direktiivi 1999 / 5 / EÜ nõuetele ja muudele asjakohastele sätetele.

Konformitätserklärung

German

Garmin erklärt hiermit, dass dieses Infotainment System den wesentlichen Anforderungen und weiteren relevanten Vorschriften der Direktive 1999/5/EG entspricht.

Δήλωση συμμόρφωσης!

Greek

Δια του παρόντος, η Garmin δηλώνει ότι το συγκεκριμένο προϊόν Infotainment System συμμορφώνεται πλήρως με τις κύριες απαιτήσεις και άλλες σχετικές διατάξεις της οδηγίας 1999/5/ΕΚ της Ευρωπαϊκής Κοινότητας.

Megfelelőségi nyilatkozat

Hungarian

A Garmin ezermel kijelenti, hogy ez az infotainment rendszer az 1999/5/ EK irányelvben foglalt minden lényeges követelménynek és más vonatkozó rendelkezésnek megfelel.

Vaatumustenmukaisuusvakuutus

Finnish

Garmin vakuuttaa täten, että tämä tieto- ja viihdejärjestelmä on direktiivin 1999/5/EY olemainten vaatimusten ja muiden määräysten mukainen.

Déclaration de conformité

French

Par la présente, Garmin déclare que cet Infotainment System est conforme aux principales exigences et autres clauses pertinentes de la directive européenne 1999/5/EC.

Samræmisýfirlýsing

Icelandic

Hér með lýsir Garmin því yfir að þetta Infotainment System sé í samræmi við grundvallarkröfur og önnur viðeigandi ákvæði tilskipunar 1999 / 5 / EB.

Dichiarazione di conformità

Italian

Con il presente documento, Garmin dichiara che il sistema Infotainment è conforme ai requisiti essenziali e alle altre disposizioni in materia previste dalla Direttiva 1999/5/CE.

Atbilstības deklarācija

Latvian

Garmin ar šo paziņo, ka šī informatīvi izkaidējošā sistēma atbilst Direktīvas 1999/5/EK pamatprasībām un citiem saistītajiem noteikumiem.

Atifikties deklaracija

Lithuanian

Šiuo dokumentu „Garmin“ pareiškia, kad ši informacinė pramoginė sistema atitinka 1999/5/EB direktyvos pagrindinius reikalavimus ir kitas atitinkamas nuostatas.

Appendix

Perisytiharan Kepatuhan

Maltese

Dengan ini, Garmin mengisytiharkan bahawa Sistem Maklumat Hibur ini adalah mematuhi syarat-syarat utama dan peruntukan berkaitan lain Arahan 1999 / 5 / EC.

Samsvarserklæring

Norwegian

Garmin erklærer herved at dette Infotainment-systemet samsvarer med hovedkravene og andre relevante bestemmelser i direktivet 1999/5/EF.

Deklaracja zgodności

Polish

Firma Garmin niniejszym deklaruje, że ten system infomacyjny/rozrywkowy spełnia zasadnicze wymagania dyrektywy 1999/5/WE i inne określone w niej warunki.

Declaração de Conformidade

Portuguese

Por este meio, a Garmin declara que este sistema Infotainment cumpre os requisitos fundamentais e restantes provisões aplicáveis constantes da Directiva 1999/5/CE.

Vyhlasenie o zhode

Slovak

Spoločnosť Garmin týmto vyhlasuje, že tento systém Infotainment je v súlade s nevyhnutnými požiadavkami a ďalšími príslušnými ustanoveniami Smernice 1999 / 5 / ES.

Izjava o skladnosti

Slovenian

S tem Garmin izjavlja, da je ta informativno-razvedrlni sistem skladen z bistvenimi zahtevami in drugimi ustreznimi določili direktive 1999/5/ES.

Declaración de conformidad

Spanish

Por la presente, Garmin declara que este Infotainment System cumple con los requisitos esenciales y otras disposiciones relevantes de la Directiva 1999/5/CE.

Överensstämmelseförklaring

Swedish

Härmed intygar Garmin att det här infotainment-systemet överensstämmer med de grundläggande kraven och andra föreskrifter i direktiv 1999/5/EG.



Index

Index

Symbols

- 2-D map view 20
- 3-D map view 20

A

- accessories 32
- addresses 14
- audio
 - sound adjustment 26
- auxiliary audio 29
- avoidances
- traffic 24

B

- backup camera 32
- Bluetooth technology 22–23
- friendly name 30
- media 29
- pairing a phone 22
- settings 30
- brightness 30

C

- calls
 - answering 23
 - contacts 22
 - dialing 22
 - history 23
 - home 23
 - muting 23
- cd
 - file formats 28

- playing 28
- cleaning the touchscreen 32
- current location, saving 15
- customizing the system 30–35

D

- deleting
 - recent finds list 15
 - saved locations 16
 - trips 16
- detours 18
- advanced 19
- diacritical characters 13
- driving directions 20

E

- editing
 - change categories 15
 - destinations 16
 - home 15
 - locations 15
 - map symbol 15
 - saved trip 16
- EULAs 7–11
- exit services 19

F

- Favorites. See saving locations
- finding locations
 - addresses 14
 - parking 15
 - recent selections 15
 - saved locations 15
 - using the map 14
- fuel stations 14

G

- going home 15
- GPS
 - settings 30
 - simulator 15

H

- hands-free phone calls 22
- home
 - going 15
 - phone number 23
 - setting a location 15

I

- icons
 - applications 12
 - finding 14
- intersections

J

- junction view 21

K

- keyboard 13
- language 31

L

- language
 - keyboard 31
 - text 31
 - voice 31
- locale
 - initial setting 13
 - locations 14

M

- maps
 - data layout 20
 - detail level 30
 - errors 15
 - theme 30
 - view 20
- media
 - auxiliary audio 28
 - Bluetooth technology 29
 - browser 26
 - cd player 28
 - Pandora 28
 - radio 26
 - SD card 27
 - sound 26
- muting
 - calls 23
- myTrends 18

N

- navigation 18
- off road 19
- next turn 20

P

- pairing a mobile phone 22
- Pandora 28
- parking 15
- PIN
 - Bluetooth technology 22
- points of interest
 - finding 14



Index

- R**
- recalculating routes 18
 - recently found locations 15
 - renaming trips 16
 - resetting
 - home location 15
 - the max speed 21
 - routes
 - off road 19
 - stopping 18
- S**
- safety information 6
 - satellite signals 13
 - saving locations 15–16
 - screen
 - brightness 30
 - SD card 27
 - settings 30–31
 - software
 - version 30
 - sound adjustment 26
 - system settings 30–31
- T**
- time settings 30
 - Track Up 20
 - traffic 24–25
 - activating a subscription 25, 31
 - adding traffic subscriptions 31
 - incidents 24
 - traffic alerts 21
 - trip computer 21
 - resetting information 18
- U**
- unit ID 30
- V**
- voice command
 - activating 17
 - icons and tones 17
 - navigating with 17
 - voice language 31
 - voice mail 23
 - volume
 - adjusting 13, 30
 - volume mixer 30
- W**
- where am i? 21



