Ergonomic Dual Scroll Optical Mouse Instruction Manual

HO97769 rev. 3





www.jascoproducts.com

TABLE OF CONTENTS

FEATURE DESCRIPTIONS3
PACKAGE CONTENTS 3
SYSTEM REQUIREMENTS 3
CONNECTING YOUR MOUSE4
INSTALLING THE SOFTWARE5
MOUSE FUNCTIONS6
TROUBLESHOOTING7
3 YEAR LIMITED WARRANTY 8
FCC STATEMENT9

FEATURE DESCRIPTIONS

- Ergonomic design provides lasting comfortScroll vertically and horizontally
- · Provides pinpoint precision on most surfaces and won't wear out
- Compatible with any USB port

PACKAGE CONTENTS

- Ergonomic Dual Scroll Optical Mouse
- Software CD
- User's Manual

SYSTEM REQUIREMENTS

- Pentium 133 MHz or higher processor
- Windows® 98 SE, ME, 2000, or XP
- Mac® OS 8.5 and higher
- CD drive
- USB Port

CONNECTING YOUR MOUSE

- If you are currently using a PS/2 mouse, shut down your computer. This is not necessary if you are currently using a USB mouse. (You must **Shut down** and **turn off** your computer before connecting or disconnecting any PS/2 device.)
- 2. Disconnect the existing mouse.
- 3. Connect the USB plug of your GE Ergonomic Dual Scroll Mouse to the USB port on your computer or hub.
- 4. If you turned off your computer, turn on your computer and start your Operating System.
- 5. Move the mouse to ensure there is a good connection.

Note: Optical mice do not work well on very dark, glass or highly reflective surfaces. If your mouse does not work properly, try a different surface such as a plain white piece of paper.

INSTALLING & USING THE SOFTWARE

The basic functions of your mouse will work without installing any software. In order to take full advantage of the additional features of your GE Ergonomic Dual Scroll Mouse, you must install the software. This will allow you the option of scrolling horizontally and programming the mouse buttons. The mouse must be plugged in to use this software.

- 1. Close all open applications.
- Uninstall any existing third-party mouse software from your computer using "Add/Remove Programs" in the Control Panel. You may need to restart your computer when this is finished.
 Do not remove the standard Microsoft® mouse drivers!
- 3. Insert the included CD into your CD drive.
- 4. If the CD does not auto run, open My Computer. Double-click on your CD drive. Double-click on Setup.exe.
- 5. Follow the on-screen instructions. You will need to restart your computer to complete the installation process.
- 6. To use the software, first make sure your mouse is plugged in.
- Click on the mouse icon () to open the settings menu. It is located in your task bar on the lower right hand corner of your screen, and in the Start Menu under Programs -> GE -> 97769 Dual Scroll Optical Mouse.
- 8. Use the settings menu to program the left scroll wheel and side buttons, as well as the function of the scroll wheels.

MOUSE FUNCTIONS

- 1. <u>Standard Left Mouse Button</u> In any supporting application, click once to select files or programs or double click to open selected applications. This button cannot be programmed.
- 2. <u>Standard Right Mouse Button</u> In any supporting application, right click to select item and display a pop-up menu of common commands. This button cannot be programmed.
- 3. <u>Scroll Wheels & Button</u> In any supporting application, roll the scroll wheels to move up and down. The left scroll wheel also doubles as a third button. By default, this button activates or deactivates scroll lock. This feature allows any movement of the mouse to scroll through your document. The scroll wheel button and the functions of the scroll wheels can be programmed.
- 4. <u>Back Web Navigation Button</u> –In any supporting application press this button to go back to the previous screen. This button can be programmed.
- 5. <u>Forward Web Navigation Button</u> In any supporting application press this button to go to the next screen. Note: this function typically works only if you have used the "back" function to return to the current screen. This button can be programmed.

Note: Optical mice do not work well on very dark, glass or highly reflective surfaces. If your mouse does not work properly, try a different surface such as a plain white sheet of paper.

TROUBLESHOOTING

1. Mouse Does Not Respond

- Make sure the USB plug is securely connected to your computer or hub.
- Make sure you have installed all Windows® updates and patches for your OS. Visit www.microsoft.com
- Optical mice do not work well on very dark, glass or highly reflective surfaces. Try using your mouse on a different surface such as a plain white sheet of paper.

2. Remove the GE Ergonomic Dual Scroll Mouse Software

- Open the Start Menu. Go to Programs -> GE -> 97769 Dual Scroll Optical Mouse. Select "Uninstall Dual Scroll Optical Mouse". Follow the directions to remove the software completely.
- From the Control Panel, use "Add/Remove Programs" to uninstall "GE Dual Scroll Optical Mouse". Follow the directions to remove the software completely.

3. Other application software will not install properly This may be due to the GE Ergonomic Dual Scroll Mouse Software. Uninstall the GE mouse software. Install the required application, and then reinstall the mouse software.

If your mouse still does not work after following these steps, please contact Jasco product support at www.jascoproducts.com.

5 YEAR LIMITED WARRANTY

Jasco Products Company warrants this product to be free from manufacturing defects for a period of five years from the original date of consumer purchase. This warranty is limited to the repair or replacement of this product only and does not extend to consequential or incidental damage to other products that may be used with this unit. This warranty is in lieu of all other warranties express or implied. Some states do not allow limitations on how long an implied warranty lasts or permit the exclusion or limitation of incidental or consequential damages, so the above limitations may not apply to you. This warranty gives you specific rights, and you may also have other rights which vary from state to state. If unit should prove defective within the warranty period, return prepaid with dated proof of purchase to:

Jasco Products Company 311 N.W. 122nd Oklahoma City, OK 73114

FCC STATEMENT

Notice: Federal Communications Commission (FCC) requirements, Part 15 This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Any changes of modifications not expressly approved by the grantee of this device could void the users authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

 is a trademark of the General Electric Company and is used under license to Jasco Products Company LLC, 311 N.W. 122nd Street, Oklahoma City, OK 73114 www.jascoproducts.com