

INSTRUCTIONS:

Plug timer into GFCI protected outlet.
Choose from the following functions by rotating the selector dial:

(OFF) POWER OFF

(ON) POWER ON

(2, 4, 6 or 8 Hrs) ON at dusk, **OFF (2), (4), (6) or (8)** hours later

(DUSK-DAWN) ON at dusk, **OFF** at dawn

Not for permanent installation. Do not install or use this product for more than a 90 day period per year. When used outdoors, plug only into a GFCI protected receptacle. Receptacle should be mounted in an approved "weatherproof while in use" type outlet box.

* Timer must be mounted where accessible to sunlight for dusk-dawn features.

INSTRUCCIONES

Enchufe temporizador en el tomacorriente de GFCI protegidas.
Escoja entre las siguientes funciones haciendo rotar el selector:

(OFF) APAGADO

(ON) ENCENDIDO

(2, 4, 6 u 8 horas) ENCENDIDO al anochecer,

APAGADO (2), (4), (6) u (8) horas después

(DUSK-DAWN) ENCENDIDO al anochecer, **APAGADO al amanecer**

Este temporizador no permite una instalación permanente. No instale ni utilice este producto durante un periodo mayor a 90 días al año. Al usar en espacios exteriores, conecte solamente en un receptáculo protegido con GFCI (interruptor de circuito por falla de conexión a tierra). El receptáculo debe montarse en una caja de distribución eléctrica aprobada tipo "a prueba de agua mientras está en uso".

* Temporizador debe montarse en accesible a la luz del sol para funciones de atardecer-amanecer