

Product Name: Gigastone Wireless Charger

Trade Name: Gigastone

Model No.: GA-9100B

User's manual

60P模造
雙面單色印刷
攤開尺寸：296x 104 mm
單面尺寸：74 x 104 mm
M型折



www.gigastone.com




About GA-9100B

Contenu du colis

Chargeur sans fil GA-9100B x1
Câble USB x1
Mode d'emploi x1



Apparence



Spécification

Entrée universelle: 5.0V=1A-2A Distance de transmission: ≤ 8 mm
Entrée de charge rapide: 9.0V=2A Taux de conversion: ≥ 70%
Sortie universelle: 5.0V=1A-1.5A Dimensions: 115x115x8.5 mm
Sortie de charge rapide: 9.0V=1.67A



Instructions

1. Alimentation du GA-9100B via l'adaptateur ou l'ordinateur.
2. Si aucun périphérique n'est placé sur le GA-9100B connecté, alors la LED de celui-ci sera verte (mode veille).
3. Tout périphérique compatible avec le chargement sans fil placé sur le GA-9100B se chargera automatiquement. Cela se matérialisera sur le GA-9100B par une lumière bleue.
4. Utilisez un chargeur à charge rapide (sortie: 9V) pour charger le GA-9100B.

Précautions


1. NE touchez PAS l'appareil avec les mains mouillées
2. N'endommagez ou ne faites pas chuter le chargeur ou le périphérique en cours de chargement
3. Utilisez l'appareil à une température comprise entre 0 et 45°C. L'utilisation en dehors de ces températures peut endommager l'appareil de façon irréversible
4. Gardez l'appareil loin des ventilateurs, des liquides, de la poussière et matériaux conducteurs (ex: mine de métal et mines de crayon)
5. Ne pas laisser l'appareil à portée des enfants et animaux
6. NE PAS démonter, remodeler ou réparer l'appareil
7. Gardez l'appareil à l'écart des cartes à bande magnétique y compris les cartes de crédit, les cartes de téléphone, les carte d'embarquement que le champ magnétique pourrait endommager le dispositif

Gigastone

GA-9100B

FAST WIRELESS CHARGER

User Guide
Mode d'emploi



產品介紹

配件

GA-9100B 無線充電底座x1
USB充電線x1
說明書x1



裝置位置



規格

普充輸入：5.0V=1A-2A 傳輸距離：≤ 8mm
快充輸入：9.0V=2A 轉化率：≥ 70%
普充輸出：5.0V=1A-1.5A 尺寸：115x115x8.5 mm
快充輸出：9.0V=1.67A



使用方式

1. 通過轉接頭或電腦，為GA-9100B供電。
2. 連接GA-9100B後，在沒有放置設備的情況下，產品待機為綠光。
3. 將需要充電的設備放到GA-9100B上，充電就會自動開始。這時，LED充電指示燈就會根據相應的主題顏色變為藍光，並以呼吸燈的方式指示正在充電。
4. 由於GA-9100B支援9V快充，故請搭配支援快速充電的充電器（9V輸出）。

注意事項

1. 請勿用濕手觸碰裝置。
2. 請勿使充電器或裝置跌落，或對其造成碰撞。
3. 裝置可用於環境溫度為0°C至45°C的環境中。在建議溫度範圍外使用或儲存裝置可能對裝置產生傷害。
4. 避免讓風扇及液體、灰塵、金屬粉末或鉛筆芯等導電材質接觸。
5. 請勿讓兒童或動物咀嚼裝置。
6. 請勿拆卸、改裝或修理裝置。
7. 磁條卡，包括信用卡、電話卡、銀行存摺及登機卡，均可能會被磁場損壞。


About GA-9100B

Package Contents

GA-9100B Wireless charger x1
User guide x1
USB cable x1



Appearance



Specification

Universal input: 5.0V=1A-2A Transmission distance: ≤ 8 mm
Fast charge input: 9.0V=2A Conversion rate: ≥ 70%
Universal output: 5.0V=1A-1.5A Product size: 115x115x8.5 mm
Fast charge output: 9.0V=1.67A



Instructions

1. Power supply for GA-9100B through the adapter or computer.
2. Without any device placed, the connected GA-9100B will be green light when standby.
3. When placing the device on the GA-9100B, it will start to charge automatically. The GA-9100B will be blue light when charging and indicate the charging status in the form of breathing light.
4. Use fast charge supported (Output: 9V) charger to charge GA-9100B.

Federal Communication Commission Interference Statement
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.
This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.
FCC Caution: To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. (Example - use only shielded interface cables when connecting to computer or peripheral devices).
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Cautions

1. Do NOT touch the device with wet hands.
2. Do NOT crash or collapts the charger or device.
3. Use the device at temperature range 0~45 °C. It could damage the device if using or keeping it out of the suggested operating range.
4. Keep the device away from the fans, liquids, dust and conducting materials (ex: metal powder and pencil leads).
5. Do NOT let children and animals keep the device in their mouth.
6. Do NOT take apart, remodel or repair the device.
7. Keep the device away from any magnetic stripe cards including credit cards, telephone cards, bankbooks and boarding pass that the magnetic field could damage the device.