

# The Jingle Ball

 **Bluetooth** WIRELESS SPEAKER

## Support

If you are having problems with your product, please contact customer support before contacting your retailer.

## Warranty Statement

life made warrants this product against defects in workmanship and material for a period of 12 months from the original date of purchase. If the product fails during normal and proper use within the warranty period, life made will repair or replace any products or parts determined to be defective in workmanship or material at its option. All components repaired or replaced by life made' service site will be under warranty for the remaining period of warranty.

This Limited Warranty covers only the accessory components packaged with this product. This Limited Warranty does not include failure caused by improper installation, operation, cleaning or maintenance, accident, damage caused by extreme temperature, humidity or extreme electrical stress, misuse, abuse unauthorized modifications to the product, software faults ,normal wear and tear or any other event, act, default or omission outside of life made' control or if the serial number has been defaced, altered or removed and the casing has been opened.


To obtain warranty service, please contact life made for specific instructions at the email below. Dated, documented proof of the original purchase is required.

## Operation:/To Charge:

- Insert the USB end of the charging cable into a computer or USB wall charger (not included).
- Insert the Micro side into the Micro USB port located on the back of the Jingle Ball.
- Charge for 2 hours for a maximum battery charge.

## Playing the music from your Bluetooth device:

- On your Smartphone or Tablet navigate to the Bluetooth menu.
- Turn ON by pressing and holding the Power Button for more than 3 seconds. A voice will sound “The Bluetooth Power On” indicating the Jingle Ball is ready to pair.
- Select the “Ornament Speaker” on your devices Bluetooth menu, “Bluetooth Connected” sound means the pairing is successful. Now you can enjoy your music.
- To control volume, select tracks, play/pause you must use the controls located on your Smartphone or Tablet.



## Troubleshooting:

- If no power, please recharge the Jingle Ball.
- If no sound, please adjust volume on your tablet, phone... make sure that they are within the effective operation range.
- If no response from the speaker, please restart it.

## Product Functions & Features:

- It is quick and easy to connect with your Bluetooth devices such as tablets and smartphones... play the music you want.
- A voice will warn you when the Jingle Ball connects successfully with your Bluetooth device.
- The Jingle Ball supports hands free calling.
- Power supply: with built-in 450mA lithium rechargeable battery inside. USB + Micro cable charging 2 hours, more than 3 hours playing...

## Specifications:

- Power supply: DC5V, 500mAH.
- Rated Output power: 3W.
- Built-in Lithium battery: 3.7V, 450mAH.
- Battery charging time: about 2 hours.
- Battery working time: >3 hours.
- Dimension:  $\phi$  70MM.
- Bluetooth version JL 2.1.
- Working distance is about 10M.
- Materials: ABS housing, electroplate on the surface.

## Accessories:

- Quick Start Guide x 1
- USB Cable x 1
- Hanging Hook x 1
- Hanging Ribbon x 1

## FCC Certification Requirements

Caution: Any changes or modifications in construction of this device which are not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the Receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.