

Golf Buddy *VOICE*


Quick Start Guide

Golf Buddy VOICE





Thank you for choosing GolfBuddy.
GolfBuddy Voice provides golf course information for you to ensure you
enjoy the very best golfing experience.

■ Quick Overview of your GolfBuddy



■ Screen Description



- 1 **07** Hole No.
- 2 **M** Meter (Yardage when not shown)
- 3  Front/Center/Back of the Green
- 4 **157** Remaining distance to the Green
- 5  Battery indicator

■ Getting Started

Plug the data cable to the power adapter to charge the unit.

Visit our website (www.gpsgolfbuddy.com) and check your course in our “course library” and download if necessary.

Please refer to the GB manager for the latest course and firmware updates.


Basic Operations

■ Power On/Off

Once you're at the course, simply power on to start playing as the unit will locate your course for you automatically.




■ Language Selection

Have the unit turned off. While holding down the  button, turn on the unit to bring up the language selection.


Use the   buttons to select your language.




■ Main Button Operation


Pressing the  main button gives you the voice information of the current screen.

■ Voice Information of the Distance to the Green

Pressing the  button will give you the distance to the center of the green.



Press  button once: Voice information to the center.

Press and hold  button: Voice information to the front.

Press and Hold  button again: Voice information to the back.

■ Switching to the Alternate Green



Press and hold the  button while on the play screen.

■ Changing the Distance Unit (Yard/Meter)



Press and hold the  button while on the play screen.



■ Volume Control



Use the   buttons to control the volume.


■ Mute



Press the   buttons at the same time to mute.



Advance Operations


Green View Screen


Pressing the  button gives you the green view screen. The green shape changes as you move to the different sides of the green. The screen also provides the hole number, par information, and left/right green information.







Measuring Distance

Press the  button then press and hold the  button for 3 seconds to start measuring.

Once you have arrived at the desired location, press the  button to finish measuring and you can view the measured distance.





Changing Holes

Press both the  button and the  buttons at the same time to bring up the hole selection. Then use the   button to change to the desired hole.



Time Setting.

Press and hold the  button to see the current time. Press and hold the  button to set the time.



■ What's included



GolfBuddy Voice



Power Adaptor



USB Data Cable



Silicon Case



Quick Start Guide

www.gpsgolfbuddy.com