

Caution:


This device complies with part15 of the FCC Rules. Operation is subject to the following two conditions:(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note:

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

INSTALLATION


1. Locate the camera to a specific position and then adjust it to a suitable angle.



2. Connect the adapter (DC 8V 200mA) to the camera.



3. Connect the antenna to the receiver.



4. Connect the receiver to a monitor/TV with AV cable (yellow for video and red for audio).




5. Connect the adapter (DC 12V 300mA) to the receiver.




6. Push the power switch to **ON** position and the channel indicator lights up.



7. Power on the monitor/TV and select **AV** mode.



8. Set the channel of receiver same as that of camera by pressing the channel button continuously, and the pictures are displayed on the monitor/TV.



9. Adjust the brightness, contrast and color of the monitor/TV for the perfect effect.

