


GRADO

Handband Bluetooth Headphones

Grado GW100 Owner's Guide

Overview



Power / Action

Volume Up / Action

Volume Down / Action

Charging Light

Line-In

Mic

Charging Port



Power



Long Press: Power On / Off

Battery Saver: If unpaired for 10 minutes, GW100 will power off.



● **Blue:** Fully Charged



● **Blue:** Powered On



● **Red:** Charging



● **Red:** Low Battery



Charging: Plug the USB Type-C cable into the charging port and connect the other end to a compatible USB port of a computer or wall charger.



Connect



Long Press: From the off state press and hold until charging light flashes blue and red.

On your device, navigate to settings and turn on Bluetooth.

After a few seconds, you will see "Grado GW100". Tap to pair.

When the paired device's Bluetooth is turned off or out of range, the GW100 can connect to a second device.



Blue & Red: Ready to Pair



Volume / Music



Short Press: Play / Pause



Short Press: Increase Volume

Long Press: Next Song



Short Press: Decrease Volume

Long Press: Previous Song



Phone / Voice



Short Press: Answer / Hang Up

Long Press: Reject Call

Double Press: Voice Assistant



Short Press: Increase Volume



Short Press: Decrease Volume



Specifications

Bluetooth Version: 5.0 with aptX

Working Distance: 10m

Battery Life: 50 hours*

Charging Time: 2.5 hours

Frequency Response: 20Hz~20KHz

Mic Sensitivity: 42dB +/- 3dB

Battery Capacity: 850mAH

Methods of pairing to Bluetooth may vary depending on the specific device. Please refer to the device's manual for further details.

*Battery life will vary depending on the listening volume and genre of music played.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help



Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part

15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.