


# USER MANUAL



4000375

## BLUETOOTH SPEAKER

### FEATURES

Thanks for your purchase of our product. Please read through this manual before making connections and operating this product. Retain this manual for future reference.

- Blue tooth playback
  - AUX input
  - Power supply: DC-5V
- Note: ● Use DC adapter or USB terminal to charge battery no matter the player power on or off.
- In low battery status, the speaker will alert you with beep sounds, the unit will switch off automatically if no charged in low battery status.
  - Power consumption: 5W
  - Speaker max output: 2WX2

### PRECAUTION

- Do not drop any objects into the unit through the openings.
- Do not spill or spray liquid of any kind on or in the unit. It may result in a fire or electric shock.
- Do not place anything heavy on the unit.

-1-

- To ensure proper ventilation and proper operation, never cover or block the slots and opening with a cloth or other materials.
- Keep the unit away from an open flame such as fire, candle, etc.
- Install the batteries correctly.
- Please dispose the batteries according to the local rule and law.
- The maximum working temperature is 35 degrees Celsius.
- Only use attachments/accessories specified by the manufacturer.
- Where the Mains plug is used as the disconnect device, the disconnect device shall remain readily operable.
- Rating label are on the bottom of the unit.

**WARNING:** The batteries shall not be exposed to excessive heat such as sunshine, fire or the like.

**CAUTION:** Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.

**Warning:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.


-2-

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

-3-

### PANEL



- |               |                        |
|---------------|------------------------|
| 1. VOLUME+    | 5. NEXT                |
| 2. PREVIOUS   | 6. MICROPHONE          |
| 3. VOLUME-    | 7. BLUETOOTH INDICATOR |
| 4. PLAY/PAUSE | 8. CHARGING-INDICATOR  |
- /HANDS FREE



1. POWER ON/OFF
2. DC IN 5V
3. AUX INPUT

-4-

### PREVIOUS

- When the player is in working mode, press to return to the previous track;

### NEXT

- When the player is in working mode, press to skip to the next track;

### VOLUME-

- When the player is in working mode, press to turn down the volume.
- The minimum volume is near in silence.

### VOLUME+

- When the player is in working mode, press to turn up the volume.
- You will hear the beep sound when you turn up to the maximum volume.

### PLAY/PAUSE/HANDS FREE

- When the player is in working mode.
- Press to temporarily pause a playback; press it again to resume the playback.
  - Press this button to answer the phone call in hands free when there is a phone call in.
  - Hold down this button for 3 seconds to disconnected the bluetooth connections, the speaker will turn to searching other

-5-

matching bluetooth device when you hear beep sounds.

### INDICATOR

- When the red indicator and the blue indicator flashing alternately, the player is in searching bluetooth signal status.
- The red indicator keeps lighting when the player connected the previous bluetooth device, if the previous bluetooth device not in the sevice areas, the player will return to searching status after 20 seconds.
- The blue indicator keeps flashing once per second means bluetooth was connected, and the model of the player will shows on mobile phone.
- It is better to switch off the unit before charging. The charging-indicator changing from red to light off indicates that the battery has been fully charged.

### AUX IN

- This player has an extra group of audio input terminals. You can input the analogue Stereo audio signals from extra devices such as mobile phone, computer, MP3 player, etc.
- Use the audio cable to connect the audio

-6-

output terminals of mobile phone, computer, MP3 player to the audio input terminal (AUX IN) of this player.

- When the player connect the AUX input terminal, the player will disconnect the bluetooth connection automatically.
- When the player disconnect the AUX input terminal, the player will return to the previous bluetooth connection.
- When the player connect the AUX input terminal, [VOLUME], [PREVIOUS] and [NEXT] buttons are only control by the extra devices.

### BLUETOOTH CONNECTION

- The model of the unit is BL1602, power on the unit then use your mobile phone to search the bluetooth signal of the unit, the unit will synchronize play songs on your mobile phone while they connected successfully.
- The blue indicator keeps flashing once per second when the player in working mode.
- The player need to input the password 0000 when the matching blue tooth device under version 2.1.
- When the operation too frequently or other reason to disturb the bluetooth reconnected, please use manually connect on the bluetooth device.

-7-