

Portable Bluetooth^e Speaker



Package Contents Bluetooth Speaker USB Charging Cable User's Guide eatures

Play your music wirelessly up to 30 feet (9.14m) away
Make and receive hands-free calls
Play a non-Bluetooth device through the speaker

Specifications
Battery Charge Timeapprox. 2 hou
Operation Time
Frequency Response 150Hz - 15k
Output Power
Impedance 4oh
S/N ratio ≥ 65
Battery charging voltage
Driver
Bluetooth protocolV3.0+El



- Pairing/Charging Indicator

 Flashes blue when searching for a
 Bluetooth device.

 Flashes blue ever 2 seconds when the
 speaker is paired with a Bluetooth device.

 Lights red when charging: indicator tums
 off when fully charged.

Charge Your Speaker Charge your speaker when the speaker

Connect the USB plug of the supplied

- Connect the USB plug of the supplied charging cable to the USB port of your computer or any USB charger.
 Connect the cable's micro USB plug to the speaker's DC 5V jack the indicator lights red when charging and turns off when fully charged.
- Unplug the charging cable when the speaker is fully charged.



Use Your Speaker

Pairing Bluetooth devices

- Turn on the speaker, the indicator flashes blue. Your speaker searches for Bluetooth devices.
- Follow the instructions for your Bluetooth device to pair it with the speaker. After successful pairing, the indicator flashes blue every 2 seconds.
- Use the playback controls on the speaker or your audio device.

4. Turn off the speaker after using.

Note: You can download Auvio EO App for free from the App Store® and Google Play to customize your calls and music. Enter password 0000 for Bluetooth connection if your device uses Android® 2.1 or below?

Connect with AUX IN

- Connect with AUX IN

 1. Connect an audio cable not included)
 to your audio device, then connect to
 your speaker's AUX IN jack.

 2. The speaker will play your audio
 source and disconnect the Bulstooth
 connection automatically.

 3. Use the playback controls on your
 audio device.

- Unplug your audio device, the speaker will return to the previous Bluetooth connection.

FCC Information

- nchaise the separation peroves we exclude: cecivier. Connect the equipment into an outliet on a sircuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV sechnician for help.

Limited Warranty
Ignition L.P. warrants this product against defects in
materials and workmarchip under normal use by the
original purchase for insisty (90) days after the date of
purchase. IGNITION L.P. MAKES NO OTHER EXPRESS
UMPRANTES.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

For product support, call 1-866-315-0426