


vtrek

USER MANUAL



WC 603

Classroom Bluetooth Speaker

Contents

Features	2
For your Attention.....	3-4
Panel.....	5-6
Connections.....	7
Trouble shooting.....	8
Specifications.....	9


Features

Thanks for your purchase of our product. Please read through this manual before making connections and operating this product. Retain this manual for future reference.

- Bluetooth playback
- AUX input

Package Contents:

User manual



DC adaptor



For Your Attention

IMPORTANT NOTES:

- Please read through this manual before making connections and operating this product. Retain this manual for future reference.
- Don't open the cabinet of this unit. No user-serviceable parts inside. Refer servicing to qualified personnel only.
- Switch off the unit when you don't use it. Switch off the unit and disconnect it from the AC power supply when it is not being used for a long time.
- Don't install the unit in a place exposed to heating sources or direct sunshine.
- Don't install the unit in a place exposed to moisture or rain.
- The apparatus shall not be exposed to dripping or splashing and any object filled with liquids, such as vases shall not be placed on it.
- Install the unit on a horizontal, flat and firm surface with good ventilation. Never block the vents which will cause malfunction resulted from overheating.
- Use a soft and clean rag to clean the outside of the unit. Never clean it with chemicals or detergent.
- This book is only a guide for user's operation, not a criterion for configuration.
- Only use attachments/accessories specified by the manufacturer.
- Where the mains plug is used as the detachable device, the detachable device shall remain readily operable.

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 - (1) This device may not cause harmful interference.
 - (2) This device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

For Your Attention

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.


- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body

Panel

FRONT PANEL:



1. VOLUME+/-

- Press to turn up/down the volume;

2. STANDBY/SOURCESELECT

- Press to switch on the unit;
- Press repeatedly to select a signal source between Bluetooth or AUX input mode;

3. PLAY/PAUSE

- Press to temporarily pause a playback; press it again to resume the playback;

4. PREVIOUS/NEXT

- Press to return to the previous track or skip to the next track;

(Note: All the button on the front panel are touch keys)


5. STANDBY (red indicator)

6. BLUETOOTH (blinking blue indicates pairing, solid blue indicates connected)

7. AUXIN (yellow indicator)

Panel

REAR PANEL:



1. USB CHARGEPORT (5V)

(Note: ● Use the USB cable (not included) to connect the USB and charge device. The charge port cannot charge battery in standby mode.

● There is no connection with the speaker after 10~15 minutes (no AUX input, USB charge or bluetooth connection), the speaker will turn to standby mode automatically and the red indicator light will illuminate. Press [PLAY/PAUSE] to wake up the speaker.

● The speaker will turn to auto standby mode after about 10~15 minutes.

● The unit cannot play music via USB charging port.

2. AUX INPUT

3. DC IN (10V)

4. POWER ON/OFF


Connections

AUX IN

This unit has an audio input terminal.
Use the audio cable(not included) to connect the input terminal **AUX IN** on the rear panel of this player, press [SOURCE SELECT] button on the front panel to switch to the AUX IN mode, the indicator on the front panel indicates in yellow that the player has been switched to AUX IN mode.

Bluetooth Connection

The model of the unit is WC 603,press [SOURCE SELECT] button on the front panel to switch to the corresponding signal source, use your mobile phone to search the bluetooth signal of the unit, then input the password 0000, the unit will synchronize to play songs on your mobile phone while they connected successfully.
Disconnect the bluetooth on the mobile phone to switch off the bluetooth connect.
Once the bluetooth is connected to your audio device successfully for the first time, you can power off the player then power on. The speaker will reconnect automatically.Press [PLAY/PAUSE] to resume the playback.
Note:●Bluetooth connection range is 30 feet.
●The model WC 603 in your device was not deleted.
●In bluetooth mode,[PLAY/PAUSE],[NEXT],[PREVIOUS],[VOLUME+/-] etc. are also active.



Troubleshooting

Before resorting to maintenance service, please kindly check by yourself with the following chart.

Symptom	Cause(s)	Remedy
No Power	● The DC power cord is not connected to the power supply or is not connected to a power supply securely.	● Please check that the DC power cord is connected securely.
Sound There is no sound or the sound is distorted.	● The volume is set to the minimum level. ● Audio device is not connected to the unit.	● Turn up the volume. ● Connect audio device via Bluetooth or Aux in.
The buttons on the unit do not work.	● The unit is being interfered with static electricity etc.	● Switch off and unplug the unit. Then connect the plug to the power supply and switch it on again.

Specifications

Power supply		DC 10V 1.5A
Power consumption		15W
Working environment	Temperature	-10~+35℃
	Relative humidity	5%~90%
Speaker output (Max)		5WX2

