

OSD User Manual

Version: V1.0

Model: A3105A(main board B.S905.5)

Description: Android Main Board

Contents

Safety Warning

1.1 Welcome page	4
1.2 Setup page	4
2.1 Main Launcher	5
2.2 Settings	9
2.3 Applications	11

Safety Warning

Before operating the unit, please read through this manual.

PLACEMENT

- Do not place the unit on an unstable cart, stand, tripod, bracket, table, or shelf.
- Do not expose the unit to direct sunlight and other sources of heat.
- Do not handle liquids near or on the unit.
- Never spill liquid of any kind into the unit
- Do not put the unit near appliances that create magnetic fields.
- Do not put heavy objects on top of the unit.

TEMPERATURE

- Do not place the unit near or over a radiator or a heater register.
- If your unit is suddenly moved from a cold to a warm place, unplug the power cord for at least two hours so that moisture that may have formed inside the unit can dry completely.

HUMIDITY

- Do not expose machine in rain, damp or place near water.
- Ensure the indoor drying, cool.

VENTILATION

- Keep the ventilation openings clear.

1.1 WELCOME PAGE

When the Androi d Box is first powered up,Welcome Page will be shown .

It will help you to co nfigu re th e d evice.



+Reminder


If you want to skip this wizard,

press “HOME” key

If you have finished this wizard
once, it will not auto-open again.

1.2 Setup page

Select Language:



Select network type:



+Reminder

If you do not want to choose your

network ,you can skip this step by press

“Skip”,You will also find the network settings
in function “Settings”

Select Wireless network(Wi-Fi)



+Reminder

If choose 'Wi-Fi', select a Wi-Fi


Access Point

If choose 'Ethernet' ,the screen will
show Ethernet connection status

Select Ethernet network(LAN)



Configure Ethernet manually




Set up the correct Time Zone




+Reminder

If network is not connected, setup the
date and time manually

Setup Date/Time manually



Date/Time



Configuration



Adjust screen size, using the arrow buttons on remote control






+Reminder

User can setup the Language, Network, Time Zone, Data/Time, and adjust screen size in this part

2.1 Main Launcher


Press the arrow buttons **◀/▶** to select the sub-screen and press **▼** into sub-screen.





FUNCTION	DESCRIPTION
	Main Launcher tab contains : Time information(You can set time information at settings) ; USB/Ethernet/Wifi function status(White for working, gray for standby)
	All App menu can view and select more apps.
	The Browser tab contains bookmarks and search bar. It allows you enjoy your time on surfing Internet. You can search for information and watch online TV etc.

FUNCTION	DESCRIPTION
	Add you favorite APP to this directory.
	The Settings screen contains most of the customizing and configuration options, such as language, aspect ratio and network settings.
	Create necessary APP shortcuts to the main launcher.

2.2 Settings

FUNCTION	DESCRIPTION
Wifi-settings 	Check to turn on Wi-Fi so can connect to Wi-Fi networks Check to receive an alert when an open Wi-Fi networks becomes available Opens a dialog where you can add a Wi-Fi networks by entering its SSID(the name it broadcasts) and security type
Ethernet 	Turn on/off the Ethernet Ethernet settings: IP address , Subnet Mask, DNS Server, Default Gateway and etc
Bluetooth 	Turn on/off the Bluetooth
Advance settings 	Contains all of the settings
Factory reset 	Restore factory default
City 	Set city

Language & input 	Select language Android keyboard
System updates 	Local update Update system via update.zip from USB flash drive or micro SD card Net update OTA network upgrade
Date & Time 	Automatic date & time (Need network) Set date Set time Select time zone User 24-hour format Select date format : dd/mm/yyyy ; mm/dd/yyyy ; yyyy/mm/dd
About device 	Android version Build number

2.3 APPLICATIONS

Install from USB Flash Drive

1. Open the “File Browsers”
2. Choose your USB flash drive or any other mass storage’s folder
3. Find your application, and press it
4. Press the install button
5. You can find the application in tab “Apps” after installation

Download & install from Browser

1. Open the Browser.
2. Press search key and input your website address
3. Download the APK file which you like if there is a link for download

(If you have problems with downloading, please make sure there is enough space in your internal storage)

Install from AppInstaller

1. Open the AppInstaller
2. Find the icon of the application, and enter it
3. Press the install button
4. You can find the application in tab after installation