# User Manual

Factory Default

Version V5.8

Introduction

This is a easily usemanualfor laser barcode scanner , if you need the moredetails about how to use ,please download from our official website or get the manual from distributors.

Installation

### ▣ keyboard wedge cable install

keyboard wedge cable install

▣ USB Cable install (put the cable insert the USB serial directly, The Computer will detection and identification automatically

▣ Accessories: Bracket install

1. Use the bracket connector connect to the main body of bracket.
2. Main body of bracket.
3. Philip's screw, Dimensions:M6*10MM
4. Base Support
5. Direct wedged in the base of bracket when the head of bracket and main body connection well.

DATA Interface Choose

USB-HID Model*****

Ps2-Keyboard Model

USB-COM Model

COM-RS232 Model

Scanning Type

Automatic successive scanning model

Automatic flashing mode

Buzzer

Sound OFF

Sound ON

Barcode Display Tybe

Display barcode type after barcode

UN-Display type after barcode

Keyboard Model

Language Choice

||||| USA

||||| German

||||| France

Keyboard Caps Lock control

||||| None

||||| Capitalize

||||| Lower case

Serial Model

Baud Rate

||||| 4800

||||| 9600

||||| 19200

||||| 38400

||||| 57600

||||| 115200

Prefix&Suffix Setting

||||| AddPre

||||| AddSuff

||||| Hide Before Character

||||| Hide After Character

Special Code ON

||||| CODE11

||||| CODE 39

||||| FULL ASCII

||||| CODE 93

||||| CODE 128

||||| CODE 128ISBT

||||| CODEBAR

||||| Enable Interleaved 2 of 5

||||| Industral 2 of 5

||||| Matrix 2 of 5

||||| CHINA POST CODE

||||| MSI CODE

||||| UPC-A

||||| UPC-E

||||| EAN-13

||||| EAN-8

Suffix & Skip Setting

||||| CR

||||| LF

||||| CR&LF

||||| Tab

||||| Space

||||| None

Wireless Setting

||||| RF Model

||||| Delet ADD

||||| Setting DeviceADD

||||| 01 ||||| 02

||||| 03 ||||| 04

||||| Pairs ADD

||||| Inventory Mode

||||| Up lodaing New Date

||||| Up lodaing ALL Date

||||| Up loading Statistic Date

||||| Reset

Federal Communications Commission (FCC) Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

●Reorient or relocate the receiving antenna.
●Increase the separation between the equipment and receiver.
●Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
●Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications made to this device not expressly approved by **Guangzhou Xunbao Electronics Technology Co., LTD** may void the FCC authorization to operate this device.

Note: The manufacturer is not responsible for any radio or tv interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.