

Bluetooth Speaker

User Manual

一: FEATURE

Portable multimedia mini Bluetooth speaker (calls answer, hands-free)

二: KEY FUNCTION SPECIFICATION

1: Power on/off: hold 3'Sec “▶||”

2: Bluetooth connection:

Previous: press “←”

Next: press “+”

Volume up: hold “+”

Volume down: hold “←”


Play/ pause: press “▶||”

When calls in:



Answer: press “▶||”

Refuse: hold 2'Sec

Dial back: Dbl-click “▶||”



1. Volume up/ Next song
2. Play/pause/calls answer
3. Volume down/previous
4. Microphone
5. USB input



三: BLUETOOTH OPERATING SPECIFICATION

1. Hold 3'Sec “ ” to Bluetooth mode, you will hear “do-do-do” sound, the blue indicator blink rapidly. That means it has been in the Bluetooth Mode.
2. After switching to Bluetooth mode, the speaker enters into re-connect mode automatically. If it can not connect to the device or cannot search the device connected before, it will enters into pairing Mode.
3. According to the instruction of your cellphone to search Bluetooth device. Then build up the connection of Bluetooth speaker and cellphone. When you hear a connected “do” sound and the blue indicator blink slowly, it means connects.
4. After connecting, it can be play/pause/previous song/next song/volume up/volume down/answeringcalls.

四: INDICATOR OPERATING SPECIFICATIONS

1. Bluetooth Pairing Mode: blue indicator blinks quickly Bluetooth; connection: blue indicator blinks slowly.
2. When charging: red indicator flash-es up; Full charge: red indicator off.

Portable Mini Speaker User Manual

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.