



BT188

Introduction

Thank you for purchasing this product. You can use this item with iPads , iPhones, iPods and many types of smartphone to stream music, and enjoy handsfree calling. In order to get the best results when using the device, please read this manual first before using.

Features&Specifications

Features:

Soothing sound quality
Built-in Mic for hands-free calling
TWS Technology - Connect 2 speakers wirelessly and play as 2.0 Speaker
IPX6 Water Resistant standards
Multiple Playback Options – BT | TF CARD | AUX
Volume and Multimedia button functions
Play music wirelessly from any BT enabled devices
Convenient carry strap

Specifications:

Bluetooth version: 5.0
Loudspeaker: 4Ω / 10W
Built-in battery: 7.4V, 2500mAh
Dimensions: 190*86*68 mm

SNR: >80dB

Bluetooth Frequency: 2.402-2.480 Ghz
Wireless Transmission Distance: up to 10m
Charging time : Approx. 6 hours
Working time: Approx. 5 hours(50% volume)
Weight: 0.6kg
Speaker dimension: 45 mm
Charging: 5 V, 2A



Controls

Power On / Off / Mode | Volume- / Previous Track | Volume+ / Next Track | Play /
Pause / Call / TWS

Inputs

BT | TF CARD | AUX

Package contents



Speaker-----1pc
Charging cable-----1pc
AUX cable-----1pc
User manual-----1pc

Important Safety Precautions


When using your Bluetooth Mobile Speaker, basic safety precautions should always be followed, including the following:

- Keep this product and its accessories away from excessive heat.
- Do not operate this device with a damaged cable or after it has malfunctioned or has been damaged in any manner.
- No sharp object should be subjected to the speaker/speaker-drivers as it may damage the speakers.
- Only use a soft cloth, no harsh abrasives or chemicals to clean, as it may damage the surface finishing.
- Ensure the speaker is waterproof by removing all the connected cables and the cap is tightly closed before exposing the speaker to liquid.
- Do not expose the speaker to water while charging, as doing so may result in damage to the speaker or

the power source.

- IPX6 - Protection assured against light splashing of water. Must not immerse in water.

A Quick Look At Your Speaker



1. Power On/Off/Mode: Long press to power On/Off. Single press to change mode.

2. Prev / Vol - :

MSD/BT mode: Single press to decrease volume and long press to select previous song.

AUX mode: Single press to decrease volume.

3. Next / Vol + :

MSD/BT mode: Single press to increase volume and long press to select next song.

AUX mode: Single press to increase volume.

4. Play/Pause/Call:

Single press to play/pause in MSD/BT mode and mute/unmute in AUX mode. Long press to disconnect with existing BT connection.

Call functions – Single press to rec/end a call. Double press to redial. Long press to reject incoming call.

TF card Slot: To connect TF card as source input

AUX Slot: To connect AUX input

5V DC: To charge the speaker using given charge cable

Operations:

Powering ON/OFF


Press and Hold "ON/OFF" button 3 seconds to power on and power off.


Pairing

The unit will automatically go into Pairing Mode when it is powered on, the LED light will be blinking in blue to indicate that you have entered pairing status. Go into your Bluetooth device settings menu and look for "BT188", once paired, the blue LED light will stay illuminated in blue and you can use your units to listen to audio from your Bluetooth sound source. Press and hold the Bluetooth button to disconnect the Bluetooth.

Making and Receiving Phone Calls

When the unit is connected and paired to your device, the unit allows you to make or receive phone calls with its built-in microphone

Press "  " shortly to accept and end a call.

To reject a call, press and hold "  " 2 seconds.


When using both units, you must only do this on the master(left) unit.


Aux-In Mode


Plug in the supplied 3.5 mm cable into the unit. The other end is connected to your device. The green LED will stay illuminated. It means in Aux-in mode.

Please note music can be controlled by your device.

In Aux Mode

Press shortly "  " to increase the volume

Press shortly "  " to lower the volume


Press shortly "  " to mute AUX function


TF card Mode


Plug in TF card into the unit. The green LED will stay illuminated. It means in "TF card" mode.

Please note music can be controlled by your device.

In TF card Mode

Press shortly "  " to increase the volume

Press shortly "  " to lower the volume

Press shortly “  ” to mute TF card function

Note : When in TF card mode, press “  ” to enter into Bluetooth mode

TWS function

The units are intended to be linked together so as to experience True Wireless Stereo sound via Bluetooth.

1. First make sure that the units do not have an active Bluetooth connection with a mobile device.
2. Power on both units, press the play/pause button on one of them to initiate the automatic pairing mode between the two units, the master(Left) unit LED blink blue when pairing, there is tone after TWS paired.
3. After slave(right) unit paired, the master unit will blink blue, the slave unit will glow yellow.
4. The master unit connected with the mobile device, both the master and slave units stay illuminated in yellow.
5. Playback function remain accessible in either unit, phone commands, however, they are available only through the master(left) unit.

Unpairing both speakers

To un-pair both the speakers, long press Play/Pause button, both the speaker will break the connection between them and both will be available for individual connection in BT mode and we can use them as two separate speakers.

Charging Instructions

1. Please use the package provided charge cable for charging this speaker.
2. The Red LED indicator indicates the battery charging status. The LED will stop glowing once the speaker gets charged completely.
3. Charging time may increase if music played and kept for charging simultaneously.
4. Suggest to charge each 3 months for the units if product out of service for a long time.

LED Indications

MSD mode – Green LED Constant

AUX mode – Green LED Constant

Bluetooth pairing mode – Blue LED Blinking

Bluetooth paired mode – Blue LED Constant

Charging – Red LED Constant

TWS paired mode – Master Speaker will Blink Blue and Slave Speaker will glow yellow.

TWS paired with BT Device – Master and Slave Speaker will glow yellow.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.