

## Instruction Manual


Welcome to choose my company product Bluetooth audio magic sound box. The product is a portable audio with Bluetooth receiver. You can store the songs in mobile phone or device with Bluetooth playback, and then transmit to this product for music playback via Bluetooth.

Read the instruction manual quickly before use.

### Main Features & Technical Parameters

1. Bluetooth audio player
2. Stereo speaker
3.  $\Phi 3.5$ mm Audio input interface
4. 7 sensor touch keys
5. Audio maximum power: 2W\*2
6. Frequency response: 20Hz-20KHz
7. Power supplied: Built-in rechargeable lithium battery
8. Connect external USB 5VDC power source to charge product
9. Charging time of about 3 - 4 hours
10. Continue play music about 2-3 hours when built-in lithium battery is fully charged
11. LED panel backlight with Bluetooth indicator, audio indicator, full power indicator, power charge indicator

### Product Illustration



### Function of the Keys

Key Name	Operation Mode	Functional Description
----------	----------------	------------------------

Power Switch	Turn on or off the main power	Main power switch
Power Key	Long sensor touch to turn on or off	Product in switch on or standby mode
Switch Mode Key	Sensor touch during music playback	Switch between Bluetooth and audio input source, corresponding indicator light will be lift up
Track Backward	Sensor touch during music playback	Bluetooth playback previously track
Play/Pause	Sensor touch during playback or pause	Continuous Bluetooth playback music or pause music playback
Track Forward	Sensor touch during music playback	Bluetooth playback next track
Volume +	Sensor touch	Increase one Bluetooth volume level
	Long sensor touch	Increase Bluetooth volume level continuously and a prompted sound when reaching max. volume level
Volume -	Sensor touch	Reduce one Bluetooth volume level
	Long sensor touch	Reduce Bluetooth volume level continuously

### Bluetooth Playback

1. Push the power switch to "ON" position, long touch power key to turn on this sound box, panel backlight on and produces a sound, reminder Bluetooth indicator light flashes quickly.
2. Turn on Bluetooth function in mobile phone or Bluetooth device; search the equipment in the Bluetooth menu.
3. When "Hiting" appear on Bluetooth equipment list, select "Hiting" to establish pairing and connection (if pass code requested, enter 0000). When the pairing and connection is

successful, this product will be produced a sound reminder, the Bluetooth indicator flashes rapidly become slow flash, you can use this product to playback your device's music.

4. If the pairing timeout or the Bluetooth indicator stops flashing, repeat steps 1-3 for pairing connection.

### Audio Input Playback

1. Touch the switch mode key(M) to switch the audio source to the audio input playback status, audio indicator light on.
2. Connect the audio cable between the audio input jack and MP3, iPod, cell phone or other audio source, playback audio source music, adjust the volume level of the audio source output to achieve the optimal sound.

#### Remark:

When audio input playback, the keys of Track backward, Track forward, Play/Pause, Volume +, Volume - are no function. Use the control keys from your audio source.

### USB and built-in rechargeable lithium battery power supply

1. Use USB power cable to connect product's USB power jack and computer or DC5V power adapter for power supply and charging the built-in rechargeable lithium battery synchronously, the power charging indicator light on at this status, and the full power indicator light on when battery full charged.
2. When the product have no power supplied by USB power, it will supplied by built-in rechargeable lithium battery.

### Troubleshooting

Failure Manifest	Solution
Bluetooth playback interrupt and produced "du du" sound	The battery is too low, please charge.
Music intermittent in Bluetooth playback	Try to move the Bluetooth device close to product or change the audio or equipment location.

Equipment cannot pair with Bluetooth audio connection	Charge the battery if it is too low.
	Move the Bluetooth device close to product.
	Switch off and restart the product to wake it up.
	Check the device or computer has Bluetooth function or not? Repeat this product's Bluetooth playback setting steps.
Touchkey failure	This product only playback one device music per time, the cancelled device and not use pairing (please see the device documentation for assistance), need to pair new device in accordance with the setup steps.
	If it is paired with the computer, specify "Hiting" for portable audio as the computer's audio output device.
Speaker volume too low	Charge the battery if it is too low.
	Move the Bluetooth device close to product.
	Touch "Volume +" key to appropriate level.

### Package Contents

1. Each 1pc of USB power cable and audio cable.
2. 1pc of power adapter (optional).
3. Instruction Manual.

### Caution:

1. The product avoids rain and damp, in order to avoid damage.
2. The product should be kept away from fire, high temperature environment to avoid the product does not work normally and explosion.
3. Do not use the hand touching the speaker or impact with other objects to avoid damage.
4. Use DC5V power supply with current output 1A above.
5. Switch the power to "ON" position when you stop playing for saving energy power.
6. When disposing of this product's rechargeable lithium battery, classification recycling if possible to avoid environmental pollution.
7. It is recommended the battery is fully charged when first time use the product.

#### FCC Certification Requirements

Caution: Any changes or modifications in construction of this device which are not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following

two conditions: (1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.