


BLUETOOTH MP3 WATCHUSER MANNAL

IMPORTANT INFORMATION REQUIRED BY THE FCC

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

I. Definition of Bluetooth MP3 Watch Key



II. Overview of Bluetooth Earphone Key



III. Components of Products

1. Bluetooth MP3 Watch	1
2. Bluetooth Earphone	1
3. Chargers for Watch and Bluetooth Earphone	1
4. Manual	1
5. USB Line for Watch	1
6. Charger Line for Bluetooth Earphone	1
7. Warranty Card	1

IV. Technical Character of Bluetooth MP3 Watch

Memory:	128MB-2GB FLASH Memory inside
USB Connection:	9H USB Connector Line Inserted
Power:	Build-in rechargeable 3.7V polymer lithium battery
Using life of Battery:	4Hours each time after completed charging
USB transmission Speed:	USB1.1
MP3 Bit:	32Kbps-320Kbps
WMA Bit:	32Kbps-192Kbps
Recording spot-check frequency:	16KHZ
Record time:	260 Min for 128MB
Frequency range:	20-20KHZ
Operation System:	Windows Me/2000/XP/Mac OS8.6 or more
Standard for Bluetooth:	V1.2, Support Hs/HF, A/V Profiles
Time for connectable of Bluetooth Earphone:	150Hs
Time for Playing:	6Hs
Transmission Distance:	10M
Charging time:	2Hs

V. State of Bluetooth MP3 Watch LED

1. Red and Green LED Indicate MP3 to be Operation, Blue LED Indicates Bluetooth to be Operation
2. After opening MP3 Watch, the Red and Green LED will Flash seconds, then Green LED will showing always, Blue LED Flash
3. If the Watch's Blue LED Flash Quickly means the discovery for the Bluetooth Device, Flash slowly means discovery Successful.
4. Green LED showing, Music On, Green LED Flash slowly indicates PAUSE.
5. Red LED Display means charging, Green LED Display means Charging OK.
6. Red LED Flash when connect with Computer.
7. When the Music on, Press the EQ Key one time, the Green and Red LED Flash together, showing Record. Press one more REC Key, the Green LED Flash, the Red LED showing, means Read A-B,
8. The watch will be closed automatically in 5Mins if the Charger is in the low Voltage State.
9. After opening, the Green LED showing means the MP3 Watch in the function state, the Red LED showing means it is in the Recording state.
10. After the opening, then press the Record Key, the Red LED showing means it is in the waiting for recording state.

VI. Operation of Bluetooth MP3 Watch

1. Bluetooth Pairing.

- a. Press the Bluetooth Earphone Playing Key, Blue LED Flash slowly. Press the Bluetooth MP3 Watch on key for a long time, Blue LED Flash 2-60seconds, if the Bluetooth MP3 Watch Pairing the Blue Earphone, the Bluetooth MP3 Watch Blue LED Flash slowly.
- b. Press Bluetooth MP3 Watch Playing Key, The Blue LED will Flash quickly, then Press the Bluetooth Earphone PAUSE key till the Blue and the Red LED Flash alternate, if just the Blue LED Flash means the Bluetooth MP3 Watch Pairing the Bluetooth Earphone successful, at the same time the Bluetooth MP3 Watch Blue LED Flash slowly.

2. Open the Bluetooth MP3 Watch

- a. Press the play key last seconds, the Green and Red LED Flash Seconds, then the Green LED showing, Blue LED Flash.
- b. When in the state of PAUSE OR STOP, Press REW/VOL key Changing between the MP3 Mode and the Record Mode, if the Green LED showing means in the state of MP3 Mode, if the Red LED showing means in the state of Record Mode, if there is no any MUSIC Files in watch the Green LED Display always.

3. MUSIC

- a. Music showing in the MP3 files.
- b. Press the play key, the Green LED showing a long time, press again, the Music will play, the Green LED flash, the Blue LED flash slowly.
- c. Press the PAUSE key when playing, the Green LED flash slowly, press the play key again Music again in shortly time, after 5 Minutes, Bluetooth MP3 Watch will stop the MUSIC automatically, and more 1 Minutes later the Bluetooth MP3 Watch will be off.
- d. Press the Play key last 2 seconds will stop.

4. Recording

- a. Press the play key for a long time without Music on, and Press the REC key going to the state of Recording, the Red LED flash and the recoding files will be keep in the Bluetooth MP3 Watch, which called VOICE file. Stop the Recording, the Red LED will showing.
- b. Without the state of Music, Press the REW/VOL key will change to be the state of recording, if press the EQ/REC key will stop the Record, the Red LED will showing, and press the EQ/REC key will record again.

5. Voice Recording.

- a. Press the Play key for a long time, without the state of Music on, press the REW/VOL key will enter into the Menu of VOICE, the Red LED will showing, press the Play key again will start the Voice Recording, at the same time , the Red LED will showing always, Green LED flash, Blue LED Flash slowly.
- b. Press the Playing Key for PAUSE, the Green LED flash slowly, Press the Play key again, will play the Voice recording files again. If the PAUSE exceed 1 Minutes, MP3 watch will stop playing the Voice recording, return to the VOICE Menu.
- c. Press the play key exceed 2 Seconds will stop the recording.

6. Forward and Backward for Music choose.

- a. In the state of the Music, press the FF/VOL+ key shortly for next Music.
- b. In the state of the Music, press the REW/VOL- key shortly for the precious Music.

7. Volume adjusting

- a. In the state of the Music, press the FF/VOL+ key long for Volume up.

b. In the state of the Music, press the REW/VOL- key long for Volume down.

8. Repeat Mode

In the state of the Music, press the REC key, choose A as the beginning point for start to repeat, the Green and the Red LED flash together, press the REC key again, choose B as the end point, the Green LED flash, the Red LED showing, the Mp3 watch will repeat between A and B till press the REC key to stop the repeat function.

9. EQ MODE

In the state of the Music, press the REC key each time, there is five EQ Mode for changing: POP, Flat, Classic, Jazz and Rock.

10. Memory Function

MP3 watch will keep the memory of the EQ mode and the song after the play off.

11. Delete the recording files

Press the FF/VOL+ key long to delete the recording files if the MP3 watch in the state of the PAUSE or stop, the Red Led flash, after deleting, the Red LED will be off.

12. Charging

a. In the state of playing, if the Red LED flash means the Power is low Voltage, 5 minutes later will be off, please recharging.

b. Mp3 watch connects with power or computer for recharging by USB line, if the Red LED will be on, the Green LED will be off means MP3 watch be in the state of recharging, contrarily, means power fully.

13. Instruction of Operation

Press shortly means 1 second, Press long means exceed 3 seconds.

VII. Instruction of Drive No Drive if connect with Windows Me/2000/XP computer.

VIII. Connection with computer

1. Connect the MP3 watch with the computer by USB line, the Portable Hard Disk will display in the computer.

2. The files in the Mp3 watch and the computer can copy, new, delete each other.

3. Music Download

a. Support the MPEG1/2, Layer3 format, bit 32 kbps-320kbps MP3 files and bit 32kbps-192kbps WMA files

b. When download the files, the Red LED will flash, after the download finished, the Red LED will be off.

c. Data will delete or lost if disconnect the USB line while transmitting.

4. The flash memory function for copy and keep the files.

IX. Function and Character of Bluetooth Earphone

1. JBH-210 Bluetooth Earphone is comply with the Bluetooth Standard 1 which be used in MP3 watch, mobile, computer and the electric appliance, with stereo sound function.

2. Support Headset, Hands free, AVDP.

3. ROSH standard, low radicalization.

4. DSP Frequency Data inside confirm the sound original.

5. Sounds showing excellent.

6. Language Dial function.

7. Re-dial the final Tel NO.

8. Enjoying the Music with no cordless connect the computer.

9. Enjoying the, talking in the computer, like Skype, QQ, MSN.
10. Connection with mobile support Headset/Hands free function.

X. Operation instruction of Bluetooth Earphone

1. Charging for Bluetooth Earphone

- a. Charging Voltage is AC160-240 for charging, connect with the power socket.
- b. Charging connection with computer by USB Line.

Notes:

Before use the Bluetooth Earphone at the first time with full power last 2 Hs.

Charging one time at least in one month.

Charging in the normal temperature, avoiding the high or low temperature.

When charging, the Red LED be on, after finished, be off

2. Correct Measures for open/ close of Bluetooth Earphone

a. Open

Press the play key for 5 seconds till the Red LED flash 3 times will be connectable mode.

b. Close

Press the play key for 5 seconds till showing 2 times sound and the Blue LED flash 2 times will be closed

c. Instruction before Use

To make sure to pair with Mp3 watch before using.

- . Unnecessary repeat pair if Paring link
- . Pairing be link again with different device
- . Pairing be with only device at the same time, finished then can be another device

3. Link with mobile

a. Pairing and Link

- (1) Open the mobile Bluetooth function
- (2) Press the play key till Blue and Red LED flash alternate will go to pair
- (3) Another search function of Bluetooth Earphone (Details reference to Manual)
- (4) Following the text JBH-210 on the mobile screen to accept Pairing, and type into the password: 0000 to link
- (5) The Blue LED of the Bluetooth Earphone will flash slowly if paring successfully.
- (6) Choose the connection in the menu key to make the paring and Link.
- (7) Then you can call and answer freely
- (8) If Pairing fails, repeat the above steps

b. Answering Method

- (1) Press the multi-function of the Bluetooth Earphone to answer when the rings coming
- (2) Press the mobile answering key to answer

c. Ending a call Method

- (1) Press the multi-function of the Bluetooth Earphone to end a call
- (2) Press the mobile answering key to end a call

d. Making a call Method

- (1) Dialing from the Bluetooth Earphone
- (2) Voice Dialing
Press the multi-function key to call the people's name that you wish to call according to the hint (Details reference to the Manual)
- (3) Redialing for the last call
Press the multi-function key over 2 seconds to Redial a call according to the hint

- e. Volume control
 - Adjusting the volume up and down during a call or the connected state
 - f. Transferring a call between Bluetooth Earphone and mobile
 - Press the multi-function over 2 seconds to transfer a call between Bluetooth Earphone and mobile during a call or connected state
 - g. Function with Listening Mp3
4. Connection with computer
- a. Pairing and link
 - (1) Link the Bluetooth Device with the computer and drive the software to make the computer has the Bluetooth cordless function.
 - (2) Pairing will be link after about 60 seconds once press the multi-function till the Red and blue LED flash alternate.
 - (3) Perform a device discovery in the computer
 - (4) Following the text JBH-210 on the computer screen and right-click the icon “pair device” to accept Pairing, and type into the password: 0000 to link
 - (5) On completing Pairing, the Bluetooth Earphone icon marked in the computer together with the Blue LED of the Bluetooth Earphone flash slowly. And right- click the Icon again to find “connection” to execute.
 - (6) Then you can listen to the Music from the computer
 - (7) If Pairing fails, repeat the above steps
 - b. Method for Bluetooth Earphone connection with computer (single phone and AV stereo phone)On completing Pairing both Bluetooth Earphone and computer, the link method for single phone as following:
 - (1) Operation in the computer to link the Bluetooth Earphone: right-click the icon in the computer to find the “connect” to execute the Bluetooth Earphone mode, then listen to the hint and press the multifunction of the Bluetooth Earphone to make sure to link. If no icon in the screen on the computer, please add the “add device from history” in the menu “Tools” to find icon of Bluetooth Earphone to execute the link process
 - (2) Operation in the Bluetooth Earphone to link the computer: Just press the multi-function can link the computer after we have completed the steps mentioned in the method 1. (Just used for Bluesoleil software) On completing Pairing both Bluetooth Earphone and computer, the link method for AV stereo phone similar to the single phone’s
 - c. Remote controlling function of Bluetooth Earphone. Just apply for the window media player, playing, PAUSE, stop remote control.
 - d. Music on, answer a call
 - Transferring the Music AV Mode into answering HFP/HSP Mode when we enjoy the Music, suddenly a call coming, finished the answering will back to be the AV Mode continue to enjoy the Music, which on the condition of connection both Bluetooth Earphone and mobile
5. Connection with speaker or TV
- Connecting with speaker or TV must have the AV device with Audio Frequency Connection and USB Connection to transmit the signal.
- a. Pairing and Link
 - (1) Press the multi-function key till the LED light flash alternate for Pairing in 60 seconds.
 - (2) Make sure the JBD-211A/USB device has the AV function, and open the Device power, then press the Pairing key to complete the Pairing

(3) If the LED light of the Device flash slowly, and the Bluetooth Earphone to be link state and enjoy the Music

4. If Pairing fails, repeat the above steps and try again

a. Close function

Control the sound by play and PAUSE key of the Bluetooth Earphone when be link state with the Device

5. Daily Maintenance.

Avoid the liquid, moisture, erode material.

Avoid the sharpness objects from scratch and damage.

Avoid the strong strength to disassemble the headset.

Charging fully if place leisurely for a long time.

Charger only supported by manufacture for charging. Charging one time at least in one month

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.