

Kids Tablet Instructions

iWawa Home2



Safe & Funny

Warm tip

For better performance and longer battery life, it is recommended that you charge the battery fully 5 hours before using the tablet for the first time and that you initially complete two to three charge cycles. Battery life will vary based on device settings, usage, and others. Certain apps may reduce battery life.

Settings

1. Network & internet

① Wi-Fi

- Click Wi-Fi to turn on the WIFI button, MID will automatically search the available WIFI wireless internet.
- Choose the Wi-Fi internet you want to connect, it will pop up the password window if it needs password, enter password to click connect.
- If you want to change the Wi-Fi to another one, please delete the connected WIFI and then reconnect the new one.

② Data usage

Click to check the details of Wi-Fi data. (The flow data you have used over a period of time.)

③ Hotspot & tethering

1) Wi-Fi hotspot

- Click Wi-Fi hotspot when WIFI is well connected, turn on the hotspot button.
- Set hotspot password
- Turn on "Turn off hotspot automatically", the hotspot will turn off if no devices are connected.

2) USB tethering

Turn on "USB tethering" if you want to share tablet's internet connection via USB.

Tips: Use hotspot and tethering to provide internet to other devices through your mobile data connection. Apps can also create a hotspot to share content with nearby devices.

④ Airplane mode

Wi-Fi can't get any signal if airplane mode is turned on. If you can't surf internet after connect WIFI, you can turn off airplane mode then turn on again to have a try.

2. Apps & notifications

❶ Recently opened apps

You can see recently opened apps in the list.

❷ All apps

You can see Apps info in it

- Storage
- DISABLE / FORCE STOP
- Setting notification

❸ Notifications

On lock screen: you can choose one setting below based on your need.

- Show all notification content
- Don't show notification at all

❹ Allow notification dots

Turn it off if you don't want to see the dot when notifications arrive.

❺ Default notification sound

You can choose the sound you like.

❻ Do Not Disturb

- Sound & vibration: When "Do Not Disturb" is on, sound and vibration will be muted, except for the items you allow. (Alarms / Media / Touch sound)
- Notifications:
 - If "No sound from notifications" is turned on, your phone won't make a sound or vibrate when notifications arrive.
 - If "No visuals or sound from notifications" is turned on, your phone won't show new or existing notifications, and won't make a sound or vibrate. Notifications won't appear when you swipe down from the top of your screen. (Keep in mind, critical notifications for phone activity and status will still appear)
- Custom restrictions:

You can hide notification dots, icons if you don't want to get notification notices.
- Do Not Disturb Duration:

Until you turn off
For 1 Hour or more (Click – or + to adjust the time)
Ask for every time.

3. Battery Setting

- You can see the battery situation, estimated standby time, last full charge and screen usage since full charge.

- b. Some futures may be limited when battery saver is on.
- c. When Battery Manage detects that apps are draining battery, you'll have the option to restrict these apps. Restricted apps may not work properly and notifications may be delayed.

Please note that battery usage data is approximate and can change based on usage.

4. Display

① Brightness level

You can adjust the brightness level from 0% to 100%

② Adaptive Brightness level

When "Adaptive Brightness" is turned on, your screen brightness will automatically adjust to your environment and activities. You can move the slider manually to help adaptive brightness learn your preferences.

③ Wallpaper

You can choose wallpaper from Live Wallpapers, Photos and Wallpapers.

④ Sleep

Setting the automatic sleep time for Never, 15/30 second, 1/2/5/10/30 minutes.

⑤ Advanced

- a. Auto-rotate screen: The screen will be rotate automatically if turn it on.
- b. Font size: Make the text on screen smaller or larger. (Four levels)
- c. Display size: Make the items on your screen smaller or larger. Some apps on your screen may change position. (Four levels)
- d. Screen saver
- e. Device theme: Automatic (based on wallpaper), Light, Dark, choose the one you want.

5. Sound

① Sound setting:

You can increase or decrease the volume below:

Media volume / Call volume / Alarm volume / Notification volume

② Do Not Disturb (Turn on or Turn off)

③ Shortcut to prevent ringing (On / vibrate)

Press Power & Volume Up together (On / vibrate)

④ Default notification sounds

⑤ Default alarm sounds

⑥ Screen locking sounds

⑦ Charging sounds

⑧ Touch sounds

6. Screenshot

- a. Select delay time to capture the screen (15/30 seconds later, 1/2/5/10/30

minutes later)

- b. Show the screenshot button in the status bar. (On or Off)

7. Storage

- a. Storage situation(used and free)
- b. Storage manager by category: Phone & videos, Musical & audio, Games, Movie & TV apps, other apps, Files and System.

8. System

① Language & input

1) Language

- a. Click languages (You can see the default language)
- b. Add a language if you can't see that in default language, search it on the top of your screen.
- c. Long press the right lines to move the language position. (Put it on the first place if you want to set it by this language)

2) Keyboard & input

The keyboard contains below typing options:

Gboard (Multilingual typing) / Google voice typing

② Updates

Please do not update operate system by your own, any changes or modifications without permission which operated by unauthorized user will result in internal failure, system halted.

iWawa Home2 (Parental Control System)

1. Security control

iWawa Home can ensure a secure network environment for kids through apps filter and website filter, which is easy for parents to separate contents that are not suitable for their children and protect kids' physical and psychological growth, parents can filter the contents which need to be blocked.


① Applications Filter

Select appropriate applications which are shown in kid's desktop, block inappropriate ones such like bloody and violent applications.




2 Websites Filtering

When children use the internet browser, it will automatically block the websites without parental permission. Parents can create some proper websites for kids so kids will not browse other unsafe websites.



3 Media Content

Parents can create specific media files for kids, which kids can enjoy their own music, photos and video.




2. Content and management

Provide children with rich applications resources, and use tools to manage applications, video, music and other contents.

① Applications Recommendation


iWawa Home will recommend some educational games and applications that are suitable for kids. The recommended contents will be regularly updated and can be downloaded for free.



② Multimedia Management

Children can open "Video" application in the desktop and watch all the good movies

selected by parents. Similarly, children can open the "Gallery" and "Music" application and see pictures or listen to songs which are previously prepared for kids.




3. Behavior Restrictions

iWawa can restrict kids' behaviors through Child Lock, Consumption Restraint, Time Limit, and Behavior Report, thus children can't disturb parents' desktop any more, and unexpected consumption and games addiction can be avoided effectively.

① Child Lock:

Without the permission of parents, children will not be able to login the child desktop. Not only ensure that kids stay in a safe environment, but also ensure that kids do not have access to parents' desktop applications.




2 Consumption Restraint

This function can effectively prevent kids' unexpected consumption from clicking wrong button, because all the purchases require parents' confirmation by entering the password.

3 Time Limit

Parents can set a timetable for kids to use the tablet and have a break time regularly, it will automatically start break time mode when time is up, and it will become temporarily unusable, which is flexible to protect kids' growing environment.



4 Behavior Report:

The tablet system automatically produces detailed reports of applications usage, which record kid's behaviors on using various applications and the frequency, in this way, parents can easily understand kids' habits and preferences.



4. Featured Functions

iWawa have provided many practical and convenient feature functions for parents and kids, such as Personal Style, Multiple Accounts, Prolong Time Quickly, Setting WIFI, Karaoke, Kids Video and Parents Remote Control.


1 Personal Style

There are multiple beautiful themes to choose, and children can create their own beautiful space.



2 Multiple Accounts:


A tablet can set up more than one account, each child can have their own account and what they are playing can be distinguished.



3 Prolong Time Quickly

Parents can enter a password to prolong 30 minutes for kids, and deal with some


unexpected conditions easily.




4 Setting WIFI:

- Enter into the parental control home page, click the setup button and get access to the page of setting,
- Click Android Settings and skip to the page of setting Android system.
- Click WLAN on the page, it will automatically search and connect to WIFI.


Step 1:



Step 2:



Step 3:



5 Karaoke:

Placing the music video files to the specific path of storage, and the system will automatically recognize the files, which makes you can see them in the menu

interface, click it to enjoy music video for free! MKV video formats files are available to support switching freely between the original and Karaoke. Sing along to millions of songs with music videos and subtitles.















1) Kids Video

There are various wonderful children videos and will be updated regularly, which concludes Cartoon, Learning, Music, Stories. Kids will love them so much.

2) Parent Remote Control

Parents can download the iWawaParent App to remotely control the tablet with iWawaHome App for time limit and network filtering.





Warning Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.