
CR M540 HTC Rhyme Docking Station User Guide



Charging the battery using the dock

- Insert the small end of the supplied USB cable into the USB connector of the dock.
- 2. Insert the other end of the USB cable into the power adapter.
- Plug in the power adapter to an electrical outlet.
- Align the dock contacts on HTC Rhyme with the contacts on the dock.



5. Gently press HTC Rhyme down to secure it in place.

Switching to Dock Mode

Dock Mode turns HTC Rhyme into a desk clock, photo slideshow viewer, or music player. You can also set it as a speakerphone when you receive calls while HTC Rhyme is docked.

- With the dock plugged in, place HTC Rhyme into the dock.
 HTC Rhyme automatically turns on Bluetooth and switches to Dock Mode.
- 2. If prompted, choose how you want to use the dock for audio.

While in Dock Mode, you can:

Play music	 Tap the playback buttons to control music playback.
	 Tap the album cover to open your music library.
	 Tap
View the time and weather information	 Tap the clock widget to open the Clock app where you can set alarms or show the time in another city.
	 Tap the weather information to open the Weather app and check forecasts or the next few days.
Play a photo slideshow	Tap Photo frame to view the photos on your storage card as a slideshow.
Access apps on HTC Rhyme	Tap the shortcut icons at the bottom of the screen to open apps such as Calendar.
	To customize the shortcuts, press and hold an appicon, and then select a new app. (Or, press MENU ≡ , and then tap Shortcuts.)
Dim the screen	Tap the dim control 🍪 button.
Modify dock settings	Press MENU 實, and then tap Settings.

To exit Dock Mode, tap 🚳 or remove HTC Rhyme from the dock.

Using Desk Clock

The Desk Clock displays the current date, time, and weather. It also shows an alarm clock indicator and the battery level.

- Tap the weather image or information to open the Weather app where you can see weather forecasts for the next few days.
- Tap III to switch to Dock Mode. Tap
 (8) to exit Dock Mode.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution

- . Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.
- . This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

FCC Notice

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.