Pairing from the Bluetooth® Device

In the Search from Device screen ► Search for the car name and pair the device ▶ Enter the Passkev ▶ Bluetooth® becomes connected.





From the Bluetooth® device, search for the car name and pair the device.

When searching from the Bluetooth® device, the car name is Santa Fe Sport and the default passkey is '0000'.

Information

- · To learn more about searching from Bluetooth® devices and pairing, refer to the user's manual for your Bluetooth® device
- Bluetooth® devices cannot be paired when the vehicle is in motion. For your safety, first park the vehicle to pair a Bluetooth® device.

When a Phone is Already **Paired**

Press the key on the steering wheel remote controller or the **PHONE** key ▶ Press Yes ▶ Select the device from the device list ▶ Press Connect





Basic Mode Screen





- Select the device you want to connect and press the Connect button.
- If the phone you want to connect does not exist, press the Add New button to pair a new Bluetooth® device.

Name	Description
1 Help	Help section related to pairing and connecting/disconnecting Bluetooth® devices and Hands- free phone features
2 Add New	Pair a new Bluetooth® device
3 Connect/ Disconnect	Connect or disconnect a Bluetooth® device
4 Delete	Delete a paired Bluetooth® device
5 Delete All	Delete all paired Bluetooth® device
6 Auto Connection	Set Bluetooth® auto-connection when car ignition is turned on

When Pairing Additional Device

Press the Add New button to pair a new Bluetooth® device.

For more information on pairing, refer to the 'When no phones have been paired' section.

i Information

 When a Bluetooth® device is connected, a new device cannot be paired. If you want to pair a new phone, first disconnect the connected Bluetooth® device.

When There is a Connected Device

Press the key on the steering wheel remote controller or the PHONE key on the head unit to display the following screen.



Enter the phone number you wish to call and press the Send button.

- · The mobile phone battery and signal strength icons may not be supported in some mobile phones.
- · The remaining battery level displayed on your mobile phone battery icon may slightly differ with the device display.
- · The speed dial feature may not be supported in some mobile phones.

Name	Description
1 Info Display Window	Displays name of currently connected device
2 Send	If no number has been entered, switches to call history screen If a number has been entered, calls the number
3 End	If a number has been entered, deletes the number During a call, ends the current call
4 Dial Pad	Used to enter the phone number Press and hold 0 to enter a '+' Press and hold 1 ~ 9 to connect to the speed dial saved within the mobile phone
5 Favorites	Displays the Favorites list screen
6 Delete	Deletes entered numbers one digit at a time
7 Contacts	Displays contacts list screen
8 Connections	Displays the Bluetooth® device Connections screen
9 Remaining Battery	Displays the remaining battery for the connected Bluetooth® device
10 Call Signal Strength	Displays the call signal strength

During a Call



The name of the other party is displayed if the number is saved within your contacts. If not, only the phone number is displayed. During a call, the other party's name/number and the call time are displayed.

- **1** Information
- The telephone number may not be displayed in some mobile phones.

Name	Description
1 Info Display Window	Displays other party's name/number If there is a waiting call, displays the call waiting information
2 Switch	If there is a call waiting, switches the current call and connects the waiting call
3 End	Ends call
4 Dial Pad	Used to enter phone number
5 Contacts	Displays the Contacts screen
6 Private	During a handsfree call, this function is used to switch the call to the mobile phone Upon switching the call to Private, the vehicle mic and speaker will turn off to allow a private conversation through the mobile phone
7 Outgoing Vol.	Adjusts outgoing volume during calls Sets call volume as heard by the other party (Levels 0~5) The outgoing volume may be heard differently depending on the connected Bluetooth® device

Status Bar Icons

Name	Description	
6	Mutes call volume	
18	Bluetooth® phone call state	
	Mobile phone contacts or call history download status	
® n	A state when Bluetooth® Handsfree and streaming Audio is all connected	
* 7	State when Bluetooth® streaming Audio is connected	
20	State when Bluetooth® Handsfree is connected	

Making/Answering Calls

Calling by Dialing a Number

Fnter number on the Dial Pad ▶ Press the Send or the key on the steering wheel remote controller.





If you press the Send button without entering a number, the Call History screen is displayed. Press and hold the dial pad 0+ (over 0.8 seconds) to enter a "+".

Name	Description
1 Send	Calls the entered phone number
2 End	Deletes all entered numbers

Information

 Most Audio and Setup mode features will not operate during a Bluetooth® handsfree call. Only the call volume and Navigation mode screen can be operated.

Making a Call from Speed Dial

Enter the 1 or 2 digit speed dial number with the Dial Pad ▶ Press and hold the last number.



- For speed dials saved within mobile phones, up to 2 digits are supported.
- Saving or changing speed dial numbers through the head unit is not supported.

Calling through Redial

Press and hold (over 0.8 seconds) the Send button or the key on the steering wheel remote controller.




1 Information

 Redialing is not possible when there is no call history or the Bluetooth® phone has not been connected.

Making a Call from Call History

Press the Send button or the key on the steering wheel remote controller ► Select contact from the Call History ► Press Call.







- Calling through the call history is not possible when there is no call history or the Bluetooth® phone has not been connected.
- Within the call history screen, press the Download button to download the call history saved in your mobile phone into the vehicle.
- For more information on downloading call histories, refer to the "Call History >> Downloading Call History" section.

Answering a Call

Incoming call notice ▶ Press the Accept button or the key on the steering wheel remote controller.



When there is an incoming call, the bell will sound and the phone number of the other party will be displayed on the incoming call pop-up, as shown here.

Information

- · When the incoming call pop-up is displayed, most audio and SETUP mode functions will not operate. Only the call volume and Navigation screens can be operated.
- · The telephone number may not be displayed in some mobile phones.

Rejecting a Call

Incoming call notice ▶ Press the Reject button or the key on the steering wheel remote controller.

Information

· The reject call function may not be supported in some mobile phones.

Operating Menus during a Call

Switching Call to Bluetooth® Phone

During handsfree call ▶ Press the Press the Private button or press and hold the key (over 0.8 seconds) on the steering wheel remote controller.







The call will be switched from the handsfree to the Bluetooth® mobile phone.

i Information

 The Private function may not be supported in some mobile phones.

Switching Call to the Handsfree

During call on mobile phone ▶ Press the Use Handsfree button or press and hold the key (over 0.8 seconds) on the steering wheel remote controller.



The call will be switched from the Bluetooth® mobile phone to the car handsfree.

Ending a Call

While on a call ▶ Press the I button or the key on the steering wheel remote controller



The Bluetooth® handsfree call will end.

Switching to Call Waiting

If another person calls while you are already on a call, the current call must be placed on hold or ended to answer the new call.





If there is waiting call, press the key on the steering wheel remote controller (under 0.8 seconds) or press the Switch button on the Phone screen.

Name	Description
1 Hold 1st Call	Places current call on call waiting and answers new call
2 End 1st Call	Ends current call and answers new call
3 Reject	Rejects new call and maintain current call
4 Switch	If there is a call waiting, switches to the waiting call


- · Call waiting is a feature that allows the caller to answer a second call while already on a call. When call waiting is used, the first call is placed on waiting mode.
- · Switching to call waiting may not be supported in some mobile phones.

Setting Mic Volume

While on a call ▶ Press the Qutgoing Vol.

▶ Set Outgoing Volume ▶ Press OK





If you press the Mute button, the outgoing volume is muted and blocked to the other party.

1 Information

 The volume heard by the other party may differ depending on the mobile phone. If call volume heard by the other party is too low or too high, adjust the volume setting.

Adjusting the Ring/Call Volume


While on a call ▶ Use the ♥ VOL knob on the head unit or the VOL+, VOL-keys on the steering wheel remote controller to adjust the ring/call volume.



Contacts

Press the **PHONE** key on the head unit or the key on the steering wheel remote controller Press Contacts





- For contacts, up to 5,000 entries can be downloaded to each paired Bluetooth® device.
- · Contacts can be viewed only when a Bluetooth® device has been connected.
- If there are numerous list entries, selecting the list page area will move to the corresponding list page.
- It is possible to download contacts during a call or while operating Bluetooth® streaming audio mode.
- When downloading contacts, the icon will be displayed within the status bar.
- It is not possible to download contacts when the contacts download setting has been turned off within your Bluetooth® device.
- · Some devices may also require device authorization to download contacts.
- If downloading cannot be normally conducted, check the Bluetooth[®] device settings or whether download confirm popup is displayed on the phone screen.
- The download feature may not be supported in some mobile phones.
- · Check to see that the Bluetooth® device supports the download feature.
- · For more information on mobile phone compatibility, visit the Hyundai Motor Company website (http://www.hyundaiusa.com).

Mobile Contacts Screen Configuration



Name	Description
1 Search	Search downloaded mobile phone contacts (Search by name or number)
2 Download	Download contacts from Bluetooth® device
3 Bluetooth® Device Name	Name of connected Bluetooth® device
4 List Page	Displays total number of list pages and current list page (List page jump upon selecting scroll area)
5 Download Source	Displays whether contacts were downloaded from the mobile phone or SIM

- · Mobile phone contacts can be searched only when a Bluetooth® device is connected.
- Up to 5,000 contacts from your Bluetooth® phone or SIM can be downloaded into the car contacts. Contacts that have been downloaded to the car cannot be edited or deleted.
- Mobile phone contacts are managed separately for each paired Bluetooth® device (max 5 devices x 5,000 contacts each). Previously downloaded data will be stored even if the Bluetooth® device has been disconnected. (However, the contacts and call history saved to the phone will be deleted if the paired phone is deleted.)
- Downloaded contacts could be lost depending on the state of the head unit. Always make sure to back up important data.

Downloading Mobile Phone Contacts

Press the Download button in the Contacts screen ▶ Press Yes





Information

Time required to download contacts may differ depending on your mobile phone model or data size.



- · Upon downloading mobile phone contacts, the previous data is deleted.
- · This feature may not be supported in some mobile phones.
- · Upon downloading, contacts saved in your SIM and mobile phone are downloaded simultaneously.
- · To change the contacts download settings, change the following menu setting.



- · When using Contacts Sync, the contacts and call histories within your mobile phone are automatically downloaded once Bluetooth® is connected.
- To turn this feature off, go to SETUP Bluetooth Contacts Sync Setting

Checking Mobile Contacts Details

Select the desired phone number from the mobile contacts list to check details about the contact.





Adding as a Favorite

Select number from the Contacts screen ► Within the details screen, press Add as Favorite ► Press Add





- · Up to 8 Favorites can be added.
- Saved Favorites can be viewed by pressing the * Favorite* button in the Phone screen.
- The Favorites Information screen is displayed only when there are more than 2 saved numbers.
- If there is only 1 saved number, then the number is directly saved to the Favorites list.

Favorites

Calling Favorites

In Phone screen ▶ Press ★ Favorite ▶ Select the desired Favorite ▶ Call is connected.






Information

- Favorites can be added through Phone Add as Favorite
- Up to 8 Favorites can be added and Favorites can be used only when a Bluetooth® device has been connected.

Selecting/Deleting Favorites

In Favorites screen ▶ Press Delete Items ▶ Select items you want to delete and press Delete Press Yes





Searching Contacts

In Phone screen ▶ Press Search





Search by Name

Press the Search by Name button >
Enter name and press Search



1 Information

 When searching for a number it is possible to search by entering just a part of the name.

Searching by Number

Press the Search by Number button >
Enter number and press Search



1 Information

 When searching a number, it is possible to search by entering just a part of the entire number.

(ex : if you enter "1544", all numbers that include "1544" will be searched.)

Call History

Entering Call History Screen

Within the Phone screen, press the Send button or the key on the steering wheel remote controller.








- **Information**
- · The call history may not be saved in the call history list in some mobile phones.
- · Calls received with hidden caller ID will not be saved in the call history list.

Call History Screen Configuration



Name	Description
1 Dialed Call	Displays the outgoing call history list
2 Received Call	Displays the incoming call history list
3 Missed Call	Displays the missed call history list
4 Download	Downloads call history from mobile phone

Downloading Call History

In Call History screen ▶ Press Download







- **i** Information
- Up to 20 dialed, incoming, and missed call history lists can be downloaded. The dialed/incoming time and call time information are not supported.

- · Sorting call histories by time is not supported.
- It is possible to download call history even during a call or during Bluetooth® streaming audio.
- When downloading call histories, the icon will be displayed within the status bar.
- It is not possible to start downloading when the call history download feature is turned off within the Bluetooth® device. Also some devices may require device authorization upon attempting to download call history. If downloading cannot be normally conducted, check the Bluetooth® device settings or the screen state.
- The download feature may not be supported in some mobile phones. Check to see that the Bluetooth® device supports the download feature.
- For more information on mobile phone compatibility, visit the Hyundai Motor website (http://www.hyundaiusa.com).

Viewing Call History Information

Within the Call History screen, select the wanted call.





Name	Description
1 Download	Download call histories from mobile phone
2 Call	Calls the number
3 Delete	Deletes the call history

Setting Bluetooth® Connection

Press the Gonnections button on the Phone screen.





Connections Menu



Name	Description
1 Help	Displays Bluetooth® Help screen
2 Add New	Pairs a new Bluetooth® device
3 Connect/ Disconnect	Connects/disconnects a Bluetooth® device
4 Delete	Deletes a paired Bluetooth® device
5 Delete All	Deletes all paired Bluetooth® devices
6 Auto Connection	Sets Bluetooth® device auto connection when car ignition is turned on
7 Paired Device List	Shows list of paired Bluetooth® devices
8 Streaming Connection State	Shows Bluetooth® Streaming connection state
9 Handsfree Connection State	Shows Bluetooth® Handsfree connection state

Connecting a Device

Select the device you wish to connect from the list ▶ Press Connect









The Phone screen is displayed once Bluetooth® Handsfree is connected, and the Bluetooth® Audio screen is displayed once audio streaming is connected.

Pairing a New Device

For more information on pairing, refer to the 'When no phones have been paired' section.



- Bluetooth® features supported within the vehicle are as follows. Some features may not be supported depending on your Bluetooth® device.
 - Answering and placing Bluetooth® Handsfree calls
 - Menu operation during call (Switch to Private, Switch to Call Waiting, Outgoing Volume)
 - Download Call History
 - Download Mobile Contacts
 - Download SIM Contacts
 - Contacts/ Call History Auto Download
 - Bluetooth® device auto connection
 - Playing Bluetooth® Streaming Audio
- It is possible to pair up to five Bluetooth[®] devices to the car system.

- Only one Bluetooth® device can be connected at a time.
- Other devices cannot be paired while a Bluetooth® device is already connected.
- When a Bluetooth® device is in the process of connecting, the connection process cannot be canceled.
- Only Bluetooth® Handsfree and Bluetooth® Audio related features will operate within this system.
- Normal operation is possible only for devices that support handsfree or audio features, such as a Bluetooth® mobile phone or a Bluetooth® audio device.
- Only one function can be used at a time between the Bluetooth® handsfree and Bluetooth® audio. (While playing Bluetooth® audio, streaming will end upon entering the Bluetooth® phone screen.)

Information

- If a connected Bluetooth® device becomes disconnected for various reasons, such as being out of range, turning the device OFF, or a Bluetooth® communication error. Bluetooth® devices are automatically searched and connected
- · If the system becomes unstable due to communication errors between the vehicle and the Bluetooth® device, reset the Bluetooth® feature and try again. Upon resetting Bluetooth® feature, the system is restored to its factory release state. Press the SETUP key ▶ Bluetooth Advanced Settings Restore Factory Settings

Disconnecting a Device

Select the device you wish to disconnect ▶ Press Disconnect ▶ Press Yes







Deleting a Device

Select the device you want to delete ▶ Press Delete Press Yes





A device cannot be deleted if it is connected. To delete a paired device, first disconnect the Bluetooth® connection and then delete the paired device.

Press Delete All to delete all paired Bluetooth® devices.

i Information

 If a paired phone is deleted, its call history and contacts lists will also be deleted.

Setting Auto Connection

Press the Auto Connection button ► Select the desired option ► Set and press Done.





If auto connection is turned on, a Bluetooth® device will automatically be connected according to the set option when the car ignition is turned on.

Name	Description
1 Disable Auto Connection	Disables auto connection
2 Previously Connected Phone	Auto connection with the previously connected Bluetooth® phone
3 User Selected Phone	Automatically connects to a user selected Bluetooth® device
4 Connect by Priority	Automatically connects according to the set Bluetooth® phone priority

- The Auto Connection button is a shortcut menu to go to SETUP > 8 Bluetooth
 Auto Connections Settings
- If you press the Setting button next to the User Selected Phone and Connect by Priority options, you can designate the phone you wish to connect or set the phone priority.

5 Voice Recognition

- ·Using Voice Recognition
- ·Voice Command Lists

CAR AVN SYSTEM

Using Voice Recognition

Starting Voice Recognition

Starting Voice Recognition

Shortly press the key on the steering remote controller (under 0.8 seconds)

▶ Say a command.





Once voice recognition starts, the voice command entry window and the six representative commands are displayed.

- If voice recognition is in [Normal Mode], then the system will say "Please say a command," followed by a beep tone.
- If voice recognition is in [Expert Mode], then you will only hear a beep.

(e.g. screen displayed when 'Help' is said)



NOTICE

 For proper recognition, say the command after the voice instruction and beep tone.

i Information

 To change the Normal/Expert setting, press the SETUP key and enter the Voice Recognition settings screen.

Skipping Prompt Messages

While prompt message is being stated ► Shortly press the ₭ key on the steering remote controller. (under 0.8 seconds)

The prompt message is immediately ended and the beep tone will sound. After the "beep", say the voice command.

Re-starting Voice Recognition

While system waits ▶ Shortly press the key on the steering remote controller. (under 0.8 seconds)

The command wait state will end and the beep tone will sound. After the "beep", say the voice command.

Ending Voice Recognition

While Voice Recognition is operating Press and hold the kev on the steering remote controller. (over 0.8 seconds)



While using voice recognition, pressing a steering wheel remote control or a different key will end voice recognition.

- In a state where the system is waiting for a voice command, say "cancel" or "exit" to end voice recognition.
- You can also press and hold the key on the steering remote controller to end voice recognition.

Using Voice Recognition

Using Voice Recognition

Press the key on the steering remote controller. The voice command entry window and the six representative commands are displayed.

1 Information

- If voice recognition is set to 'Expert', then the 'Please say a command' prompt will not be provided. Only the 'beep' will sound.
- If voice recognition is set to 'Expert', then the six representative commands are not shown on the screen.
- After the 'Beep', the) icon will change to the (icon to indicate that a command can now be stated.

Adjusting Voice Recognition Volume

While Voice Recognition is operating ► Turn the ● VOL knob left/right to adjust the voice recognition prompt volume.



Illustration on Using **Voice Recognition**

(Setting Home as the Destination)

Press the key (under 0.8 seconds). The system awaits for your command and display a list of accessible commands on the screen.









Voice Command Lists

Voice Command List

Voice commands within this system are categorized into "Common Commands" and "Mode Commands."

- Common Commands (): commands that can be used in all situations.
- Mode Commands (): commands that can be used in specific multimedia/navigation/Bluetooth® mode states.

1 Information

 Some commands will operate properly only when a USB, iPod, Bluetooth® or other device has been connected.

Help Command List

Command	Operation	
Help	Displays the main Help screen	
Destination Help	Displays the Destination related command list	
Map Help	Displays the Map related command list	
Radio Help	Displays the FM/AM radio related command list	
XM Help	Displays the XM radio related command list	
Disc Help	Displays the DISC mode related command list for the disc inserted in the CD Player	
iPod Help	Displays the iPod related command list	
USB Help	Displays the USB related command list	
Phone Help	Displays the Phone related comand list	

Audio System Command List

FM/AM Radio

Command	Operation
Radio	Plays the most recent frequency for the most recently operated band
(Radio) AM	Plays the most recent frequency for the corresponding band
(Radio) FM	Plays the most recent frequency for the corresponding band In the case of FM. The most recent frequency within the most recently played FM1 or FM2 band is played
● FM1/FM2	Plays the most recent frequency for the corresponding band
• AM <530~1710>	Plays the desired AM band frequency (e.g. AM "Five-Hundred Thirty")
• FM <87.5~107.9>	Plays the desired FM band frequency (e.g. FM "Eighty-Seven point Five")
● AM Preset <1~6>	Plays the desired AM band preset frequency
● FM1 Preset <1~6>	Plays the desired FM1 band preset frequency
● FM2 Preset <1~6>	Plays the desired FM2 band preset frequency

	0	Onessation
	Command	Operation
0	Preset <1~6>	Plays the desired preset frequency for the current band
0	Seek Up	Searches and plays the next frequency of the current band
0	Seek Down	Searches and plays the previous frequency of the current band
0	Preset Up	Plays the next preset frequency of the current band
0	Preset Down	Plays the previous preset frequency of the current band
0	Auto Store	Searches all frequencies within the current band and stores the 6 frequencies with the most superior reception as preset buttons
0	Scan On	Scans receivable frequencies from the current broadcast and plays for 5 seconds each
0	Scan Off	Ends the currently operating Scan or Preset Scan feature
0	Preset Scan	Plays through all presets for five seconds each, beginning with the current preset

Voice Command Lists

XM Radio

	Command	Operation
•	XM	Plays the last channel within the last band from XM1, XM2, and XM3
•	XM1/XM2/XM3	Plays the most recent channel for the corresponding band
•	XM Channel <1~255>	Plays the desired XM band channel (e.g. XM channel "Eleven")
•	XM1 Preset <1~6>	Plays the desired preset channel for XM1 band
•	XM2 Preset <1~6>	Plays the desired preset channel for XM2 band
•	XM3 Preset <1~6>	Plays the desired preset channel for XM3 band
0	Channel <1~255>	Plays the desired channel of the current band
0	Preset <1~6>	Plays the desired preset channel of the current band
0	Channel Up	Plays the next channel of the current band
0	Channel Down	Plays the previous channel of the current band

	Command	Operation
0	Preset Up	Plays the next preset channel of the current band
0	Preset Down	Plays the previous preset channel of the current band
0	Scan On	Scans receivable channels from the current broadcast and plays for 5 seconds each
0	Scan Off	Ends the currently operating Scan or Preset Scan feature
0	Preset Scan	Plays through all presets for five seconds each, beginning with the current preset

CD(Audio Type)

	Command	Operation
•	CD	If the DISC inserted in the CD Player is either a CD or MP3 DISC, then the CD or MP3 will be played
•	CD Track <1~99>	If the DISC inserted in the CD Player is a CD, then CD Mode will start and plays the desired track
0	Play	Plays the currently paused song
0	Pause	Pauses the current song
0	Next Track	Plays the next track
0	Previous Track	Plays the previous track
0	Repeat On	Repeats the current track
0	Repeat Off	Cancels repeat play to play tracks in sequential order
0	Shuffle On	Randomly plays the tracks within the CD
0	Shuffle Off	Cancels random Play to play tracks in sequential order
0	Scan On	Plays each file for 10 seconds beginning with the current file
0	Scan Off	Ends the currently operating Scan feature
0	Track <1~99>	Plays the desired track number

CD(MP3 Type)

	Command	Operation
•	CD	If the DISC inserted in the CD Player is either a CD or MP3 DISC, then the CD or MP3 will be played
0	Play	Plays the currently paused song
0	Pause	Pauses the current song
0	Next File	Plays the next track
0	Previous File	Plays the previous track
0	Next Folder	Plays the first file in the next folder
0	Previous Folder	Plays the first file in the previous folder
0	Repeat On	Repeats the current file
0	Repeat Off	Cancels repeat play to play files in sequential order
0	Repeat Folder	Repeats all files in the current folder
0	Shuffle On	Plays all files within the CD in random order
0	Shuffle Off	Cancels random play to play files in sequential order
0	Shuffle Folder	Randomly plays the files within the current folder
0	Scan On	Plays each file in the folder for 10 seconds beginning with the current file
0	Scan Off	Ends the currently operating Scan or Folder Scan feature
0	Folder Scan	Plays each file in the folder for 10 seconds beginning with the current file

Voice Command Lists

USB Music

	Command	Operation
•	USB	If the USB has been connected to the device, play the MP3 or image files within the USB
•	USB Music	If the USB has been connected to the device, plays the MP3 files within the USB
•	Play	Plays the currently paused song
0	Pause	Pauses the current song
0	Next File	Plays the next track
0	Previous File	Plays the previous track
0	Next Folder	Plays the first file in the next folder
0	Previous Folder	Plays the first file in the previous folder
0	Repeat On	Repeats the current file
0	Repeat Off	Cancels repeat play to play files in sequential order
0	Repeat Folder	Repeats all files in the current folder
0	Shuffle On	Plays all files within the USB in random order
0	Shuffle Off	Cancels random play to play files in sequential order
0	Shuffle Folder	Randomly plays the files within the current folder
0	Scan On	Plays each file in the folder for 10 seconds beginning with the current file
0	Scan Off	Ends the currently operating Scan or Folder Scan feature
0	Folder Scan	Plays each file in the folder for 10 seconds beginning with the current file

USB Image

	Command	Operation
•	USB	If the USB has been connected to the device, play the MP3 or image files within the USB
•	USB Image	If the USB has been connected to the device, displays the image files within the USB
0	Next File	Displays the next image file
0	Previous File	Displays the previous image file
0	Next Folder	Displays the first image file within the next folder
0	Previous Folder	Displays the first image file within the previous folder

iPod

	Command	Operation
•	iPod	Plays the songs within the iPod if the iPod has been connected to the device
0	Play	Plays the currently paused song
0	Pause	Pauses the current song
0	Next Song	Plays the next song
0	Previous Song	Plays the previous song
0	Repeat On	Repeats the current file
0	Repeat Off	Cancels repeat play to play files in sequential order
0	Shuffle On	Plays all files within the current category in random order
0	Shuffle Off	Cancels random play to play files in sequential order

My Music

	Command	Operation
•	My Music	Plays the songs within the My Music
0	Play	Plays the currently paused song
0	Pause	Pauses the current song
0	Next File	Plays the next file
0	Previous File	Plays the previous file
0	Repeat On	Repeats the current file
0	Repeat Off	Cancels repeat play to play files in sequential order
0	Shuffle On	Plays all files within the current category in random order
0	Shuffle Off	Cancels random play to play files in sequential order
0	Scan On	Plays each file in the folder for 10 seconds beginning with the current file
0	Scan Off	Ends the currently operating Scan or Folder Scan feature

Voice Command Lists

Others

Command	Operation
Audio On	Turns on the Audio
Audio Off	Turns off the Audio
Bluetooth Audio	Plays Bluetooth [®] Audio
Auxiliary	Plays the connected auxiliary device
Blue Link	Displays the Blue Link mode screen

Phone Command List

	Command	Operation
•	Call Name	Makes the call to the name
•	Call <name></name>	Call <name> saved in Contacts (e.g. Call "John")</name>
•	Dial Number	Makes the call to the number
•	Dial <number></number>	Call can be made by dialing the spoken numbers (e.g. Dial "123")
•	Contacts	Displays list of saved contacts Say the name to connect the call to the corresponding contact
•	Recent Calls	The user can select a number from the outgoing, incoming, and missed calls
•	Redial	Connects the most recently called number

Navigation Command List

Destination

Command	Operation
Find Address	Sets the destination through address search for route guidance
Previous Destination	Sets the previous destination as the current destination
Previous Searches	Sets one of the previous searches as the current destination
Find Nearest POI	Sets a POI near the current position as the destination for route guidance through the POI category search
Find the Nearest <poi category=""></poi>	Sets a POI near the current position as the destination by directly inputting the POI name for route guidance (e.g. Find the Nearest "Restaurants") For more information on <poi category="">, refer to Page 3-30.</poi>
Destination POI by Phone Number	Sets the destination by searching the phone number of the facility
Emergency Police	Searches for a police station near the current position and sets it as the destination for route guidance
Emergency Hospital	Searches for a hospital near the current position and sets it as the destination for route guidance

	Command	Operation
_	Find Emergency Dealership	Searches for a dealership near the current position and sets it as the destination for route guidance
•	My Places	Sets one of the list of previously registered addresses in the My Places as the destination
•	Go Home	Sets the previously registered home address as the destination for route guidance
•	Go to Office	Sets the previously registered office address as the destination for route guidance
	Previous Start Position	Sets the previous start position as the current destination
	Favorite Place <1 ~ 5>	Sets a previously registered favorite place as the destination for route guidance

Voice Command Lists

Мар

	Command	Operation
•	Map Current Location	Displays the current position of the vehicle
•	Voice Guidance On	Turns the Voice Guidance On
•	Voice Guidance Off	Turns the Voice Guidance Off
•	Voice Guidance Louder	Increases the Voice Guidance volume by 1 level
•	Voice Guidance Softer	Decreases the Voice Guidance volume by 1 level
•	Repeat Voice Guidance	Repeats the route guidance
•	Cancel Route	Deletes the designated destination and terminates the route guidance
•	Detour <1, 2, 5, 10> mile(s)	Searches detour routes within a <1, 2, 5, 10> mile radius
•	Detour <1, 2, 5, 10> kilometer(s)	Searches detour routes within a <1, 2, 5, 10> kilometer radius
•	Distance to Destination	Reports the remaining distance until destination by voice
•	Time to Destination	Reports the remaining time until destination by voice
•	Store Marked Location to <text tag=""> (ex : Store Marked Location to "User 1")</text>	Registers the selected location into the selected Address book
•	Replan Faster Time Route	Recalculates the route with faster time route

Command	Operation
Replan Shorter Distance Route	Recalculates the route with shorter distance route
Zoom In/Zoom Out	Decreases/Increases the map zoom by one level
Zoom <scale></scale>	Displays the map in the corresponding zoom <scale> : 150, 300, 700 feet/0.25, 0.5 miles/1 mile/2, 4, 8, 16, 64, 130, 250 miles 50, 100, 200, 400, 800 meters/1.6, 3.2, 6.4, 12, 25, 50, 100, 200, 400 kilometers</scale>
Zoom Maximum	Displays the map screen in the maximum zoom level
Zoom Minimum	Displays the map screen in the minimum zoom level
View Route	If the destination has been set, displays the entire route on the screen until the destination
XM Traffic	Displays XM Traffic information on the screen
Auto Zoom On	Turns the Auto Zoom feature on
Auto Zoom Off	Turns the Auto Zoom feature off
Auto Mode	Automatically converts the map display between daylight and night mode
Daylight Mode	Converts the map display into daylight mode
Night Mode	Converts the map display into night mode
North Up	Displays the map in North Up mode
Heading Up	Displays the map in Heading Up mode

POI Category List

Restaurants
African Restaurants
American Restaurants
Asian Restaurants
Chinese Restaurants
Coffee Shop
Continental Restaurants
Fast Food
French Restaurants
Italian Restaurants
Japanese Restaurants
Korean Restaurants
Latin American Restaurants
Mexican Restaurants
Seafood Restaurants
Vegetarian Restaurants
Other Restaurants
Automotive
Auto Parts
Auto Service
Automobile Dealership
Car Wash
Gas Station
Hyundai Dealership
Motorcycle Dealership
Parking

Rest Area	
Road Assistance	
Travel	
Airport	
Bus Station	
Campground	
City Center	
Ferry Terminal	
Hotel	
Local Transit	
Rental Car Agency	
Tourist Attraction	
Tourist Information	
Train Station	
Travel Agent	
Shopping	
Bookstore	
Clothing Shop	
Convenience Store	
Department Store	
Electronics Store	
Gift Shop	
Grocery Store	
Hardware Store	
Home Specialty Store	
Music Store	

Pharmacy
Shoe Store
Shopping Center
Sporting Goods Store
Recreation
Amusement Park
Cinema
Golf Course
Museum
Recreation Area
Ski Resort
Sports Activities
Sports Complex
Video & Game Rental
Winery
Other Recreation
Financial Services
ATM
Bank
Business Facility
Check Cashing Service
Money Transfer
Community
City Hall
Civic Center
Convention Center

Court House Fire Department Government Offices Library Police Station Post Office School Utilities Waste & Sanitary Services Attorney	
Government Offices Library Police Station Post Office School Utilities Waste & Sanitary Services Attorney	
Library Police Station Post Office School Utilities Waste & Sanitary Services Attorney	
Police Station Post Office School Utilities Waste & Sanitary Services Attorney	
Post Office School Utilities Waste & Sanitary Services Attorney	
School Utilities Waste & Sanitary Services Attorney	
Utilities Waste & Sanitary Services Attorney	
Waste & Sanitary Services Attorney	
Services Attorney	
Attorney	
Ola a salsa ar O. I. a consalsa c	
Cleaning & Laundry	
Communication Services	
Dentist	
Funeral Home	
Hair & Beauty	
Hospital	
Medical Service	
Mover Services	
Photography	
Physician	
Social Service	
Tailor & Alteration	
Tax Service	

MEMO

6 Information

- ·XM Data
- ·Blue Link®
- ·GPS Information
- ·Help

CAR AVN SYSTEM

XM Data

About XM Data

Press the INFO key ▶ Press ✓ XM Data





About XM Data Service

The XM Data Service is a paid membership Satellite radio service which provides users with traffic, stock, sports, and weather information. However, weather information is not supported for vehicles purchased in Canada.



Name	Description
1 Weather	Displays weather information for the next three days Press the More button to check details
2 Traffic	Displays road accident/traffic information Press the More button to check details
3 Stocks	Shows stock information for three Favorite Stocks Press the More button to check details
4 Sports	Shows sports team information for two My Teams Press the More button to check details